

Genesis 80GMVS

Genesis 80GMVS Multi-Functional Vacuum Sealer Instruction Manual

Model: 80GMVS

1. INTRODUCTION

Thank you for choosing the Genesis 80GMVS Multi-Functional Vacuum Sealer. This appliance is designed to preserve food, liquids, and dry goods efficiently, making it suitable for food preservation, meal preparation, and sous vide cooking. Please read this manual thoroughly before operating the device to ensure safe and optimal performance.

Important Safety Instructions

- Read all instructions before use.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only manufacturer-recommended attachments.
- Do not use outdoors.
- Always place the appliance on a stable, flat, heat-resistant surface.
- Avoid contact with moving parts.
- Do not use for purposes other than its intended use.

2. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your Genesis 80GMVS Vacuum Sealer:

1. **Control Panel:** Buttons for various sealing modes (Normal, Soft, Seal, External) and Stop.
2. **Sealing Strip:** Heats to create a strong seal on vacuum bags.
3. **Vacuum Channel:** Area where air is extracted from the bag.

4. **Lid Latch:** Secures the lid during operation.
5. **Accessory Port:** For connecting an external vacuum hose (not included) for containers.
6. **Power Cord:** Connects the unit to an electrical outlet.



Figure 2.1: Overview of the Genesis 80GMVS Multi-Functional Vacuum Sealer. This image displays the top view of the vacuum sealer, highlighting its sleek design and the control panel with various function buttons.

3. SETUP

1. **Unpack:** Carefully remove the vacuum sealer from its packaging. Retain packaging for future storage or transport.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Placement:** Place the vacuum sealer on a dry, flat, and stable surface, ensuring adequate space around the unit for ventilation.
4. **Power Connection:** Plug the power cord into a standard electrical outlet. The indicator light may illuminate, indicating the unit is ready.

4. OPERATING INSTRUCTIONS

This section details how to use your vacuum sealer for various food types and sealing methods.

4.1 Preparing Bags and Food

- Use only vacuum sealer bags designed for this appliance.
- Ensure the bag is clean and dry inside the sealing area.
- Leave at least 7-10 cm of space between the food and the top of the bag for proper sealing.
- For moist foods, pre-freeze or place a paper towel inside the bag to absorb excess moisture.

4.2 Vacuum Sealing (Dry Mode)

1. Place the open end of the bag into the vacuum channel. Ensure it lies flat and smooth over the sealing strip.
2. Close the lid firmly until the latches click into place.
3. Press the **NORMAL** button for standard vacuum and seal. The appliance will automatically vacuum the air and then seal the

- bag.
4. Once the process is complete, the indicator light will turn off. Press the lid release buttons (if present) or gently lift the lid to open.
 5. Remove the sealed bag.



Figure 4.1: The Genesis 80GMVS vacuum sealer in operation, sealing a bag containing salmon. This image demonstrates the appliance actively extracting air from a bag, preparing it for preservation.

4.3 Vacuum Sealing (Wet/Moist Mode)

For foods with moisture, use the **WET** setting (often combined with Normal/Soft depending on model, or indicated by a specific button if available). This mode adjusts the vacuum pressure and sealing time to accommodate liquids, preventing them from being drawn into the vacuum pump.

1. Follow steps 1 and 2 from "Vacuum Sealing (Dry Mode)".
2. Press the **WET** button (if available) or select the appropriate setting for moist food.
3. The appliance will proceed with vacuuming and sealing.
4. Once complete, open the lid and remove the sealed bag.

4.4 Soft Vacuum Mode

For delicate items like bread, chips, or pastries, use the **SOFT** mode to prevent crushing. This mode reduces the vacuum pressure.

1. Follow steps 1 and 2 from "Vacuum Sealing (Dry Mode)".
2. Press the **SOFT** button.
3. Monitor the vacuum process. When the desired air removal is achieved, press the **SEAL** button immediately to stop vacuuming and initiate sealing.
4. Once complete, open the lid and remove the sealed bag.



Figure 4.2: A close-up view of the Genesis 80GMVS control panel and the sealing area with meat inside a bag. This image highlights the various control buttons, including 'STOP', 'NORMAL', 'SOFT', 'SEAL', and 'EXTERNAL', providing a clear view of the user interface during operation.

4.5 Seal Only Function

Use the **SEAL** button to create a seal without vacuuming. This is useful for making custom-sized bags from a roll or for resealing bags of snacks.

1. Place the open end of the bag over the sealing strip.
2. Close the lid firmly.
3. Press the **SEAL** button. The sealing indicator light will illuminate.
4. Once the light turns off, the seal is complete. Open the lid and remove the bag.

4.6 External Vacuum Function

The **EXTERNAL** function is used with an external vacuum hose (sold separately) to vacuum seal canisters, jars, or wine stoppers.

1. Connect one end of the external vacuum hose to the accessory port on the vacuum sealer.
2. Connect the other end of the hose to the port on your vacuum-sealable container.
3. Press the **EXTERNAL** button. The appliance will begin to extract air.
4. The vacuuming will stop automatically or when you press **STOP**.
5. Remove the hose from the container and the appliance.



Figure 4.3: Examples of various food items, including sliced meat, fish, and dried goods, successfully vacuum-sealed in transparent bags. This image illustrates the effectiveness of the vacuum sealer in preserving different types of food.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will extend the life of your vacuum sealer.

- **Before Cleaning:** Always unplug the appliance from the power outlet.
- **Exterior:** Wipe the exterior of the unit with a damp cloth and mild soap. Do not use abrasive cleaners or immerse the unit in water.
- **Vacuum Channel:** Clean any food residue or liquids from the vacuum channel using a damp cloth. Ensure it is completely dry before next use.
- **Sealing Strip:** Gently wipe the sealing strip with a soft, dry cloth. Do not scratch or damage the strip, as this can affect sealing performance.
- **Storage:** Store the appliance in a clean, dry place with the lid unlatched to prevent compression of the sealing gaskets, which can lead to poor seals over time.

6. TROUBLESHOOTING

If you encounter issues with your vacuum sealer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet.

Problem	Possible Cause	Solution
Bag does not vacuum properly.	Lid not properly closed; bag not positioned correctly; bag is damaged; moisture in vacuum channel.	Ensure lid is latched; reposition bag so opening is flat in vacuum channel; check bag for holes; clean and dry vacuum channel.
Bag does not seal.	Sealing strip is dirty or damaged; bag is wrinkled; too much moisture.	Clean sealing strip; ensure bag is flat; pre-freeze moist foods or use paper towel.
Air leaks into bag after sealing.	Improper seal; sharp objects in bag; bag material defect.	Re-seal the bag; ensure no sharp edges on food; use high-quality vacuum bags.

7. SPECIFICATIONS

Feature	Detail
Brand	Genesis
Model Number	80GMVS
Material	Plastic
Operation Mode	Manual
Product Dimensions	44L x 18.5W x 10.5H centimetres
Item Weight	1.4 kg
Colour	Multicolor



8. WARRANTY AND SUPPORT


For warranty information and customer support, please refer to the documentation provided with your purchase or contact Genesis customer service. Keep your proof of purchase for warranty claims.

Manufacturer: Genesis



Related Documents - 80GMVS

	<p>2019 Genesis G70 Owner's Manual: Operation, Maintenance, and Safety Guide</p> <p>Your essential guide to the 2019 Genesis G70. This owner's manual provides detailed information on vehicle operation, safety features, maintenance, and specifications to ensure a safe and optimal driving experience.</p>
	<p>2022 Genesis G70 Owner's Manual</p> <p>Your essential guide to the 2022 Genesis G70. This owner's manual provides detailed information on vehicle operation, safety features, maintenance schedules, and all onboard systems for the Genesis G70 (Model NG90-EU12B).</p>

<div><div>OWNER'S MANUAL</div><div>Operation</div><div>Maintenance</div><div>Specifications</div></div> <div><p>Read this manual before driving your Genesis vehicle. It contains important information about the safe operation, maintenance, and use of your vehicle. It also contains information about the features and equipment available on your vehicle. Please read this manual carefully and keep it with you at all times. It is your responsibility to read this manual and understand the information it contains. Failure to do so may result in injury or damage to your vehicle.</p></div>	<p>Genesis Owner's Manual: Operation, Maintenance, and Specifications for Electric Vehicle</p> <p>Comprehensive owner's manual for Genesis electric vehicles, covering operation, maintenance, safety features, charging, and specifications. Essential guide for Genesis Branded Vehicle owners.</p>
<div><div>GENESIS CARE PLAN</div><div>TERMS, CONDITIONS, AND SERVICES</div></div> <div><p>The Genesis Care Plan is a comprehensive maintenance and service program designed to provide Genesis vehicle owners with peace of mind. It covers scheduled maintenance, roadside assistance, pick-up/delivery, courtesy cars, software updates, and connected services for Genesis vehicles in the UK.</p></div>	<p>Genesis Care Plan: Terms, Conditions, and Services</p> <p>Explore the comprehensive Genesis Care Plan, covering scheduled maintenance, roadside assistance, pick-up/delivery, courtesy cars, software updates, and connected services for Genesis vehicles in the UK.</p>
<div><div>OWNER'S MANUAL</div><div>Operation</div><div>Maintenance</div><div>Specifications</div></div> <div><p>Read this manual before driving your Genesis vehicle. It contains important information about the safe operation, maintenance, and use of your vehicle. It also contains information about the features and equipment available on your vehicle. Please read this manual carefully and keep it with you at all times. It is your responsibility to read this manual and understand the information it contains. Failure to do so may result in injury or damage to your vehicle.</p></div>	<p>Genesis Owner's Manual: Your Guide to Operation, Safety, and Maintenance</p> <p>This comprehensive owner's manual provides essential guidance for Genesis vehicle owners on safe operation, maintenance, and understanding of their vehicle's features, specifications, and systems.</p>
<div><div>2020 GENESIS G70</div><div>GETTING STARTED GUIDE</div><div>AUDIO, CONNECTIVITY, AND NAVIGATION</div></div> <div></div>	<p>2020 Genesis G70 Getting Started Guide: Audio, Connectivity, and Navigation</p> <p>A comprehensive guide for the 2020 Genesis G70, covering essential features for audio, smartphone connectivity (Android Auto, Apple CarPlay), phone pairing, making calls via voice commands, navigation system usage, and Genesis Connected Services. Learn how to customize your driving experience and stay connected.</p>