

Manuals.plus /

› home stuff /

› home stuff 7-Tier Wall Shelf Unit with LED Remote Control Light (White) Instruction Manual

home stuff Display shelving

home stuff 7-Tier Wall Shelf Unit with LED Remote Control Light (White)

Brand: home stuff | Model: Display shelving

1. INTRODUCTION

Thank you for choosing the home stuff 7-Tier Wall Shelf Unit. This manual provides essential information for the safe assembly, operation, and maintenance of your new shelf unit. Please read these instructions carefully before beginning assembly and retain them for future reference.





Image 1: The home stuff 7-Tier Wall Shelf Unit, showcasing its design and potential for display.

2. PRODUCT FEATURES

- **7-Tier Design:** Maximizes vertical space for organizing and displaying items.
- **Extra Strong Backboard:** Provides enhanced durability and stability for secure mounting.
- **Versatile Use:** Suitable for bedrooms, living rooms, hallways, offices, and more, functioning as a bookshelf, shoe shelf, or general display unit.
- **Modern Aesthetic:** Minimalist design blends seamlessly with contemporary home decor.
- **Integrated LED Remote Control Light:** Enhances display items and adds ambient lighting.

OUR BRAND

OTHER BRAND



Image 2: Detailed view of key features including the LED light, robust backboard, and ease of maintenance.

3. SAFETY INFORMATION

- **Weight Capacity:** The maximum load capacity is 55 lbs horizontally and 6 lbs vertically per shelf. Do not exceed these limits to prevent damage or injury.
- **Secure Mounting:** Always ensure the shelf unit is securely mounted to a sturdy wall using appropriate hardware. Failure to do so may result in the unit tipping over.
- **Children and Pets:** Keep children and pets away from the unit during assembly. Do not allow children to climb on the shelves.
- **Placement:** Avoid placing the unit in high-traffic areas where it could be easily bumped or knocked over.

4. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Shelf Panels (7 pieces)
- Backboard Panel (1 piece)
- Mounting Hardware (screws, wall anchors)

- LED Light Unit (1 piece)
- Remote Control (1 piece)
- Instruction Manual (this document)

5. ASSEMBLY INSTRUCTIONS

Assembly is required for this shelf unit. It is recommended to have two people for easier and safer assembly. Please follow these steps carefully:

1. **Prepare the Area:** Clear a spacious, flat, and clean area for assembly. Lay out all components and hardware.
2. **Attach Shelf Panels to Backboard:** Carefully align the pre-drilled holes on the shelf panels with those on the backboard. Use the provided screws to secure each shelf to the backboard. Ensure all connections are tight.
3. **Install LED Light (Optional):** If using the LED light, attach it to the designated area on the top shelf according to the separate LED light instructions.
4. **Wall Mounting:**
 - Choose a suitable location on a sturdy wall.
 - Mark the drilling points on the wall using the backboard as a template.
 - Drill pilot holes and insert wall anchors if necessary (for drywall).
 - Carefully lift the assembled shelf unit and align it with the drilled holes.
 - Secure the unit to the wall using the provided mounting screws. Ensure it is level and stable.
5. **Final Check:** Gently test the stability of the installed shelf unit before placing any items on it.

No More Untidiness

A powerful wall shelf that mounts easily, holds strong, and organizes beautifully.




Image 3: Product dimensions and the strong backboard, crucial for stable assembly.

Holds More Than Just Décor



LED Lights with Remote Control



Versatile Design Fits Any Space



Upgraded Strong Backboard for Support



Easily Clean with Simple Wipe

Image 4: Illustration of the sturdy construction with a strong backboard and premium wood.

6. OPERATING INSTRUCTIONS (LED REMOTE CONTROL LIGHT)

Your home stuff 7-Tier Wall Shelf Unit includes an LED light with a remote control for convenient operation.

1. **Battery Installation:** The remote control requires 1 Lithium Ion battery (included). Open the battery compartment on the remote and insert the battery, ensuring correct polarity.
2. **Turning On/Off:** Press the "ON" button on the remote control to activate the LED light. Press the "OFF" button to turn it off.
3. **Brightness Adjustment:** Use the brightness control buttons (e.g., "+" and "-" or specific symbols) on the remote to adjust the light intensity.
4. **Timer Function:** If available, use the timer button (e.g., "30 min") to set the light to automatically turn off after a specified period.



Image 5: Visual guide for the LED light and its remote control functions.

7. MAINTENANCE

To ensure the longevity and appearance of your shelf unit, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using abrasive cleaners or harsh chemicals, which can damage the finish.
- **Dusting:** Regularly dust the shelves to prevent buildup.
- **Inspection:** Periodically check all screws and mounting hardware to ensure they remain tight and secure. Tighten if necessary.
- **LED Light Care:** If the LED light stops working, first check the battery in the remote control. If the issue persists, contact customer support.

8. TROUBLESHOOTING

If you encounter any issues with your home stuff 7-Tier Wall Shelf Unit, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shelf unit is wobbly/unstable.	Loose mounting screws or improper wall anchors.	Ensure all wall mounting screws are tightened. Verify that appropriate wall anchors were used for your wall type.
LED light not turning on.	Remote control battery is dead or incorrectly installed.	Replace the remote control battery or check its polarity. Ensure the LED unit is properly connected.
Items sliding off shelves.	Shelf is not level.	Re-adjust the shelf unit to ensure it is perfectly level during installation.

9. SPECIFICATIONS

Feature	Detail
Brand	home stuff
Model Name	Display shelving
Color	White
Material	Engineered Wood
Number of Shelves	7
Product Dimensions (D x W x H)	9.25"D x 9.4"W x 74"H
Item Weight	20 Pounds
Weight Limit (Horizontal)	55 Pounds
Weight Limit (Vertical)	6 Pounds
Installation Type	Wall Mount
Special Feature	LED Remote Control Light (Cordless)
Assembly Required	Yes
Batteries	1 Lithium Ion battery required (for remote)

10. WARRANTY AND SUPPORT

For any inquiries, missing parts, or support needs, please contact the seller directly through your purchase platform. Specific warranty details may vary and are typically provided at the point of purchase or by the seller.