

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Braun](#) /
- › [Braun Series 5 5118s Electric Shaver Instruction Manual](#)

Braun 52-B1200s

Braun Series 5 5118s Electric Shaver Instruction Manual

PRODUCT OVERVIEW

The Braun Series 5 5118s electric shaver is engineered to provide a clean and fast shaving experience with optimal comfort. It features a flexible shaving head with 3 blades designed to adapt to facial contours, ensuring close contact with the skin. This model supports both wet and dry shaving, offering versatility for your grooming routine. The shaver is equipped with two distinct shave modes: Standard for balanced performance and Turbo for an accelerated shave. Its EasyClean system simplifies maintenance, allowing for quick rinsing under water without removing the shaver head.



Figure 1: Braun Series 5 5118s Electric Shaver

WHAT'S IN THE BOX

Your Braun Series 5 5118s package includes the following components:

- 1x Braun Series 5 5118s Electric Shaver
- 1x Precision Trimmer EasyClick Attachment
- 1x Cleaning Brush
- 1x Charging Cable and Base



Figure 2: Box Contents - Shaver and Precision Trimmer

Unboxing Video

Video 1: This video demonstrates the unboxing process of the Braun Series 5 shaver, showing the included items and initial presentation.

FEATURES

- **Clean and Fast Shave:** Designed for a comfortable and efficient shave.
- **3 Flexible Blades:** The shaver head adapts to your unique face contours for a close shave while protecting your skin.

3 FLEXIBLE BLADES

ADAPTS TO YOUR CONTOURS FOR A CLOSE SHAVE



Figure 3: Flexible Blades for Contour Adaptation

- **2 Shave Modes:** Choose between Standard mode for optimal balance and comfort, or Turbo mode for an extra fast shave with up to 25,500 cutting actions per second.



Figure 4: Turbo Shaving Mode

- **100% Waterproof:** Suitable for both wet and dry use, including in the shower.



Figure 5: Waterproof Design for Wet & Dry Use

Waterproof Demonstration Video

Video 2: This video demonstrates the waterproof capabilities of the Braun Series 5 shaver by showing it submerged in water while operating.

- **EasyClick System:** Easily swap and upgrade your shaver heads with various attachments.
- **Precision Trimmer:** Includes a Precision Trimmer EasyClick attachment for detailing.



Figure 6: 2-in-1 Grooming Tool with Precision Trimmer

- **Long-lasting Battery:** Features a Li-Ion battery with up to 50 minutes of runtime. A 5-minute quick charge provides enough power for one shave.
- **Engineered in Germany:** Guarantees quality and durability.

OPERATING INSTRUCTIONS

Charging the Shaver

Before first use, fully charge the shaver. Connect the charging cable to the shaver and plug it into a power outlet. The battery indicator lights on the shaver will show the charging status. A full charge provides up to 50 minutes of cordless shaving. For a quick shave, a 5-minute charge is sufficient.

Shaving

You can use the Braun Series 5 5118s for both dry and wet shaving. For dry shaving, ensure your face is clean and dry. For wet shaving, you may use shaving foam or gel. Press the power button to turn on the shaver. Select your desired shave mode: Standard for a balanced shave or Turbo for a faster, more powerful shave. Gently move the shaver against the direction of hair growth, ensuring the flexible head maintains contact with your skin.

Using the Precision Trimmer

To use the precision trimmer, ensure the shaver is turned off. Detach the main shaver head by pulling it off.

Attach the Precision Trimmer EasyClick attachment until it clicks into place. Turn on the shaver and use the trimmer for precise styling of sideburns, mustache, or beard lines.

Travel Lock

To prevent accidental activation during travel, activate the travel lock. Press and hold the power button for 3 seconds until the lock symbol appears on the display. To deactivate, press and hold the power button again for 3 seconds.

Product Review Video

Video 3: This video provides a review and testing of the Braun Series 5 electric shaver, demonstrating its features and performance.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your shaver.

- **EasyClean System:** After each use, always unplug the shaver. With the shaver head attached, rinse the shaver under warm running water. The EasyClean system allows water to flow through the cutting elements, flushing out stubble without needing to remove the head.



Figure 7: EasyClean System in Action

- **Deep Cleaning:** For a more thorough clean, remove the shaver head and rinse both the head and the

shaver body under warm running water. Allow all parts to air dry completely before reassembling or storing.

- **Cleaning Brush:** Use the provided cleaning brush to remove any stubborn hair particles from the shaver head or body. Do not use the brush on the foil part of the shaver head as it may damage it.
- **Shaver Head Replacement:** For optimal shaving performance, replace the shaver head (foil and cutter block) every 18 months. The shaver may indicate when a replacement is due.



Figure 8: Replacing Shaver Head

TROUBLESHOOTING

If you encounter any issues with your Braun Series 5 5118s shaver, please refer to the comprehensive user manual included in your package or visit the official Braun support website for detailed troubleshooting steps and solutions.

SPECIFICATIONS

Model Number	52-B1200s
Product Dimensions	5.39 x 2.64 x 9.92 inches
Item Weight	13.76 ounces
Power Source	Battery Powered (1 Lithium Ion battery included)
Special Feature	Rechargeable, Wet & Dry Use, Waterproof
Manufacturer	Procter & Gamble
UPC	069055139264

WARRANTY AND SUPPORT

The Braun Series 5 5118s is engineered in Germany, reflecting a commitment to quality. For specific warranty details, including coverage period and terms, please refer to the warranty card included in your product packaging or contact Braun customer support directly. Support information can typically be found on the official Braun website.

