

JoyGeek GD305

JoyGeek

JoyGeek 3-in-1 Wireless Charging Station

INSTRUCTION MANUAL

Product Overview

The JoyGeek 3-in-1 Wireless Charging Station is designed to simultaneously charge your iPhone (12-16 series), Apple Watch (2-10/Ultra), and AirPods (3, 2, Pro). This compact and foldable charger offers a space-saving solution for both work and travel, featuring strong magnetic suction for secure device placement and an adjustable night light with three different settings.

Setup Guide

Your JoyGeek 3-in-1 Wireless Charging Station comes ready-to-use with all necessary components. Follow these steps for initial setup:

- Unpack Contents:** Carefully remove the charging station, data cable, and 18W adapter from the packaging.
- Connect Power:** Insert the data cable into the charging station's USB Type A port and connect the other end to the provided 18W adapter. Plug the adapter into a standard wall outlet.
- Positioning:** Place the charging station on a flat, stable surface. The foldable design allows for various configurations, including an upright position for phone charging or a tilted angle for optimal viewing.

Image: The JoyGeek 3-in-1 Wireless Charging Station connected to its power adapter, ready for use.

Your browser does not support the video tag.

Video: An official demonstration of the JoyGeek 3-in-1 Charger Stand for Magsafe, showcasing its features and ease of use.

Operating Instructions

This charging station simplifies your charging routine. Ensure the station is powered on before placing devices.

Charging Your Devices

- **iPhone:** Place your Mag-Safe compatible iPhone (iPhone 12-16 series) onto the magnetic charging pad. The strong magnetic suction will align your device for optimal charging. The phone can be charged in an upright position or tilted for viewing.
- **AirPods:** Open the designated AirPods charging spot on the station and place your AirPods (Pro/2/3/4 wireless version) inside. Charging will begin automatically.
- **Apple Watch:** Extend the Apple Watch charging arm from the side of the station and place your Apple Watch (Series 2-10/Ultra/Ultra2/S9/8/7/6/5/4/3/2/SE) onto the charging puck.



Image: The charging station actively charging an iPhone, AirPods, and Apple Watch simultaneously, demonstrating its multi-device capability.



Image: A detailed compatibility chart showing supported iPhone, AirPods, and Apple Watch models and their respective charging wattages.

Adjustable Night Light

The charging station features an adjustable night light at its base. Press the button on the front to cycle through three different light options: warm white, cool white, and natural light, or turn the light off. This feature makes it an ideal bedside companion.



Image: The charging station on a nightstand, illustrating its use as a night light with an iPhone in nightstand mode.

Your browser does not support the video tag.

Video: A short demonstration of the charging station's nightstand mode and its ability to charge multiple devices simultaneously.

Care and Maintenance

To ensure the longevity and optimal performance of your charging station, follow these simple care instructions:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe down the surface of the charging station. Avoid using abrasive cleaners, solvents, or harsh chemicals.
- **Storage:** When not in use or for travel, fold the charging station into its compact form. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Safety:** Do not disassemble or attempt to repair the device yourself. Keep it away from water and high humidity.



Image: The charging station shown in its foldable and portable configurations, highlighting its convenience for storage and travel.

Troubleshooting

If you encounter any issues with your JoyGeek 3-in-1 Wireless Charging Station, please refer to the following common solutions:

- **Device Not Charging:**

- Ensure the charging station is properly connected to the 18W adapter and a working power outlet.
 - Verify that your device is correctly aligned on the charging pad. The strong magnetic suction should help with alignment.
 - Remove any thick phone cases (greater than 0.16 inches or 4mm) or metal objects, credit cards, magnets, or PopSockets from your phone, as these can interfere with wireless charging.
- **Night Light Not Working:**
 - Press the light control button on the front of the station to cycle through the light modes.
 - Ensure the station is receiving power.
 - **Phone Not Staying on Pad:**
 - Confirm your iPhone is Mag-Safe compatible.
 - Ensure there are no obstructions or foreign objects between the phone and the charging pad.

The charging station features multi-functional chip protection against over-current, over-voltage, short-circuit, and overheating, ensuring safe charging for your devices.

Product Specifications

Feature	Detail
Brand	JoyGeek
Model Number	GD305
Package Dimensions	4.41 x 3.82 x 3.5 inches
Item Weight	11.7 ounces
Color	White
Connectivity Technology	Wireless
Connector Type	USB Type A
Input Voltage	9 Volts
Mounting Type	Tabletop Mount
Special Features	Magnetic, Magsafe Compatible, Wireless Charging, Multi-Device Portable, Adjustable Night Light
Included Components	Mag-Safe charger, high-quality data cable, QC 3.0 adapter

Warranty and Support

Your JoyGeek 3-in-1 Wireless Charging Station comes with a **24-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable performance of your device.

Please retain your proof of purchase for warranty claims.

For any questions, technical assistance, or warranty support, please refer to the contact information provided in the product packaging or visit the official JoyGeek website.