

- Manuals.plus /
- › GreenForest /
- › GreenForest Folding Desk (35.4 inch, Black) Instruction Manual

GreenForest Folding Desk 35.4 inch

GreenForest Folding Desk (35.4 inch, Black) Instruction Manual

Model: Folding Desk 35.4 inch | Brand: GreenForest

1. INTRODUCTION

This manual provides instructions for the GreenForest 35.4 inch Black Folding Desk. This desk is designed for versatility and space-saving, suitable for various environments such as home offices, studies, bedrooms, and small apartments. It features a no-assembly design for quick setup and easy storage.



Image 1.1: The GreenForest 35.4 inch Black Folding Desk in use.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using the product.

- Ensure the desk is stable when in use to prevent tipping.
- Handle with care to maintain durability.
- Do not place excessively heavy items on the desk. Refer to specifications for weight capacity.
- Keep fingers clear of folding mechanisms during setup and storage to avoid pinching.

3. SETUP AND OPERATION

The GreenForest Folding Desk requires no assembly. It is designed for quick unfolding and folding.

3.1 Unfolding the Desk

1. Place the folded desk flat on the floor.

2. Gently unfold the left and right leg frames outwards.
3. Locate the support rod and insert its pins into the designated slots on the leg frames to secure them.
4. Carefully flip the desk upright. Ensure all legs are fully extended and locked into place before use.

Open and use without installation

3 seconds to complete, no installation issues




Image 3.1: Visual guide for unfolding the desk.



Image 3.2: Detailed 3-step unfolding process.

3.2 Folding the Desk

1. Clear all items from the desk surface.
2. Carefully flip the desk upside down.
3. Remove the support rod from its slots.
4. Fold the leg frames inwards until the desk is in its compact, folded state.

3.3 Instructional Video

For a visual demonstration of how to correctly open and close the desk, please watch the video below:

Video 3.1: Demonstration of opening and closing the GreenForest Folding Desk.

4. STORAGE

The folding design allows for convenient storage in various small spaces.

- The folded width is approximately 2.8 inches, making it very thin.
- It can be stored behind a door, under a sofa, or under a bed.
- Its lightweight nature makes it easy to move and transport.



Image 4.1: Examples of space-saving storage options for the folded desk.



Easy To Carry Around



Image 4.2: The desk is lightweight and easy to carry.

5. MAINTENANCE

To ensure the longevity and appearance of your GreenForest Folding Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surface with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all connections and moving parts to ensure they are secure.
- **Protection:** Avoid prolonged exposure to direct sunlight or extreme temperatures to prevent material degradation.

6. TROUBLESHOOTING

If you encounter any issues with your GreenForest Folding Desk, consider the following general troubleshooting steps:

- **Stability Issues:** Ensure the support rod is correctly inserted into the leg frame slots. Verify that the desk is placed

on a flat, even surface.

- **Difficulty Folding/Unfolding:** Check for any obstructions in the folding mechanism. Ensure the support rod is fully disengaged before folding.
- **Damaged Parts:** If any part of the desk appears damaged or broken, discontinue use and contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	GreenForest
Model	Folding Desk 35.4 inch
Color	Black
Product Dimensions (L x W x H)	35.4" x 18.9" x 29.5"
Folded Width	2.8 inches
Item Weight	16.9 Pounds
Top Material Type	Engineered Wood
Base Material	Metal
Special Features	Foldable, Lightweight, Multifunctional, Portable, Scratch Resistant
Assembly Required	No
Product Care Instructions	Wipe with Dry Cloth



Image 7.1: Product dimensions when open and folded.

8. WARRANTY AND SUPPORT

For warranty information or customer support, please contact GreenForest directly through their official channels or the retailer where the product was purchased. Keep your purchase receipt for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CM5B9GKW>

More documents and user manuals: <https://manuals.plus/>