

ETENWOLF AIR3

ETENWOLF AIR 3 Air Pump Instruction Manual

MODEL: AIR3

Introduction

Thank you for choosing the ETENWOLF AIR 3 Air Pump. This compact and powerful device is designed for quick inflation and deflation of various inflatable products, and also features a versatile camping light. Please read this manual carefully before use to ensure proper operation and maintenance.



2X Faster than Ever



2,600mAh Battery



Air Mattress



Inflatables



5 Adapter Nozzles



Camping Light



Vacuum Bag

Image: The ETENWOLF AIR 3 pump demonstrating its inflation and deflation capabilities on an inflatable item.

Key Features:

- Fast Inflation & Deflation:** Achieves rapid inflation/deflation with 0.65 PSI (4.5 kPa) air pressure and 13 CFM (360 L/min) wind speed.
- Large Battery Capacity:** Equipped with a 2600 mAh Lithium Battery, capable of inflating multiple items on a single charge.
- Compact & Lightweight:** Designed for portability, easily attachable to a backpack or stored in a pocket.
- Integrated Camping Light:** Features a 600 Lumens LED light with three modes for various lighting needs.
- Versatile Nozzles:** Includes five different nozzles to fit most inflatable products.

What's in the Box

- ETENWOLF AIR 3 Air Pump
- USB-C Charging Cable
- 5 Adapter Nozzles
- Storage Bag



Image: The ETENWOLF AIR 3 Air Pump and its accessories laid out, including the pump, USB-C cable, various nozzles, and a black storage bag.

Setup

1. **Charge the Device:** Before first use, fully charge the ETENWOLF AIR 3 using the provided USB-C cable. The pump cannot be powered on while charging. Unplug the power cable before turning it on.
2. **Select Appropriate Nozzle:** Choose one of the five included nozzles that best fits the valve of your inflatable item.
3. **Attach Nozzle:** Securely attach the selected nozzle to the inflation port (for inflating) or deflation port (for deflating) of the air pump.



Image: A nozzle specifically designed for sleeping pads, showing its size and shape.



Image: A nozzle specifically designed for air mattresses, showing its size and shape.

Operating Instructions

Inflation

1. Ensure the correct nozzle is attached to the inflation port (located on the side of the pump).
2. Insert the nozzle firmly into the inflatable item's valve.
3. Press the power button once to start inflation. The pump will operate at 0.65 PSI (4.5 kPa) and 13 CFM (360 L/min).
4. Monitor the inflation process and turn off the pump by pressing the power button once when the item is sufficiently inflated.



Image: A visual representation highlighting the ETENWOLF AIR 3's 2X faster inflation speed with 360 L/min airflow.

Deflation

1. Attach the appropriate nozzle to the deflation port (located on the top of the pump).
2. Insert the nozzle firmly into the inflatable item's valve.
3. Press the power button once to start deflation.
4. Allow the pump to extract air until the item is fully deflated. Turn off the pump by pressing the power button once.



Image: A nozzle designed for vacuum storage bags, illustrating its use for efficient deflation and space-saving.

Camping Light Function

1. Press and hold the light button to turn on the LED light.

2. Press the light button repeatedly to cycle through the three brightness modes: 60 Lumens (soft light), 200 Lumens (reading light), and 600 Lumens (outdoor light).

3. Press and hold the light button again to turn off the light.



Image: The ETENWOLF AIR 3 functioning as a camping light, showcasing its three distinct light modes and their respective durations.

Maintenance

- Keep the air pump clean and free from dust and debris.
- Store the pump and its accessories in the provided storage bag in a cool, dry place when not in use.
- Avoid exposing the pump to extreme temperatures or direct sunlight for prolonged periods.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

Troubleshooting

Problem	Possible Cause	Solution
Pump does not turn on	Low battery; Charging cable connected	Charge the pump fully; Unplug charging cable before use.
Slow inflation/deflation	Incorrect nozzle; Obstruction in port	Ensure correct nozzle is used and securely attached; Check ports for blockages.
Light not working	Low battery; Light button not pressed correctly	Charge the pump fully; Press and hold the light button.

Specifications

Brand	ETENWOLF
Model Name	AIR3
Material	Plastic
Item Weight	145 Grams

Product Dimensions	1.89" L x 1.89" W x 2.44" H
Power Source	Battery Powered
Air Flow Capacity	13 Cubic Feet Per Minute (360 L/min)
Maximum Pressure	4.5 Kilopascal (0.65 PSI)
Operation Mode	Automatic
Battery Capacity	2600 mAh Lithium Battery
Light Output	60 / 200 / 600 Lumens

Warranty and Support

The ETENWOLF AIR 3 Air Pump comes with a **1-year warranty**. For any questions, comments, or support needs, please contact ETENWOLF customer service. You can register your product for an extended warranty by visiting the official ETENWOLF website.

ETENWOLF is dedicated to designing reliable and innovative outdoor equipment. We are committed to providing excellent customer service and support.