Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GOJOOASIS GJ-GGL22A

GOJOOASIS Outdoor Large Dog Kennel Playpen Crate Instruction Manual

Model: GJ-GGL22A

Brand: GOJOOASIS

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your GOJOOASIS Outdoor Large Dog Kennel Playpen Crate, Model GJ-GGL22A. This product is designed to provide a secure and comfortable outdoor enclosure for your pets, offering protection from various weather conditions.

2. Important Safety Information

- Read all instructions carefully before assembly and use.
- Ensure all components are securely fastened before placing pets inside the enclosure.
- Always place the kennel on a flat, level, and stable ground surface to prevent tipping.
- Regularly inspect the kennel for any signs of wear, damage, or loose parts. Repair or replace damaged components immediately.
- Do not allow children to play unsupervised near or inside the kennel.
- Supervise pets, especially during initial use, to ensure they are comfortable and secure within the enclosure.
- In extreme weather conditions (e.g., strong winds, heavy snow), consider additional anchoring or temporary disassembly to prevent damage.

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.




Image description: An assembled GOJOOASIS Outdoor Large Dog Kennel Playpen Crate with a white pitched roof, showcasing the overall structure and components.

- Metal Frame Panels (various sizes for walls, door, and roof structure)
- Wire Mesh Panels
- Door Panel with Hinges
- Security Door Locks (2 units)
- 180g Waterproof Polyester Fabric Tarp (Top Cover)
- Elastic Cords for Tarp Attachment
- Wire Mesh Upgrade Fixings
- Assembly Hardware (e.g., spring buttons, bolts, nuts)
- Instruction Manual

4. Setup and Assembly Instructions

It is recommended to have two people for easier and safer assembly. Follow these steps in sequence for proper installation.

Step 4.1: Unpack and Identify Components

Carefully remove all parts from the packaging. Lay them out on a clean, flat surface and compare them against the 'Package Contents' list to ensure everything is present.

Step 4.2: Assemble the Metal Frame

Begin by connecting the main metal frame panels. The frame utilizes a spring button mechanism for secure connections. Insert the frame tubes into the connectors until the spring buttons snap into place. Ensure all connections are firm and

stable.



Image description: A detailed view of the kennel's robust construction, showing a spring button connection, elastic ball strap, two security door locks, and wire mesh upgrade fixing points.

Step 4.3: Install Wire Mesh Panels

Once the main frame is assembled, attach the wire mesh panels to the frame. The upgraded design features foldable meshing for simplified installation. Use the provided wire mesh upgrade fixings to secure the mesh panels firmly to the frame, ensuring there are no gaps where a pet could escape or get injured.

Step 4.4: Attach the Door

Integrate the door panel into the designated opening in the frame. Ensure the hinges are correctly aligned and secured. Test the door to confirm it swings freely and closes properly. Install the two security door locks to ensure the door can be securely fastened.

Step 4.5: Install the Top Cover

Drape the 180g waterproof polyester fabric tarp over the assembled frame. The cover is designed with a pitched roof to facilitate water, debris, and light snow runoff. Secure the cover to the frame using the durable elastic cords. Ensure the cover is pulled taut and all cords are fastened for a snug fit and optimal weather protection.



Image description: A golden retriever playing near the GOJOOASIS dog kennel, with an inset showing the 180g PE all-season tarp material, highlighting its UV resistant, waterproof, and anti-dropping properties.

Step 4.6: Final Placement

Position the fully assembled kennel on a flat, level ground surface. Uneven ground can compromise the stability and structural integrity of the enclosure. Ensure there are no sharp objects or hazards in the immediate vicinity.

5. Operating Your Pet Enclosure

5.1: Door Operation

The kennel is equipped with a lockable door for secure pet containment. To open the door, disengage both security door locks. To close, ensure the door is fully shut and engage both locks. Always double-check that the locks are properly

secured to prevent accidental escapes or unauthorized entry.

5.2: Top Cover Management

The removable top cover provides essential protection from environmental elements. Ensure it is always securely fastened with the elastic cords when in use. In anticipation of strong winds or heavy precipitation, verify the cover's attachment and consider additional measures if necessary to prevent damage or displacement.

6. Maintenance and Care

Regular maintenance will extend the lifespan of your GOJOOASIS pet enclosure and ensure continued safety for your pet.

6.1: Cleaning the Frame and Mesh

Periodically clean the galvanized metal frame and wire mesh. Use a mild soap solution and water, then rinse thoroughly with clean water. Allow all metal components to air dry completely to prevent rust. Avoid using abrasive cleaners or harsh chemicals, which can damage the rust-resistant coating.

6.2: Cleaning the Top Cover

The polyester fabric tarp can be cleaned with a damp cloth and mild soap. Do not use bleach or strong detergents. Ensure the cover is completely dry before folding and storing to prevent mildew and maintain its waterproof properties.

6.3: Inspections

Conduct routine inspections of the entire kennel. Check all frame connections, welds, and wire mesh fixings for tightness and integrity. Examine the door hinges and locks for smooth operation and security. Inspect the elastic cords for fraying or loss of elasticity. Replace any worn or damaged parts promptly.

7. Troubleshooting

Issue: Kennel feels unstable after assembly.
Solution: Ensure the kennel is placed on a completely flat and level ground surface. Verify that all frame connections are fully engaged with the spring buttons and that all wire mesh fixings are securely tightened.

Issue: Water accumulates on the top cover.
Solution: The pitched roof design is intended for water runoff. Ensure the cover is stretched taut and securely fastened with all elastic cords to maintain the proper pitch. Clear any leaves or debris that may be obstructing water flow.

Issue: Door is difficult to open or close.
Solution: Check for any obstructions in the door's path or hinges. Ensure the overall frame is square and level. Lubricate hinges with a suitable outdoor lubricant if necessary. Verify that the security locks are aligned correctly and not bent.

8. Product Specifications



Image description: A diagram illustrating the dimensions of the GOJOOASIS dog kennel (78.74"L x 78.74"W x 63"H) and a guide for measuring dog body length and shoulder height to determine suitability.

- **Model:** GJ-GGL22A
- **Brand:** GOJOOASIS
- **Overall Dimensions (L x W x H):** 78.74" x 78.74" x 63" (approximately 200 cm x 200 cm x 160 cm)
- **Frame Material:** Heavy-Duty Galvanized Metal
- **Top Cover Material:** 180g Waterproof & UV Protected Polyester Fabric
- **Color:** Silver Frame, White Tarp
- **Target Audience:** Dogs and most medium-sized pets
- **Key Features:** Removable Fading-Resistant Top Cover, Sturdy Welded Metal Frame, Lockable Door, Upgraded Foldable Wire Meshing

9. Warranty and Customer Support

This GOJOOASIS product is covered by a**1-year warranty** from the date of purchase, specifically for manufacturing defects. This warranty does not cover damage resulting from improper assembly, misuse, neglect, or normal wear and tear.

For warranty claims, technical assistance, replacement parts, or any other inquiries, please contact GOJOOASIS customer support. Refer to your purchase documentation or the official GOJOOASIS website for the most current contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CM6KYK8B

More documents and user manuals: **https://manuals.plus/**