

RL LIVE YOUR LIGHT R31573031

Reality Leuchten Bidar R31573031

3-BULB PENDANT LIGHT INSTRUCTION MANUAL

Brand: RL LIVE YOUR LIGHT | Model: R31573031

1. Product Overview

The BIDAR three-light pendant luminaire is designed to provide a unique well-being light in your home, serving as a luminous centerpiece. Light gently shines through its intricate patterns, creating a distinctive play of light in the surrounding environment. The natural wood accents enhance the warm and comfortable feel. This fixture combines matte white metal, natural wood accents, and a playful design, making it an exciting decorative element for any room.

For energy-efficient lighting, the use of LED light sources is recommended. These offer an optimal alternative to conventional halogen lamps, providing high light quality and energy savings of up to 80%. Additionally, LED bulbs have a long lifespan, low heat generation, and are environmentally friendly.

- Bidar 3-bulb pendant light in matte white metal with natural wood and white metal shades.
- Bulbs not included. Recommended: 3 E27 bulbs, maximum 28W each.
- Each shade has a diameter of 15 cm. The height of each shade is continuously adjustable up to a maximum of 150 cm.





Image 1.1: The Reality Leuchten Bidar R31573031 3-Bulb Pendant Light, showcasing its matte white metal shades with intricate patterns and natural wood accents.



Image 1.2: The Bidar pendant light installed in a modern living space, demonstrating its aesthetic appeal and light distribution.

2. Safety Instructions

Please read all instructions carefully before installation and use. Keep this manual for future reference.

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with all local and national electrical codes. Always disconnect power at the main circuit breaker before installation, maintenance, or bulb replacement.
- **Bulb Compatibility:** Use only E27 bulbs with a maximum wattage of 28W per bulb. Do not exceed the recommended wattage.
- **Handling:** Handle the light fixture with care. Avoid dropping or subjecting it to strong impacts.
- **Environment:** This fixture is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- **Cleaning:** Always turn off and allow the fixture to cool before cleaning. Use a soft, dry cloth. Do not use abrasive cleaners or solvents.

3. Package Contents

Verify that all components are present and undamaged before beginning installation.

- 1 x Reality Leuchten Bidar R31573031 3-Bulb Pendant Light Fixture
- 1 x Mounting Hardware Kit (screws, anchors, wire connectors)
- 1 x Instruction Manual

Note: Light bulbs are not included and must be purchased separately.

4. Setup and Installation

Follow these steps for proper installation. If you are unsure about any step, consult a qualified electrician.

1. Prepare for Installation:

- Turn off power at the main circuit breaker to the junction box where the fixture will be installed.
- Ensure the power is off by testing with a voltage tester.
- Unpack the fixture and all components.

2. Mount the Mounting Plate:

- Attach the mounting plate to the ceiling junction box using the provided screws. Ensure it is securely fastened.

3. Connect Wiring:

- Carefully connect the fixture's wires to the corresponding wires from the junction box using the wire connectors:
- Connect the live (black or brown) wire from the fixture to the live wire from the junction box.
- Connect the neutral (white or blue) wire from the fixture to the neutral wire from the junction box.
- Connect the ground (green or bare copper) wire from the fixture to the ground wire from the junction box.
- Ensure all connections are tight and secure.

4. Secure the Fixture:

- Carefully tuck the wires into the junction box.
- Align the fixture's canopy with the mounting plate and secure it with the provided screws or nuts.

5. Install Bulbs:


- Screw three E27 bulbs (max 28W each) into the sockets.

6. Adjust Shade Height:

- Adjust the length of each pendant cord to your desired height (up to 150 cm) by pushing the cord through the mechanism in the canopy.

7. Restore Power:

- Turn the power back on at the main circuit breaker.
- Test the light fixture.



R315730xx

Image 4.1: Technical drawing showing the dimensions and structure of the Bidar R31573031 pendant light, useful for installation planning.

5. Operating Instructions

The Reality Leuchten Bidar R31573031 pendant light is operated via a standard wall switch connected to its electrical circuit.

- **Turning On/Off:** Flip the wall switch to the 'ON' position to illuminate the fixture. Flip it to the 'OFF' position to turn off the light.
- **Bulb Type:** This fixture uses E27 base bulbs. For optimal performance and energy efficiency, LED bulbs are recommended.
- **Wattage:** Ensure that each bulb does not exceed 28 Watts.

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your light fixture.

- **Cleaning:** Before cleaning, ensure the power is off and the fixture has cooled down. Wipe the metal and wood surfaces with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:**
 - a. Turn off power to the fixture at the circuit breaker.
 - b. Allow the old bulb to cool completely before touching it.
 - c. Carefully unscrew the old E27 bulb.
 - d. Screw in a new E27 bulb, ensuring it does not exceed 28W.
 - e. Restore power and test the light.
- **Inspection:** Periodically check for any loose connections or damaged wiring. If any issues are found, consult a qualified electrician.

7. Troubleshooting

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker. Ensure wall switch is ON.
	Loose wiring connection.	Turn off power at breaker. Check and tighten all wire connections.
	Faulty bulb.	Replace bulb with a new, working E27 bulb (max 28W).
Light flickers.	Loose bulb or wiring.	Turn off power. Tighten bulb. Check wire connections.
	Incompatible dimmer switch.	Ensure dimmer switch is compatible with LED bulbs if using them.

If the problem persists after trying these solutions, please contact customer support or a qualified electrician.

8. Specifications

Attribute	Value
-----------	-------

Attribute	Value
Brand	RL LIVE YOUR LIGHT
Manufacturer	Reality Leuchten GmbH
Product Dimensions (L x W x H)	15 x 71 x 150 cm
Item Weight	2.23 Kilograms
Item Model Number	R31573031
Number of Items	1
Style	3-Bulb Pendant
Color	Matte White
Shape	Oval
Material	Metal
Finish Types	Matte
Number of Bulbs	3
Included Components	Mounting Instructions
Voltage	230 Volts (AC)
Special Features	Adjustable Height
Shade Color	White
Shade Material	Metal
Beam Angle	Incandescent
Plug Type	Electric Cable
Switch Style	Touch
Installation Type	Ceiling Mount
Batteries Required	No
Bulb Type	LED (Recommended)
Energy Label	Not Rated
Luminous Flux	1350 lumens
Wattage	28 Watts (Max per bulb)
Fixture Shape	Pendant
Room Type	Living Room
Indoor/Outdoor Use	Indoor
Power Source	Electric Cable

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller/manufacturer directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Reality Leuchten GmbH

For further assistance, please visit the official RL LIVE YOUR LIGHT website or contact their customer service department.