

## HENDI 860526

# HENDI Uniq 8L Soup Kettle Instruction Manual

Model: 860526

## 1. INTRODUCTION

Thank you for choosing the HENDI Uniq 8L Soup Kettle. This manual provides essential information for the safe and efficient operation, maintenance, and care of your appliance. Please read these instructions thoroughly before initial use and keep them for future reference. This appliance is designed for professional use in commercial kitchens and catering environments.

## 2. SAFETY INSTRUCTIONS

- Ensure the appliance is connected to a grounded power outlet with the correct voltage (220V) and frequency (50Hz).
- Do not immerse the appliance base, power cord, or plug in water or any other liquid.
- Always place the appliance on a stable, level, and heat-resistant surface, away from flammable materials and heat sources.
- Keep children and unauthorized personnel away from the appliance during operation.
- Exercise caution when handling hot liquids and surfaces. Use insulated gloves if necessary.
- Never operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way. Contact qualified service personnel for repairs.
- This appliance is designed for keeping food warm, not for cooking.
- Do not operate the appliance without water in the Bain-Marie tank.
- Always unplug the appliance before cleaning or maintenance.

## 3. PRODUCT OVERVIEW

The HENDI Uniq Soup Kettle features a modern design and robust construction for efficient food warming. Key components include:

- **Heat-resistant Polypropylene Casing:** Durable and safe exterior.
- **8-liter AISI 304 Stainless Steel Soup Container:** Removable for easy cleaning and hygiene.
- **AISI 304 Stainless Steel Heating Element:** Located in the water tank for efficient heat transfer.
- **Tempered Glass Lid:** Features an insulated handle, spoon notch, and aluminum hinge. Its two-part design minimizes heat loss.
- **Integrated Card Holder:** Allows for easy labeling of contents.
- **Digital Control Panel:** Displays operating time, set temperature, and actual temperature.
- **Water Tank with Max Fill Line:** For the Bain-Marie heating system.



*Figure 1: Front view of the HENDI Uniq Soup Kettle with its sleek black casing and HENDI logo.*



*Figure 2: Side view of the soup kettle, showing the digital control panel and the tempered glass lid in an open position, revealing the stainless steel inner container.*



Figure 3: A hand demonstrating the placement of the integrated card holder on the lid of the soup kettle, used for labeling contents.

## 4. SETUP

---

1. **Unpacking:** Carefully remove the soup kettle from its packaging. Retain the packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, clean all parts that will come into contact with food. Wash the stainless steel soup container and lid with warm soapy water, rinse thoroughly, and dry completely. Wipe the exterior casing with a damp cloth.
3. **Placement:** Place the appliance on a stable, level, and dry surface. Ensure there is adequate ventilation around the unit and that it is not near any heat sources or water.
4. **Fill Water Tank:** Remove the stainless steel soup container. Fill the outer water tank with approximately 1.5 liters of clean water, up to the maximum fill line. This water is for the Bain-Marie heating system. **Do not overfill.**
5. **Insert Soup Container:** Place the empty or filled stainless steel soup container back into the water tank.
6. **Connect Power:** Plug the power cord into a suitable grounded electrical outlet.

## 5. OPERATING INSTRUCTIONS

---

1. **Power On:** After connecting to power, the digital display will illuminate.
2. **Set Temperature:** Use the control panel to set the desired temperature. The temperature can be adjusted between +35°C and +85°C in 1°C increments. The last set temperature is saved and will be selected automatically upon reactivation.
3. **Monitor Display:** The digital display shows the operating time, the set temperature, and the actual temperature of the water in the Bain-Marie tank.

4. **Add Food:** Once the water reaches the desired temperature, add your pre-cooked soup or other food item to the stainless steel container.
5. **Lid Usage:** Place the tempered glass lid on the container. The two-part lid design helps maintain temperature and hygiene. Use the integrated card holder to label the contents for easy identification.
6. **Warming Function:** The Bain-Marie heating system gently warms and holds food at the set temperature, reducing the risk of overheating or burning. **Note: This appliance is for keeping food warm only; it is not suitable for cooking raw ingredients.**
7. **Power Off:** To turn off the appliance, unplug it from the power outlet.

## 6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance ensure the longevity and hygienic operation of your soup kettle.

1. **Disconnect Power:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Clean Soup Container and Lid:** Remove the stainless steel soup container and the tempered glass lid. Wash them with warm water and a mild detergent. Rinse thoroughly and dry completely before reassembling or storing.
3. **Clean Water Tank:** Drain any remaining water from the Bain-Marie tank. Wipe the interior of the tank with a damp cloth. For stubborn deposits, use a descaling solution suitable for stainless steel, following the product instructions. Rinse thoroughly.
4. **Clean Exterior:** Wipe the polypropylene casing with a damp cloth. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
5. **Storage:** Store the clean and dry appliance in a cool, dry place.

## 7. TROUBLESHOOTING

If you encounter issues with your HENDI Uniq Soup Kettle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	No power supply; damaged cord/plug.	Check power connection and outlet. Inspect cord/plug for damage. If damaged, contact service.
Food is not warming.	Insufficient water in Bain-Marie tank; incorrect temperature setting; heating element issue.	Ensure water tank is filled to the max line. Verify temperature setting. If problem persists, contact service.
Digital display not working correctly.	Electrical fault; sensor issue.	Unplug and replug the appliance. If the issue continues, contact service.
Water in tank boils rapidly.	Temperature set too high.	Reduce the set temperature. The Bain-Marie system is designed for gentle warming.

For issues not listed here or if troubleshooting steps do not resolve the problem, please contact HENDI customer support or a qualified service technician.

## 8. SPECIFICATIONS


Feature	Specification
Model Number	860526
Capacity	8 Liters
Power Supply	220V, 500W
Temperature Range	+35°C to +85°C (adjustable in 1°C increments)
Water Tank Capacity	Approx. 1.5 Liters (up to max fill line)
Dimensions (L x W x H)	40.5 x 36.5 x 32.5 cm
Weight	4.68 kg
Materials	Polypropylene casing, AISI 304 stainless steel container/heating element, tempered glass lid








## 9. WARRANTY AND SUPPORT

HENDI products are manufactured to high-quality standards. For information regarding warranty terms and conditions, or for technical support, please refer to the warranty card included with your product or visit the official HENDI website. Please have your model number (860526) and purchase details ready when contacting support.

© 2023 HENDI. All rights reserved.

### Related Documents - 860526

	<p><a href="#">HENDI Chafing Dish &amp; Soup Kettle User Manual</a></p> <p>This user manual provides essential safety instructions, operating guidelines, maintenance procedures, and troubleshooting tips for HENDI Chafing Dish UNIQ and Soup Kettle UNIQ appliances.</p>
---	---

 <p><b>UNIQ CHAFING DISH</b> UNIQ CHAFING DISH</p> <p><b>UNIQ SOUP KETTLE</b> UNIQ SOUP KETTLE</p> <p>204825 v.02, 204887, 204832, 204900 v.02_s.01</p>	<p><a href="#">HENDI UNIQ Chafing Dish &amp; Soup Kettle User Manual</a></p> <p>This user manual provides essential safety instructions, operating guidelines, cleaning and maintenance procedures, and troubleshooting tips for the HENDI UNIQ Chafing Dish and UNIQ Soup Kettle.</p>
 <p><b>CHAFING DISH ELECTRIC</b> CHAFING DISH ELECTRIC</p> <p>204825 v.02, 204887, 204832, 204900 v.02_s.01</p>	<p><a href="#">HENDI Chafing Dish Electric User Manual</a></p> <p>User manual for the HENDI Chafing Dish Electric (models 204825 v.02, 204887, 204832, 204900 v.02_s.01). Provides instructions on safe operation, maintenance, and technical specifications for commercial food warming applications.</p>
 <p><b>THERMOSYSTEM</b></p> 	<p><a href="#">Hendi Thermosystem User Manual and Safety Guide</a></p> <p>Comprehensive user manual for the Hendi Thermosystem, detailing safety precautions, technical specifications, operational instructions, maintenance, troubleshooting, and warranty information for professional kitchen use.</p>
 <p><b>THERMOSYSTEM</b></p> <p>201107 v.02, 201206 v.02, 201466</p>	<p><a href="#">HENDI THERMOSYSTEM User Manual   Models 201107, 201206, 201466</a></p> <p>Comprehensive user manual for HENDI THERMOSYSTEM commercial food warming appliances (models 201107 v.02, 201206 v.02, 201466). Covers safety, operation, cleaning, maintenance, troubleshooting, and warranty for professional kitchens.</p>
 <p><b>SOUP KETTLE</b></p> 	<p><a href="#">Hendi Soup Kettle User Manual - Models 860502, 860519</a></p> <p>Comprehensive user manual for the Hendi Soup Kettle (models 860502 and 860519), detailing operation, safety regulations, maintenance, and troubleshooting for professional food service use. Learn about energy-saving features and proper usage.</p>