

BoxWave QuickTrigger Auto

BoxWave QuickTrigger Auto Gaming Trigger

User Manual

INTRODUCTION

The BoxWave QuickTrigger Auto is a gaming accessory designed to enhance your mobile gaming experience, specifically for the Blackview Oscal C80. This device provides auto-trigger technology, offering a competitive edge in fast-paced mobile shooting games. It features a long-lasting battery, tactile feedback, and electronic firing pulses to improve focus and performance during gameplay. This manual provides instructions for setup, operation, and maintenance of your QuickTrigger Auto.

Please note: This product is for the left trigger only.



Image: The BoxWave QuickTrigger Auto gaming trigger shown alongside a Blackview Oscal C80 smartphone, illustrating the product's compatibility and intended use.

SETUP INSTRUCTIONS

Follow these steps to set up your QuickTrigger Auto for optimal gaming performance:

1. **Positioning the Trigger:** Gently slide the QuickTrigger Auto onto the top edge of your Blackview Oscal C80. Adjust its position to align with the desired in-game button on your screen. Ensure it is securely attached but not overly tight to avoid damage to your device.



Image: A visual representation of the QuickTrigger Auto, showing how it can be detached and attached to a mobile phone, highlighting its snap-on design.

2. **Power On:** Once positioned, press and hold the power button on the QuickTrigger Auto to turn it on. A small indicator light may illuminate to confirm it is active.
3. **In-Game Configuration:** Launch your desired mobile game (e.g., PUBG Mobile, Call of Duty Mobile, Fortnite Mobile). Navigate to the game's settings or interface customization menu. Locate and move the firing icon and aiming icon to the functional touch point on the screen where the QuickTrigger Auto will make contact. This ensures the trigger activates the correct in-game action.



Image: A user's hands holding a smartphone equipped with two gaming triggers (note: this product is for the left trigger only), demonstrating the ergonomic grip and in-game setup.

OPERATING INSTRUCTIONS

The QuickTrigger Auto is designed for competitive mobile gaming, offering advanced features for improved performance.

Gaming Advantage

The auto-trigger technology provides a significant advantage in mobile phone gaming. By optimizing button placement and enlarging the thumb button area, gamers can achieve greater focus and maintain an edge over opponents for longer periods. The tactile feel and electronic firing pulses contribute to a more responsive and immersive gaming experience.

Game Compatibility

This trigger is ideal for mobile shooting games such as PUBG Mobile, Call of Duty Mobile, and Fortnite Mobile. It offers 4 distinct settings, providing up to 64 clicks per second. This versatility allows users to effectively use non-automatic weapons as if they were automatic, enhancing their in-game capabilities.

Electronic Features

The QuickTrigger Auto incorporates pulse-touch technology. Simply hold down the left button for continuous tapping, eliminating trigger finger burnout during extended gaming sessions. The device is designed for effortless charging and connection, ensuring you can focus on your game without interruption.



Image: A close-up view of the QuickTrigger Auto attached to a smartphone, actively engaged in a mobile game, demonstrating its precise interaction with the touchscreen.

MAINTENANCE

To ensure the longevity and optimal performance of your BoxWave QuickTrigger Auto, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the trigger. Avoid using abrasive cleaners or solvents, as these can damage the material and electronic components.
- **Storage:** When not in use, store the QuickTrigger Auto in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Charge the device using the provided cable or a compatible charger. Avoid overcharging, which can reduce battery life over time.
- **Handling:** Handle the trigger with care. Avoid dropping it or subjecting it to strong impacts, as this can damage internal components.

TROUBLESHOOTING

If you encounter any issues with your QuickTrigger Auto, please refer to the following common solutions:

Problem	Possible Cause	Solution
Trigger not responding in game.	Incorrect in-game button placement; low battery; trigger not powered on.	Ensure the in-game firing/aiming icon is directly under the trigger's contact point. Charge the device. Press and hold the power button to turn it on.
Trigger not holding charge.	Faulty charging cable; battery degradation.	Try a different charging cable. If the issue persists, contact customer support.

Problem	Possible Cause	Solution
Trigger feels loose on phone.	Improper attachment.	Re-attach the trigger, ensuring it snaps securely onto the phone's edge.

SPECIFICATIONS

- Model:** QuickTrigger Auto
- Brand:** BoxWave
- Color:** Jet Black
- Material:** Polycarbonate
- Item Weight:** 10 ounces
- Country of Origin:** China
- Compatibility:** Blackview Oscal C80 (Left Trigger Only)



Image: A side profile of a smartphone with the QuickTrigger Auto attached, illustrating its slim design and how it integrates with the phone's form factor, including a measurement of 18mm thickness.

WARRANTY AND SUPPORT

Your purchase of the BoxWave QuickTrigger Auto includes limited third-party technical support for the Blackview Oscal C80. This support is available for up to 3 inquiries via electronic messaging. Please note that BoxWave is not affiliated with or endorsed by Blackview.

For technical assistance or further inquiries, please refer to the contact information provided with your product packaging or visit the official BoxWave website.

