Bellemave bed-frames

Bellemave Twin Size Loft Bed with Desk & 4-Storage Shelves Instruction Manual

1. Introduction

This manual provides instructions for the Bellemave Twin Size Loft Bed, designed with an integrated desk and four storage shelves. It offers a comfortable sleeping area and a functional workstation, suitable for various room configurations. Please read all instructions carefully before assembly and use to ensure safe operation and longevity of your product.



Image 1.1: Overview of the Bellemave Twin Size Loft Bed with integrated desk and storage shelves in Espresso finish.

2. Safety Information

Adherence to these safety guidelines is crucial for preventing injuries and ensuring the safe use of the loft bed.

- **Important:** Always ensure all connections are tight before initial use and periodically thereafter.
- Do not allow children under 6 years of age on the upper bunk.
- Use only mattresses that meet the recommended thickness of 6 inches.
- Ensure guardrails are properly installed and maintained at all times.
- Do not attach or hang items on any part of the loft bed that are not designed for use with the bed (e.g., hooks, belts, jump ropes).
- Periodically check and ensure that the guardrail, ladder (integrated shelves), and other components are in their proper position, free from damage, and that all connectors are tight.
- The bed is designed to support a maximum weight of 250 lbs. Do not exceed this weight limit.
- Proposition 65 Warning: This product can expose you to chemicals including wood dust, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.

3. Setup (Assembly Instructions)

The Bellemave Twin Size Loft Bed requires assembly. It is recommended that two adults assemble this product to ensure safety and efficiency.

Before You Begin:

- Unpack all components and verify against the parts list provided in your separate assembly guide. Do not discard packaging until assembly is complete and all parts are accounted for.
- Ensure you have all necessary tools, which are typically included with the product.
- Follow the step-by-step instructions provided in the separate assembly guide carefully.
- Do not overtighten screws during initial assembly; tighten fully once all parts are aligned and the structure is stable.

Note: Your product ships in 2 separate packages, which may arrive at different times. Please ensure both packages have arrived before beginning assembly.

4. Operating (Usage)

The Bellemave Twin Size Loft Bed is designed for multi-functional use in compact spaces.

- **Sleeping Area:** The elevated bed provides a comfortable sleeping surface. Ensure the mattress fits snugly within the bed frame (inner dimension: 39.2" x 76").
- **Integrated Desk:** The spacious desk located beneath the bed offers a dedicated area for study, work, or creative activities.
- **Storage Shelves/Ladder:** The four integrated shelves serve a dual purpose: providing convenient storage for books, decor, or personal items, and functioning as a sturdy ladder for safe access to the upper bunk.

5. Maintenance

Proper care and maintenance will help preserve the appearance and structural integrity of your loft bed.

- **Cleaning:** Wipe surfaces with a clean, dry, or slightly damp cloth. Avoid harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the wood finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections to ensure they remain tight. Retighten as necessary to maintain structural stability and safety.
- **Wood Care:** Protect wood surfaces from direct sunlight and extreme temperature changes to prevent warping, cracking, or fading. Use coasters or protective pads under items placed on the desk surface.

6. Troubleshooting

Refer to these common issues and solutions if you encounter problems with your loft bed.

- **Loose Connections:** If the bed feels wobbly or unstable, carefully check all bolts and screws. Tighten them securely using the appropriate tools.
- **Squeaking Noises:** Squeaking can often be resolved by tightening all hardware. If persistent, disassemble and reassemble the affected section, ensuring all parts are correctly aligned and tightened.
- **Missing Parts:** If you discover any parts are missing during assembly, please refer to the contact information in the Warranty & Support section for assistance. Do not attempt to substitute parts.

7. Specifications

Detailed specifications for the Bellemave Twin Size Loft Bed.

- **Product Type:** Loft Bed Frame
- **Size:** Twin
- **Material:** Pine Wood + MDF
- **Overall Product Dimensions:** 79.7"L x 42"W x 68.3"H
- **Bed Inner Dimension:** 39.2" x 76"
- **Total Height:** 68.3"
- **Overall Product Weight:** 137.5 lb
- **Weight Capacity (Upper Bed):** 250 lb
- **Number of Slats:** 14 pcs
- **Recommended Mattress Thickness:** 6"
- **Special Features:** Integrated Desk, 4 Storage Shelves, Safety Guard Rail
- **Color:** Espresso



Image 7.1: Detailed dimensions of the Bellemave Twin Size Loft Bed.

8. Warranty & Support

For assistance with your Bellemave Twin Size Loft Bed, please refer to the following information.

- **Warranty:** This product comes with a 12-month warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for all warranty claims.
- **Customer Support:** For any questions, concerns, or assistance with assembly, missing parts, or product issues, please contact Bellemave customer service. Refer to your purchase documentation or the Bellemave official website for specific contact details.