



[Manuals.plus](#) /

> [Bellemave](#) /

> Bellemave Twin Size Loft Bed with Desk & 4-Storage Shelves Instruction Manual AGUO-GX245K

Bellemave AGUO-GX245K

Bellemave Twin Size Loft Bed with Desk & 4-Storage Shelves

INSTRUCTION MANUAL

INTRODUCTION

Thank you for purchasing the Bellemave Twin Size Loft Bed with Desk and 4-Storage Shelves. This manual provides important information regarding the safe assembly, operation, and maintenance of your new loft bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This loft bed is designed to provide a comfortable sleeping area, a functional desk, and convenient storage shelves, optimizing space in your room. Ensure all components are present and undamaged before proceeding.

SAFETY INFORMATION

Your safety is paramount. Please adhere to the following safety guidelines:

- **Weight Capacity:** The upper bed has a maximum weight capacity of 250 lbs. Do not exceed this limit.
- **Mattress Thickness:** Use a mattress with a maximum thickness of 6 inches for the upper bed to ensure proper guardrail height.
- **Guardrails:** Always ensure guardrails are securely in place. Do not remove or modify them.
- **Assembly:** Assemble the bed strictly according to the instructions. Do not use power tools for assembly unless explicitly stated, as this may overtighten fasteners and damage the wood.
- **Supervision:** Children should be supervised when using the loft bed, especially during initial use.
- **Falling Hazard:** Do not allow children to play under the loft bed without supervision or to hang from any part of the bed structure.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Regular Checks:** Periodically check all bolts and fasteners to ensure they are tight. Retighten as necessary.
- **No Jumping:** Do not jump on the bed.

PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact

customer support.

- Bed Frame Components (Headboard, Footboard, Side Rails, Slats)
- Desk Components
- Shelf Components
- Guardrails
- Assembly Hardware (Bolts, Screws, Washers, Allen Wrench)
- Instruction Manual

Note: Specific quantities of each component will be detailed in the included assembly guide.

SETUP AND ASSEMBLY

Assembly requires two adults. Clear a spacious area for assembly. Follow the numbered steps provided in the separate assembly guide included with your product. The following images illustrate key structural components.



Image: The loft bed frame, showcasing the sturdy wooden slats that support the mattress and the integrated desk area beneath the bed. This view helps in understanding the main structural components during assembly.



Image: An angled view of the loft bed frame, highlighting the integrated ladder which also functions as storage shelves. This image demonstrates how the shelving unit connects to the main bed structure.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Identify Hardware:** Match all hardware to the parts list in your assembly guide.
3. **Assemble Main Frame:** Begin by connecting the main bed frame components (headboard, footboard, side rails) using the provided bolts and an Allen wrench. Do not fully tighten bolts until the entire frame is assembled.
4. **Install Slats:** Secure the wooden slats to the side rails. Ensure they are evenly spaced and firmly attached.
5. **Attach Desk and Shelves:** Assemble and attach the desk and storage shelf units to the main frame as indicated in the assembly guide.
6. **Install Guardrails:** Securely attach the full-length guardrails to the upper bed frame.
7. **Final Tightening:** Once all components are in place, carefully tighten all bolts and screws. Do not overtighten.
8. **Placement:** Position the assembled loft bed against a wall for added stability.

The Bellemave Loft Bed is designed for practical use in a compact space.

- **Sleeping Area:** Place a twin-size mattress (maximum 6 inches thick) on the upper bed slats. Ensure the mattress fits snugly within the frame.
- **Desk Usage:** The integrated desk provides a dedicated workspace for studying, reading, or using a computer. Keep the desk clear of excessive weight.
- **Storage Shelves:** Utilize the four integrated shelves for books, decorative items, or other personal belongings. Distribute weight evenly across the shelves.
- **Access:** Use the integrated ladder/shelves for safe access to the upper bunk. Always face the ladder when climbing up or down.



Image: The Bellemave loft bed in a furnished room, demonstrating the functional desk space and the utility of the storage shelves. A chair is placed at the desk, and items are on the shelves, illustrating typical use.

MAINTENANCE

Proper maintenance will extend the life and appearance of your loft bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Hardware Check:** Every 3-6 months, inspect all bolts, screws, and fasteners. Tighten any that have become loose.
- **Avoid Moisture:** Protect the wood from excessive moisture and direct sunlight to prevent warping or fading.

TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware. Uneven floor.	Check and tighten all bolts and screws. Ensure the bed is on a level surface.
Squeaking noises.	Loose connections. Friction between parts.	Tighten all hardware. Apply a small amount of wax or silicone spray to contact points if necessary.
Parts do not align during assembly.	Incorrect orientation of parts. Bolts overtightened prematurely.	Review the assembly guide for correct part orientation. Loosen all bolts, align parts, then retighten gradually.

If the issue persists, please contact customer support for further assistance.

SPECIFICATIONS

Detailed dimensions and material information for the Bellemave Twin Size Loft Bed:

Feature	Detail
Product Type	Loft Bed Frame
Size	Twin
Material	Pine Wood + MDF
Overall Product Dimension	79.7"L x 42"W x 68.3"H
Bed Inner Dimension	39.2" x 76"
Total Height	68.3"
Weight Capacity (Upper Bed)	250 lbs
Number of Slats	14 pcs
Recommended Mattress Thickness	6"
Assembly Required	Yes



Image: A technical diagram illustrating the precise dimensions of the Bellemave Twin Size Loft Bed, including length, width, height, and specific measurements for the desk and shelves.

WARRANTY AND SUPPORT

This product comes with a limited warranty. For details regarding warranty coverage, please refer to the warranty information provided with your purchase documentation or contact Bellemave customer service.

For any questions, missing parts, or assistance with assembly, please contact Bellemave customer support. Have your model number (AGUO-GX245K) and purchase date ready when contacting support.

Contact Information: Please refer to your purchase receipt or the Bellemave official website for the most current customer service contact details.

