**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## VECELO YT-Q28-WHE

# VECELO Queen Size White Metal Platform Bed Frame with Headboard

INSTRUCTION MANUAL

## 1. Introduction

This manual provides detailed instructions for the assembly, usage, and maintenance of your VECELO Queen Size White Metal Platform Bed Frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

### Package Contents:

- 1 x Bed Frame (Disassembled Components)
- 1 x Instruction Manual
- 1 x Assembly Kit (Hardware and Tools)

## 2. Safety Information

- Ensure all parts are present before assembly.
- Do not fully tighten screws until all components are correctly aligned and assembled.
- Place the bed frame on a flat, stable surface during assembly.
- Regularly inspect all screws and bolts to ensure they remain tightened.
- This bed frame is designed for use with a mattress; a box spring is not required. Mattress is not included.
- Maximum weight capacity for the Queen size is 660 lbs. Do not exceed this limit.

## 3. Parts List

Before assembly, identify all components. Refer to the diagram below for visual identification and dimensions.





**Figure 3.1:** Dimensions of the VECELO Queen Size Metal Platform Bed Frame. The frame measures 80 inches in length, 60 inches in width, and 35 inches in height at the headboard. Under-bed clearance is 12.6 inches.

Typical components include:

- Headboard Section
- Footboard Section
- Side Rails (Left and Right)
- Center Support Beam
- Support Legs (Various sizes)
- Metal Slats
- Hardware Kit (Bolts, Washers, Nuts, Allen Wrench)

## 4. Assembly Instructions (Setup)

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

1. **Unpack and Organize:** Lay out all parts on a clean, soft surface to prevent scratches. Verify all components against the parts list.
2. **Attach Headboard Legs:** Secure the support legs to the headboard section using the provided hardware. Do not fully tighten.
3. **Attach Footboard Legs:** Secure the support legs to the footboard section using the provided hardware. Do not fully tighten.
4. **Connect Side Rails:** Attach the side rails to the headboard and footboard sections. Ensure the connections are secure but do not fully tighten bolts yet.
5. **Install Center Support:** Place the center support beam between the headboard and footboard, connecting it to the designated points on the side rails. Attach any additional center support legs.
6. **Place Slats:** Distribute the metal slats evenly across the frame. Secure them to the side rails and center support beam

as indicated in the diagram.

7. **Final Tightening:** Once all parts are assembled and aligned, systematically tighten all bolts and screws using the provided Allen wrench. Ensure the bed frame is stable and level.



**Figure 4.1:** The VECELO bed frame structure, illustrating the robust metal slat support system designed to eliminate the need for a box spring.



**Figure 4.2:** Detail of a leg attachment point, demonstrating the secure bolted connection for stability.

## 5. Usage

After assembly, place your mattress directly onto the metal slats. This platform bed frame is designed to support your mattress without the need for a box spring. The 12.6-inch under-bed clearance provides convenient storage space for various items.



**Figure 5.1:** Example of utilizing the under-bed clearance for storage, showcasing the practical design of the VECELO bed frame.

## 6. Maintenance

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all bolts and connections to ensure they are tight. Re-tighten if necessary to maintain stability and prevent noise.
- **Movement:** When moving the bed frame, lift it rather than dragging it to prevent damage to the legs or floor.

## 7. Troubleshooting

- **Squeaking Noise:** If the bed frame produces noise, ensure all bolts are fully tightened. Loose connections are the most common cause of squeaking.
- **Instability:** If the frame feels unstable, check that all legs are in firm contact with the ground and that all connections

are secure. Ensure the frame is on a level surface.

- **Missing Parts:** If any parts are missing or damaged upon arrival, contact customer support immediately for assistance.

## 8. Specifications

| Feature | Detail |
|---|---|
| Model Number | YT-Q28-WHE |
| Size | Queen |
| Product Dimensions (L x W x H) | 80" x 60" x 35" |
| Color | White |
| Material | Steel |
| Under Bed Clearance | 12.6 Inches |
| Max Load Capacity (Queen) | 660 lbs |
| Assembly Required | Yes |

## 9. Warranty and Customer Support

VECELO products are manufactured with quality and care. For any questions regarding assembly, missing parts, or product performance, please contact VECELO customer support. Keep your purchase receipt for warranty claims.

For further assistance, please visit the VECELO store or contact our customer service department.

© 2023 VECELO. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0CM8YSD4C**

More documents and user manuals: **https://manuals.plus/**