

XINLEI ML1350

XINLEI ML1350 Mobile TV Stand Instruction Manual

For 13-50 Inch Flat/Curved TVs

1. PRODUCT OVERVIEW

The XINLEI ML1350 is a versatile mobile TV stand designed to accommodate most flat or curved televisions ranging from 13 to 50 inches. It features a robust alloy steel construction, offering stability and durability. This stand provides flexible viewing options with adjustable height and tilt functionality, making it suitable for various environments such as homes, offices, gyms, and exhibition halls. Its mobile design with lockable casters allows for easy repositioning, while the space-saving base ensures efficient use of floor area.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum load capacity of 20 kg (44 lbs). Overloading can cause instability and potential injury.
- **TV Size:** Ensure your TV's screen size is within the recommended range of 13-50 inches.
- **VESA Compatibility:** Verify your TV's VESA mounting pattern matches the stand's supported patterns (75x75mm to 200x200mm).
- **Assembly:** Follow all assembly instructions carefully. Incorrect assembly can lead to product failure.
- **Stability:** Always ensure the stand is on a stable, level surface. Lock the casters when the stand is in a stationary position to prevent accidental movement.
- **Children and Pets:** Keep children and pets away from the TV stand during assembly and ensure the TV is securely mounted to prevent tipping.
- **Moving the Stand:** When moving the stand, do so slowly and carefully, especially on uneven surfaces. Ensure the TV is securely attached and casters are unlocked before moving.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

- Base with Casters

- Main Support Pole
- TV Mounting Bracket (VESA plate)
- Mounting Arms (if applicable)
- Hardware Kit (screws, washers, spacers, Allen wrench, etc.)
- Instruction Manual

4. SETUP INSTRUCTIONS

Follow these steps to assemble your XINLEI ML1350 Mobile TV Stand.

1. **Attach Casters to Base:** Securely attach the casters to the base frame. Ensure two of the casters are lockable and positioned correctly for easy access.
2. **Assemble Base and Pole:** Connect the main support pole to the assembled base using the provided screws and tools. Ensure all connections are tight and stable.
3. **Attach TV Mounting Bracket:** Secure the VESA mounting bracket to the top of the main support pole.
4. **Prepare TV for Mounting:** Attach the VESA mounting arms (if separate) to the back of your television using the appropriate screws and spacers from the hardware kit. Ensure the screws are not overtightened and are compatible with your TV's VESA holes.
5. **Mount TV to Stand:** Carefully lift your television and hook the mounting arms onto the VESA mounting bracket on the stand. Secure the TV in place using the safety screws or locking mechanisms provided.

COMPATIBLE



Figure 4.1: Compatibility details for screen size and VESA patterns.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Height

The XINLEI ML1350 features unlimited point adjustable height, with a maximum height of 53 inches. To adjust the height, loosen the locking mechanism on the main support pole, carefully raise or lower the TV to your desired viewing level, and then securely tighten the locking mechanism. Ensure the TV is balanced during adjustment.



FLEXIBLE HEIGHT ADJUSTMENT



OURS
Unlimited Point Gears



OTHERS
Limited Gears

Figure 5.1: Flexible height adjustment mechanism.

5.2 Adjusting Tilt Angle

This TV stand allows you to tilt your television up to 30 degrees upwards and 10 degrees downwards. To adjust the tilt, loosen the tilt adjustment knobs or levers located on the TV mounting bracket. Carefully adjust the screen to your preferred angle to reduce glare and optimize viewing, then tighten the knobs/levers to secure the position.

OPTIMAL VIEWING ANGLES



Figure 5.2: Optimal viewing angles with tilt adjustment.

5.3 Moving the Stand

To move the TV stand, ensure the casters are unlocked. Gently push or pull the stand to its new location. Once in position, engage the locks on the casters to prevent unintended movement and ensure stability.

LOCKABLE CASTERS



Figure 5.3: Mobile design with lockable casters.

5.4 Space-Saving Design

The stand features a unique base design with a longer front and shorter rear, allowing it to be positioned closer to walls or behind furniture, optimizing space utilization.

SPACE-SAVING



Figure 5.4: Space-saving base design.

6. MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- **Periodic Checks:** Regularly inspect all screws and connections to ensure they remain tight. Retighten if necessary.
- **Caster Care:** Keep the casters free of debris to ensure smooth movement.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stand is unstable/wobbly	Loose connections; uneven surface; overloaded	Check and tighten all screws. Move to a level surface. Ensure TV weight is within limits.

Problem	Possible Cause	Solution
TV does not fit the bracket	Incorrect VESA pattern; TV too large/heavy	Verify your TV's VESA pattern and weight against specifications. Contact support if incompatible.
Casters not rolling smoothly	Debris in casters; casters locked	Clean any debris from the caster wheels. Ensure casters are unlocked for movement.
Difficulty adjusting height/tilt	Locking mechanisms are too tight or loose	Loosen locking mechanisms before adjusting, then tighten securely. Do not force adjustments.

8. SPECIFICATIONS




Figure 8.1: Product dimensions and specifications.

Feature	Detail
---------	--------

Feature	Detail
Model	ML1350
Compatible TV Sizes	13 - 50 inches
Maximum Load Capacity	20 kg (44 lbs)
VESA Compatibility	75x75mm, 100x100mm, 100x200mm, 200x100mm, 200x200mm
Tilt Angle	Up 30°, Down 10°
Maximum Height	53 inches (approx. 134.6 cm)
Material	Alloy Steel
Color	Black
Mounting Type	Freestanding
Movement Type	Adjustable, Mobile
Package Dimensions	44.6 x 20.6 x 13.7 cm
Item Weight	6.04 kg

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact XINLEI customer service through their official website or the retailer where the product was purchased. Please have your model number (ML1350) and purchase date available when contacting support.

© 2023 XINLEI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question