

RG51A(2)-E

Replacement Remote Control User Manual

Model: RG51A(2)-E, RG51A/E, RG51B(2)/E

PRODUCT OVERVIEW

This manual provides instructions for the use and care of your replacement remote control for Midea Air Conditioners. This remote is designed as a compatible replacement and may not offer all functions of your original remote.



Figure 1: Front view of the replacement remote control, showing the display screen and various function buttons such as AUTO, COOL, DRY, HEAT, TEMP, MODE, ON/OFF, FAN SPEED, SWING, SLEEP, TIMER ON, DIRECT, TIMER OFF, ECO, CLEAN, LED DISPLAY, and TURBO.

The remote control is made of durable ABS plastic. Please note that the color of the remote (black or white) will be sent randomly.

MODELS COVERED

This manual applies to the following replacement remote control models:

- RG51A(2)-E
- RG51A/E
- RG51B(2)-E

RG51A/E

RG51A(2)/E

RG51B(2)/E



Figure 2: Comparison of three compatible remote control models: RG51A/E, RG51A(2)/E, and RG51B(2)/E, highlighting their similar layouts and functions.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open.
3. Insert two AAA batteries (not included) according to the polarity indicators (+ and -) inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Note: Ensure batteries are inserted correctly to prevent damage to the remote control.

OPERATING INSTRUCTIONS

This replacement remote control is pre-programmed and generally requires no setup for compatible Midea Air Conditioners. Simply point the remote at the air conditioner unit and press the desired function button.

Key Functions

Button	Function
ON/OFF	Powers the air conditioner unit on or off.
MODE	Cycles through operating modes: Auto, Cool, Dry, Heat, Fan.
TEMP ▲/▼	Adjusts the temperature setting.

Button	Function
FAN SPEED	Adjusts fan speed: Auto, Low, Med, High.
SWING	Controls the louver swing function.
SLEEP	Activates or deactivates sleep mode for quiet operation and energy saving.
TIMER ON/OFF	Sets the timer for the unit to turn on or off automatically.
ECO	Activates energy-saving mode.
TURBO	Activates rapid cooling or heating.

Important: As this is a replacement remote, some advanced functions present on your original remote may not be supported or may operate differently. If you have your original remote's part number or your unit's model, providing this information can help ensure better compatibility.

MAINTENANCE

Cleaning the Remote

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's range decreases or the air conditioner unit no longer responds consistently. Always replace both batteries at the same time with new ones of the same type.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Remote not responding	<ul style="list-style-type: none"> ◦ Batteries are dead or inserted incorrectly. Replace batteries, ensuring correct polarity. ◦ Obstruction between remote and AC unit. Ensure a clear line of sight. ◦ Remote is too far from the AC unit. Move closer.
Some functions not working	<ul style="list-style-type: none"> ◦ This is a replacement remote; some specific functions of your original unit may not be supported. ◦ Ensure the remote model (e.g., RG51A(2)-E) is compatible with your specific Midea AC unit.
Display is dim or blank	Batteries are low. Replace with new batteries.

SPECIFICATIONS

- **Model Compatibility:** RG51A(2)/E, RG51A/E, RG51B(2)/E (for Midea Air Conditioners)
- **Material:** ABS Plastic
- **Power Source:** 2 x AAA Batteries (not included)
- **Color:** Black or White (randomly sent)
- **Special Feature:** Ergonomic design

Note: Specifications are subject to change without notice.

WARRANTY AND SUPPORT

Warranty Information

As a replacement product, specific warranty details may vary. Please refer to the seller's return policy or contact the seller directly for warranty information.

Customer Support

If you encounter any issues or have questions regarding the compatibility or operation of your replacement remote control, please contact the seller through the platform where you purchased the item. Providing your original remote's part number or your air conditioner unit's model number can assist in resolving compatibility inquiries.

© 2023 Generic. All rights reserved.

This manual is for informational purposes only. The manufacturer and seller are not responsible for any damages or injuries resulting from improper use of this product.