Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 839-848V80BG

HOMCOM Recliner Chair User Manual

Model: 839-848V80BG | Brand: HOMCOM

1. Introduction

Thank you for choosing the HOMCOM Recliner Chair, model 839-848V80BG. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read these instructions carefully before use and retain them for future reference.



Image 1.1: The HOMCOM Recliner Chair (Model 839-848V80BG) in a living room setting.

2. Safety Instructions

- **Weight Limit:** Do not exceed the maximum recommended load of 150 kg (330 lbs).
- **Assembly:** Ensure all parts are correctly assembled and tightened before use. Periodically check all fasteners to ensure they remain secure.
- **Children and Pets:** Keep children and pets away from the chair during assembly. Do not allow children to play on or around the recliner.
- **Moving Parts:** Be aware of moving parts during reclining and footrest operation to avoid pinching or injury.
- **Placement:** Place the chair on a level, stable surface. Ensure adequate space around the chair for reclining and swiveling.
- **Cleaning:** Follow maintenance instructions for cleaning to avoid damage to materials.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Recliner Base
- Seat Section
- Backrest Section
- Armrests (Left and Right)
- Footrest Mechanism
- Assembly Hardware (screws, washers, tools)
- Instruction Manual

4. Setup and Assembly

Assembly is required for this recliner. An illustrated instruction manual is included to guide you through the process. Please follow the steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Attach Base:** Secure the seat section to the recliner base using the provided hardware. Ensure the swivel mechanism is correctly aligned.
3. **Connect Backrest:** Attach the backrest to the seat section. Pay close attention to the alignment of screw holes and ensure all connections are firm. *Note: Some users have reported that aligning screw holes for the backrest and armrests may require careful adjustment or temporary manipulation of the synthetic leather covering. Ensure screws are fully engaged and tightened without forcing.*
4. **Install Armrests:** Secure the armrests to the main chair frame. Ensure the reclining lever and footrest cable (if applicable) are not obstructed.
5. **Final Check:** Once assembled, gently test the chair's stability and functions before full use.



Image 4.1: Dimensions of the recliner, useful for planning placement and assembly.

5. Operating Instructions

5.1 Reclining Function

The chair features a manual reclining mechanism, allowing you to adjust the backrest to your preferred angle, up to 130 degrees.

1. **To Recline:** Locate the lever on the side of the chair (typically on the right). Pull the lever to release the backrest lock. Lean back gently to achieve your desired reclining angle.
2. **To Return Upright:** Lean forward while pushing the lever back into its original position. The backrest will return to the upright position.



Image 5.1: The recliner in its maximum reclined position with the footrest extended.

5.2 Footrest Operation

The integrated footrest provides leg support and extends in conjunction with the reclining function.

1. **To Extend Footrest:** While seated, pull the side lever (same as for reclining). The footrest will automatically extend as you recline.
2. **To Retract Footrest:** Push down on the footrest with your legs until it locks back into the closed position. Ensure the lever is also returned to its upright position.



Image 5.2: Detail of the manual reclining lever.



Image 5.3: Detail of the tension adjustment knob, which may affect recline and footrest ease of movement.

5.3 Swivel Function

The chair is designed to swivel 360 degrees, allowing for easy movement and conversation in any direction.

- **To Swivel:** Simply rotate the chair in the desired direction while seated. Ensure the area around the chair is clear to prevent obstruction.
- *Note: One user reported that the swivel function might be limited by the footrest control cable if not properly routed during assembly. Ensure the cable is not taut or caught.*



Image 5.4: The chair's 360-degree swivel feature.



Image 5.5: Key features of the recliner: manual recline, 360° swivel, faux leather, and extendable footrest.

6. Maintenance

6.1 Cleaning

- **Material:** The chair is made with synthetic PU leather. For general cleaning, wipe with a soft, damp cloth.
- **Stains:** For stubborn stains, dry cleaning is recommended. Avoid harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the material.
- **Frame:** Wipe the metal base and frame with a dry or slightly damp cloth.

6.2 General Care

- Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- Avoid exposing the chair to direct sunlight for prolonged periods to prevent fading and material degradation.
- Keep sharp objects away from the synthetic leather to prevent punctures or tears.

7. Troubleshooting

Problem	Possible Cause	Solution
Difficulty during assembly (e.g., screw holes not aligning)	Misalignment of parts, synthetic leather obstructing holes.	Carefully adjust parts. Gently manipulate the synthetic leather to expose screw holes. Do not force screws; ensure proper alignment before tightening. Refer to the illustrated manual.
Footrest does not extend or retract smoothly/fully	Mechanism obstruction, cable issue, or tension setting.	Check for any obstructions under the footrest. Ensure the reclining lever is fully engaged. Adjust the tension knob (if present) for smoother operation. If the issue persists, inspect the footrest cable for proper routing and connection.
Chair does not swivel 360 degrees freely	Obstruction, or footrest control cable interfering with rotation.	Ensure no objects are blocking the base. During assembly, verify that the footrest control cable is routed correctly and does not become taut or caught when swiveling.
Chair feels unstable or wobbly	Loose fasteners.	Check and re-tighten all assembly screws and bolts. Ensure the chair is on a level surface.

8. Specifications

Feature	Detail
Brand	HOMCOM
Model Number	839-848V80BG
Color	Beige

Feature	Detail
Material	Synthetic PU Leather, Steel Frame
Product Dimensions (Upright)	78L x 80W x 109H cm (30.7L x 31.5W x 42.9H inches)
Product Dimensions (Reclined)	78L x 134W x 100H cm (30.7L x 52.8W x 39.4H inches)
Seat Dimensions	53W x 48D cm (20.9W x 18.9D inches)
Seat Height	45 cm (17.7 inches)
Max Recline Angle	130°
Weight Capacity	150 kg (330 lbs)
Item Weight	18.5 kg (40.8 lbs)
Special Features	Adjustable Backrest, Padded Armrests, Ergonomic Design, Reclining, Footrest, 360° Swivel
Care Instructions	Dry cleaning recommended for stains. Wipe with damp cloth for general cleaning.

9. Warranty and Support

Information regarding specific warranty terms for the HOMCOM Recliner Chair (Model 839-848V80BG) is not provided in this document. For warranty details, spare parts availability, or customer support, please refer to the original purchase documentation or contact HOMCOM directly through their official website or the retailer where the product was purchased.

Manufacturer: HOMCOM

Website: Visit HOMCOM Website

© 2026 HOMCOM. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CM9HKJRN

More documents and user manuals: **https://manuals.plus/**