

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [roiesvry](#) /
- › [roiesvry XS16 3.0 inch Mini Smartphone User Manual](#)

roiesvry XS16

roiesvry XS16 3.0 inch Mini Smartphone User Manual

Model: XS16

1. INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your roiesvry XS16 3.0 inch Mini Smartphone. Please read this manual thoroughly before using your device to ensure proper functionality and to maximize your user experience.



Image: The roiesvry XS16 Mini Smartphone, showcasing its compact size when held in a hand.

2. PRODUCT OVERVIEW

2.1 Package Contents

- roiesvry XS16 Mini Smartphone
- USB Type-C Charging Cable
- Protective Film (pre-applied or included)
- Protective Case
- User Manual

2.2 Device Features

- **Compact Design:** Small and portable, designed for easy handling and pocketability.
- **Display:** 3.0-inch HD IPS Touch Screen.
- **Operating System:** Android 10.0 with Google App Store support.
- **Processor:** Quad Core.
- **Memory & Storage:** 3GB RAM, 64GB ROM.
- **Cameras:** 5MP Rear Camera, 2MP Front Camera.
- **Battery:** 2000mAh capacity.
- **Connectivity:** 4G LTE, Wi-Fi, Bluetooth.
- **Charging Port:** USB Type-C.

- **SIM Support:** Dual SIM capability.

Small and portable

Card body fashionable and portable

Born with a lightweight feel and a compact design like the palm of the hand, the small size does not take up any space, making it fashionable and cutting-edge.





Image: The XS16 Mini Smartphone demonstrating its small, card-like body for portability.

3. INITIAL SETUP

3.1 Inserting SIM Cards

1. Locate the SIM card tray on the side of the device.
2. Use the provided SIM ejector tool to open the tray.
3. Carefully place your Nano-SIM cards into the designated slots. Ensure they are correctly oriented.
4. Gently push the SIM tray back into the device until it clicks into place.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button (usually on the right side) until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' from the options on the screen.

3.3 Initial Configuration

Upon first power-on, follow the on-screen prompts to set up your device. This includes selecting your language, connecting to Wi-Fi, setting up your Google account, and configuring security options.

4. OPERATING INSTRUCTIONS

4.1 Navigation

- **Touch Screen:** Tap, swipe, pinch-to-zoom to interact with the interface.
- **Home Button:** Returns to the home screen.
- **Back Button:** Returns to the previous screen.
- **Recent Apps Button:** Displays recently used applications.

4.2 Making Calls

1. Open the 'Phone' application.
2. Enter the phone number using the dial pad or select a contact.
3. Tap the call icon to initiate the call.

4.3 Sending Messages

1. Open the 'Messaging' application.
2. Tap the 'New Message' icon.
3. Enter the recipient's number or select from contacts.
4. Type your message and tap 'Send'.

4.4 App Management

The device runs on Android 10.0 and supports the Google App Store. You can download and install a wide range of applications. To manage apps, go to **Settings > Apps & notifications**.

Original purity

10.0 Android Native System

Lightweight and compact body, pure Android system, compatible with various mainstream apps, smooth and fast multitasking operation, easy to meet daily needs.





Image: The XS16 Mini Smartphone showcasing its Android 10.0 operating system and compatibility with various applications.

5. CHARGING AND BATTERY

The XS16 is equipped with a 2000mAh battery. To charge the device:

1. Connect the USB Type-C cable to the charging port at the bottom of the phone.
2. Connect the other end of the cable to a compatible USB power adapter or a computer's USB port.
3. The battery icon on the screen will indicate charging status.

For optimal battery life, avoid extreme temperatures and fully discharging the battery frequently.

Strong electrical energy

Quickly regenerate and accompany for a long time

Type-C fast charging, full battery, long-lasting and more powerful range, balancing high performance and low power consumption, playing games, watching TV dramas, and constantly exciting.





Image: The XS16 Mini Smartphone connected to a Type-C charger, displaying battery charging status.

6. CAMERA USAGE

The XS16 features a 5MP rear camera and a 2MP front camera for capturing photos and videos.

1. Open the 'Camera' application.
2. Tap the shutter button to take a photo.
3. Switch between front and rear cameras using the camera toggle icon.
4. Select video mode to record videos.

HD camera

Clear and stable production of large films

Every time the shutter is pressed, delicate colors and moving moments are displayed, and the details of light and dark are more beautiful. As you can see, the "mirror" is in control.

20%↑

15%↑

Signal-to-noise
ratio improvement

Improved color
restoration



Image: Close-up of the rear camera module on the XS16 Mini Smartphone.

Beauty camera

If you want to shoot, shoot the dazzling protagonist

Portrait mode, available on camera for any shot, providing a variety of illusion style masks, intelligently optimized skin, easy to take photos with ease, and changing selfie style.



7. STORAGE MANAGEMENT

The device comes with 64GB of internal storage. To manage your storage:

- Go to **Settings > Storage** to view usage and free up space.
- You can transfer files to a computer using the USB Type-C cable.

Massive storage

Massive and exciting downloads

With 64GB of storage space, you can easily store games, photos, and videos. With such a large space, you can pack everything you like.



12000
Photos



225 episodes
TV play



3500 pieces
Music





Image: Visual representation of the 64GB storage capacity on the XS16 Mini Smartphone.

8. MAINTENANCE

8.1 Cleaning

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using harsh chemicals or abrasive materials.

8.2 Software Updates

Periodically check for software updates to ensure your device has the latest features and security patches. Go to **Settings > System > System update**

8.3 Protective Accessories

The included protective film and case help guard against scratches and minor impacts. Ensure they are properly installed for maximum protection.

9. TROUBLESHOOTING

Issue	Possible Solution
Device does not power on	Ensure the battery is charged. Connect to a charger for at least 30 minutes.
No network signal	Check if SIM cards are correctly inserted. Verify network settings and ensure your plan is active. Restart the device.
Apps crashing or slow performance	Close background apps. Clear app cache (Settings > Apps). Restart the device. Ensure sufficient storage space.
Touch screen unresponsive	Restart the device. Ensure the screen is clean and dry.
Battery drains quickly	Reduce screen brightness. Close unused apps. Disable Wi-Fi/Bluetooth when not in use. Check for background app activity.

If issues persist, please refer to the support section or contact customer service.

10. SPECIFICATIONS

Feature	Detail
Model Name	XS16
Brand	roiesvry
Operating System	Android 10.0
Screen Size	3.0 Inches
Resolution	320 x 480
RAM	3 GB
Memory Storage Capacity	64 GB
Rear Camera	5 MP
Front Camera	2 MP
Battery Capacity	2000 mAh
Charging Port	USB Type-C
Cellular Technology	4G LTE
Wireless Connectivity	Wi-Fi, Bluetooth
SIM Support	Dual SIM
Audio Jack	No headphone jack
Item Weight	8.1 ounces
Manufacturer	SOYES

11. PRODUCT VIDEOS

XS16 Mini Smartphone Overview

Your browser does not support the video tag.

Video: A detailed overview of the XS16 Mini Smartphone, highlighting its features and compact design.

XS16 Pro Mini Smartphone Features


Your browser does not support the video tag.

Video: This video demonstrates various features and functionalities of the XS16 Pro Mini Smartphone.

12. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or

visit the official roiesvry website. Keep your proof of purchase for warranty claims.



© 2023 roiesvry. All rights reserved.