

[Manuals.plus](#) /

› [Upstreman](#) /

› User Manual for Upstreman 4.0 Cu.Ft. Mini Fridge with Freezer

## Upstreman BR401

# Upstreman 4.0 Cu.Ft. Mini Fridge with Freezer User Manual

Model: BR401

## PRODUCT OVERVIEW

The Upstreman 4.0 Cu.Ft. Mini Fridge with Freezer is a compact and efficient refrigeration solution designed for small spaces such as dorms, offices, and bedrooms. It features a double-door design with separate compartments for refrigeration and freezing, offering versatile storage options. This appliance is engineered for energy efficiency and quiet operation, making it suitable for various living environments.



Front view of the Upstreman 4.0 Cu.Ft. Mini Fridge with Freezer in black.

# PRODUCT SIZE



Diagram illustrating the product dimensions (17.71" W x 17.71" D x 45.27" H) and internal capacity, showing 1.0 cu.ft. for the freezer and 3.04 cu.ft. for the cooler.

## WHAT'S IN THE BOX

- 1 x Upstreman 4.0 Cu.Ft. Mini Fridge with Freezer
- 1 x User Manual
- Accessories (e.g., shelves, crisper drawer, ice tray if included)

## SETUP AND INSTALLATION

## Unpacking

Carefully remove all packaging materials. Inspect the refrigerator for any shipping damage. Keep packaging materials until you are satisfied with the product's operation.

## Placement

Choose a location with a hard, level surface away from direct sunlight and heat sources. Ensure adequate air circulation around the unit (at least 4 inches of space on the sides and back). The refrigerator operates quietly at 38 dB and is energy efficient, costing approximately \$0.10 per day.



Visual representation of the refrigerator's low energy consumption and quiet 38dB operation.



**Kitchen**



**Office**



**Apartment**



**Garage**

Examples of suitable placement locations for the compact refrigerator, including kitchen, office, apartment, and garage.

## Leveling

The refrigerator is equipped with adjustable legs to ensure stability on uneven floors. Rotate the legs clockwise or counter-clockwise to raise or lower the unit until it is level.

## Door Reversal

The reversible door design allows you to change the door swing direction (left or right) to best suit your room layout. Refer to the detailed instructions in the included user manual for the door reversal procedure.



Diagram illustrating the reversible door feature, allowing the door to open from either side.

## Initial Operation

Before plugging in, clean the interior and exterior of the refrigerator. After placement, allow the unit to stand upright for at least 4 hours (or preferably 24 hours, as suggested by some users) before plugging it into a power outlet. This allows the refrigerant to settle, ensuring optimal performance.

## OPERATING INSTRUCTIONS

### Temperature Control

The refrigerator features 5 adjustable temperature settings, providing flexibility for various food and beverage storage needs. The refrigerator compartment temperature ranges from 33.8°F to 46.4°F, while the freezer compartment maintains a consistent -0.4°F.



Close-up of the temperature control dial with settings from 1 to 5.



Visual guide to the freezer temperature (-0.4°F) and cooler temperature range (33.8°F to 46.4°F).

## Internal Storage

The refrigerator offers a 3.04 cu.ft cooler and a 0.96 cu.ft freezer. It includes removable shelves for customizable storage and a crisper drawer designed to keep fruits and vegetables fresh.

- **Adjustable Shelves:** The shelves can be repositioned to accommodate items of various heights.
- **Crisper Drawer:** Located at the bottom, this drawer helps maintain humidity for produce.
- **Automatic LED Light:** An internal LED light automatically illuminates when the refrigerator door is opened, aiding visibility.



**CRISPER DRAWER**



**ADJUSTABLE SHELVES**



**AUTOMATIC LIGHT**



**5 TEMPERATURE SETTINGS**

Detailed view of the crisper drawer, adjustable glass shelves, automatic interior light, and temperature control knob.



A hand demonstrating the adjustability of the glass shelves.



The crisper drawer, designed to keep fruits and vegetables fresh.

## MAINTENANCE AND CARE

### Cleaning

Regularly clean the interior and exterior of your refrigerator. Use a soft cloth with a mild detergent and warm water. Avoid abrasive cleaners or harsh chemicals. Ensure the unit is unplugged before cleaning.

### Defrosting

This refrigerator features manual defrost. When frost accumulates to about 1/4 inch thickness in the freezer compartment, it's time to defrost. Unplug the unit, remove all food, and allow the frost to melt naturally. Wipe dry before restarting.

### Shelf Adjustment

To adjust shelves, carefully lift the shelf and pull it out. Reinsert into desired slots, ensuring it is securely seated.

## TROUBLESHOOTING

If you encounter issues with your Upstreman mini fridge, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Refrigerator does not cool	Not plugged in; power outage; temperature setting too high; poor ventilation.	Check power connection; verify power supply; adjust temperature setting lower; ensure adequate space around the unit.
Unit is making unusual noise	Unit not level; objects vibrating against the unit; normal operating sounds.	Adjust leveling legs; ensure nothing is touching the back or sides; some humming is normal during operation.
Excessive frost buildup in freezer	Frequent door opening; high humidity; door not sealed properly.	Minimize door openings; ensure door gasket is clean and sealing tightly; perform manual defrost.

Problem	Possible Cause	Solution
Food not freezing in freezer	Freezer overloaded; door left open; temperature setting too high.	Do not overload freezer; ensure door is closed properly; verify freezer temperature is at -0.4°F.

## SPECIFICATIONS

Feature	Detail
Brand Name	Upstreman
Model Info	BR401
Product Dimensions (W x D x H)	17.71 x 17.71 x 45.27 inches
Capacity	4 Cubic Feet
Refrigerator Fresh Food Capacity	3.04 Cubic Feet
Freezer Capacity	0.96 Cubic Feet
Annual Energy Consumption	291 Kilowatt Hours Per Year
Installation Type	Freestanding
Color	Black
Voltage	115 Volts
Number of Crispers/Drawers	1
Defrost System	Manual
Door Hinges	Reversible
Door Material Type	Stainless Steel
Shelf Type	Adjustable
Number of Shelves	3
Number Of Doors	2

## WARRANTY AND SUPPORT

Your Upstreman 4.0 Cu.Ft. Mini Fridge with Freezer comes with a one-year quality service warranty. For any product inquiries, technical support, or warranty claims, please refer to the contact information provided in your included user

manual or visit the official Upstreman support website.

For a digital copy of the user manual, you can also refer to the following link [Upstreman 4.0 Cu.Ft. Mini Fridge User Manual \(PDF\)](#)