

[Manuals.plus](#) /

› [XP-Pen](#) /

› XPPen Artist 22 Plus Drawing Tablet User Manual

XP-Pen MD220FH

XPPen Artist 22 Plus Drawing Tablet User Manual

Model: MD220FH | Brand: XP-Pen

1. INTRODUCTION

The XPPen Artist 22 Plus is a 22-inch drawing display designed for digital artists and creative professionals. It features a fully laminated anti-glare screen, an X3 Pro Smart Chip Stylus with 16K pressure levels, and a wide color gamut to provide a precise and immersive creative experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



Image: XPPen Artist 22 Plus Drawing Tablet overview.

2. WHAT'S IN THE BOX

Please verify that all items are present in the package:

- XPPen Artist 22 Plus Drawing Display
- X3 Pro Smart Chip Stylus
- Drawing Display Stand
- Drawing Glove
- 10 x Pen Nibs

- Pen Clip
- Cleaning Cloth
- Nib Removal Tool
- USB-C to USB-C Cable
- USB-A to USB-C Cable
- HDMI Cable
- Power Cable
- Power Adapter

High color accuracy. Everything on point.



Image: All components included in the XPPen Artist 22 Plus package.

3. SETUP

3.1 Connecting the Tablet

The Artist 22 Plus offers flexible connectivity options:

- **USB-C to USB-C Connection:** Connect one end of the USB-C to USB-C cable to the tablet's USB-C port and the other end to a compatible USB-C port on your computer that supports DisplayPort Alternate Mode. Connect the power adapter to the DC port.
- **HDMI and USB-A to USB-C Connection:** Connect the HDMI cable from the tablet to your computer's HDMI port. Connect the USB-A to USB-C cable from the tablet's USB-C port to a USB-A port on your computer. Connect the power adapter to the DC port.

Highly compatible. Highly capable.



Image: Connection methods for the Artist 22 Plus drawing display.

3.2 Driver Installation

Before using the tablet, download and install the latest drivers from the official XPPen website. Ensure any previous tablet drivers are uninstalled to prevent conflicts. Restart your computer after installation.

3.3 Stand Adjustment and VESA Mounting

The Artist 22 Plus includes a built-in foldable stand that allows for angle adjustments from 15° to 88° for comfortable working positions. The display also supports VESA mounting (100 x 100 mm) for integration with external monitor arms or stands.

**Fully laminated screen.
No parallax error.**



Image: Adjustable foldable stand for ergonomic use.

**Fully laminated screen.
No parallax error.**



Image: VESA mounting points for flexible display setup.

4. OPERATING THE TABLET

4.1 X3 Pro Smart Chip Stylus

The included X3 Pro Smart Chip Stylus features 16K pressure levels, offering enhanced sensitivity and precision for detailed artwork. It supports 60° tilt recognition, allowing for natural shading and brush strokes. The stylus is designed for smooth and accurate lines, minimizing lag and broken lines.




Image: X3 Pro Smart Chip Stylus with 16K pressure sensitivity.




Image: Convenient pen clip for stylus storage.

4.2 Display Features

The 22-inch display provides a spacious canvas with a 16:9 screen ratio and 1920 x 1080 resolution. It boasts 130% sRGB color gamut, 8-bit color depth, and 16.7 million colors, ensuring vibrant and accurate color reproduction. The fully laminated screen minimizes parallax, and the anti-glare matte film reduces reflections for a comfortable viewing experience.



Image: Fully laminated screen with anti-glare film for reduced parallax.



Image: Color accuracy features including 130% sRGB and 8-bit color depth.

4.3 Compatibility

The Artist 22 Plus is compatible with various operating systems, including Windows 7 (or later), macOS 10.10 (or later), Chrome OS 88 (or later), Android (USB3.1 DP1.2), and Linux. It supports popular digital art software such as Adobe Photoshop, Illustrator, SAI, CDR, GIMP, Krita, MediBang, FireAlpaca, Toonboom, Maya, and Blender3D.

Fully laminated screen. No parallax error.



Anti-glare matte film



No parallax error



Image: Broad compatibility with operating systems and creative software.

4.4 Usage Modes

Beyond drawing, the Artist 22 Plus can function as an extended display for various activities, including video mirroring, screen splitting for multitasking, gaming, remote meetings, and online classes.

16K pressure sensitivity curve. More stable and smooth.





Image: Versatile usage modes for the display.

Your browser does not support the video tag.

Video: Official product video showcasing the XPPen Artist 22 Plus Drawing Tablet with Screen, highlighting its features and versatility.

5. MAINTENANCE

5.1 Cleaning the Screen

Use the provided cleaning cloth or a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, lightly dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals or abrasive materials that could damage the anti-glare film.

5.2 Stylus Nib Replacement

When the stylus nib wears down, use the nib removal tool to carefully pull out the old nib. Insert a new nib firmly into the stylus until it clicks into place. Replacement nibs are included in the package.

5.3 General Care

Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the tablet or exposing it to liquids. Always use the provided cables and power adapter to ensure optimal performance and safety.

6. TROUBLESHOOTING

6.1 No Display/Signal

- Ensure all cables (USB-C, HDMI, Power) are securely connected.
- Verify that your computer's USB-C port supports DisplayPort Alternate Mode if using a single USB-C cable.
- Check your computer's display settings to ensure the tablet is detected and set as an extended or mirrored display.
- Try connecting the tablet to a different port on your computer or using different cables.

6.2 Stylus Not Responding/Inaccurate

- Ensure the latest drivers are installed correctly. Reinstall if necessary.
- Calibrate the screen and stylus through the XPPen driver settings.
- Check if the stylus nib is worn out and replace it if needed.
- Ensure there are no other tablet drivers installed that might conflict with the XPPen driver.

6.3 Parallax Issues

The Artist 22 Plus features a fully laminated screen to minimize parallax. If you experience slight offset, ensure your display resolution is set to 1920x1080 and perform a stylus calibration through the driver software.

7. SPECIFICATIONS

Feature	Detail
Model Name	MD220FH
Product Dimensions	25.5 x 17.7 x 0.04 inches

Feature	Detail
Item Weight	17.8 pounds
Display Size	21.5-inch (22-inch class)
Resolution	1920 x 1080
Color Gamut	130% sRGB
Color Depth	8-bit (16.7 Million Colors)
Stylus Pressure Levels	16384
Stylus Tilt Support	60°
Special Feature	Full Lamination, Anti-Glare Display
Connectivity Technology	USB (USB-C, HDMI)
Operating System Compatibility	Windows 7+, macOS 10.10+, Chrome OS 88+, Android (USB3.1 DP1.2), Linux
VESA Mount	100 x 100 mm



Image: Product dimensions of the Artist 22 Plus.

8. WARRANTY AND SUPPORT

XPPen offers a **1-Year Protection Plan** for all its products. For detailed terms and conditions regarding support, returns, and refunds, please refer to the official XPPen website or contact XPPen customer service directly. You can reach out via Amazon Message for any product-related inquiries.



Image: XPPen warranty and service information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question