

[Manuals.plus](#) /

› [Mingxiong](#) /

› Mingxiong Active Pen 3 Nibs Replacement for Lenovo Active Pen 3 User Manual

Mingxiong MX_LX_ActivePen3_Tips

Mingxiong Active Pen 3 Nibs Replacement User Manual

For Lenovo Active Pen 3

1. INTRODUCTION

Thank you for choosing Mingxiong Active Pen 3 Nibs. This product is designed to replace worn or damaged nibs on your Lenovo Active Pen 3, ensuring continued precision and responsiveness for your digital tasks. This manual provides essential information on compatibility, installation, usage, and maintenance to help you get the most out of your replacement nibs.

2. COMPATIBILITY

These replacement nibs are specifically designed for and compatible with the **Lenovo Active Pen 3**. Please verify your stylus model before installation to ensure proper fit and function.

Compatible with Lenovo Active Pen 3



Image: The Mingxiong replacement nib shown alongside a Lenovo Active Pen 3, illustrating compatibility.

3. INSTALLATION GUIDE

Replacing the nib on your Lenovo Active Pen 3 is a simple two-step process:

1. Step 1: Remove the Old Nib

Gently pull the old or worn nib straight out from the tip of your Lenovo Active Pen 3. You may use a small pair of tweezers if it is difficult to grip. Avoid twisting or bending the nib during removal to prevent damage to the pen's internal components.

2. Step 2: Insert the New Nib

Take a new Mingxiong replacement nib and carefully insert it straight into the tip of the pen. Push it in until you feel a slight click or resistance, indicating it is securely seated. Do not force the nib.

High sensitivity and precision



Image: A close-up view of the replacement nib positioned next to the stylus tip, demonstrating where the nib is inserted.

4. OPERATING PRINCIPLES

The Mingxiong replacement nibs are engineered to maintain the high performance of your Lenovo Active Pen 3, offering:

- **Pressure Sensitivity:** Experience precise control with 4096 levels of pressure sensitivity, allowing for nuanced lines and shading with minimal effort.
- **Accuracy and Responsiveness:** Achieve real-time outlining and shadowing without delay, responding to the lightest touch.
- **Scratch-Free Design:** The nib material is designed to prevent scratches on your screen while significantly reducing friction for a smooth writing and drawing experience.




Image: Illustrations of the stylus tip creating various lines, demonstrating its precision and smooth operation.

5. MAINTENANCE

To ensure the longevity and optimal performance of your replacement nibs and Lenovo Active Pen 3:

- **Regular Cleaning:** Periodically wipe the nib with a soft, dry, lint-free cloth to remove any dust or debris.
- **Avoid Impact:** Protect the pen and nib from drops or impacts, which can cause damage.
- **Proper Storage:** When not in use, store your pen in a safe place where the nib is not subjected to pressure or friction.
- **Replace When Worn:** Replace the nib if you notice a decrease in performance, visible wear, or if it begins to scratch your screen.

6. TROUBLESHOOTING

If you encounter issues after replacing your nib, consider the following:

- **Nib Not Responding:** Ensure the nib is fully inserted into the pen. Remove and re-insert it firmly.
- **Inaccurate Input:** Check if the nib is damaged or bent. If so, replace it with a new one.
- **Pen Not Working:** Verify that your Lenovo Active Pen 3 itself is functioning correctly with its original nib (if available) or another compatible nib. Ensure your device's drivers are up to date.
- **Compatibility Check:** Double-check that your stylus is indeed a Lenovo Active Pen 3, as these nibs are not universally compatible with all styluses.

7. SPECIFICATIONS

Feature	Detail
Product Name	Mingxiong Active Pen 3 Nibs Replacement
Model Number	MX_LX_ActivePen3_Tips
Compatibility	Lenovo Active Pen 3
Material	Plastic
Color	Black

Product Dimensions	0.79 x 0.08 x 0.08 inches
Item Weight	0.634 ounces (0.02 Kilograms)

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Mingxiong Active Pen 3 Nibs, please contact the seller directly through the platform where you made your purchase. Please refer to your purchase documentation for specific return or warranty policies, as these are typically handled by the seller.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question