

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jada](#) /

› [Jada Marvel RC Buggy Spiderman Remote Control Car User Manual](#)

**Jada 253223025**

# Jada Marvel RC Buggy Spiderman Remote Control Car with Turbo Function - 1:24 Scale

Model: 253223025 | Brand: Jada

## PRODUCT OVERVIEW

This Jada Marvel RC Buggy Spiderman is a 1:24 scale remote-controlled vehicle designed for exciting play. It features a full-function remote control with turbo capabilities and 2.4 GHz technology.

Immerse yourself in the world of your favorite hero, Spider-Man! This ergonomic and easy-to-use remote-controlled buggy, adorned with Spider-Man's colors, is sure to delight. Take control of this 1:24 scale car and practice to become the best race car driver! Thanks to the remote control with full driving functions and a turbo function, you can win all races! You can steer your car as you wish: move it forward, turn it right and left, and also make it go backward in a straight line or to the left and right. It operates on 2.4GHz technology and includes batteries. Suitable for ages 6 and up.



Image: The Spider-Man themed RC buggy and its accompanying remote control. The buggy is red and blue with Spider-Man details, and the remote control features Spider-Man graphics.

## SETUP

Before operating your RC Buggy, ensure that both the vehicle and the remote control have fresh batteries installed. The product includes the necessary batteries.

## Battery Installation

1. Locate the battery compartment on the underside of the RC Buggy.
2. Open the battery compartment cover.
3. Insert the required batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.
5. Repeat the process for the remote control.

The 2.4 GHz technology allows for multiple RC vehicles to be used in the same area without signal interference. Ensure both the vehicle and remote are powered on to establish connection.



Image: A rear view of the Spider-Man RC buggy, highlighting the detailed rear engine design and large wheels.

## OPERATING INSTRUCTIONS

The remote control provides full-function steering for the RC Buggy. Familiarize yourself with the controls before operating the vehicle.

### Remote Control Functions

- **Forward/Backward:** Use the left joystick to move the buggy forward or backward.
- **Left/Right Steering:** Use the right joystick to steer the buggy left or right while moving.
- **Turbo Function:** Activate the turbo button (usually located on the remote) for a burst of speed.

The 2.4GHz frequency allows for up to 8 vehicles to be played simultaneously without interference, making it ideal for multi-player racing.



2.4GHz w/ TURBO BOOST



FULL FUNCTION R/C

PLAYS UP TO  
8 VEHICLES

Image: The RC buggy and remote control with labels indicating "2.4GHz w/ TURBO BOOST", "FULL FUNCTION R/C", and "PLAYS UP TO 8 VEHICLES".



6.5in / 16.51cm



Image: A side view of the Spider-Man RC buggy, showing its length as 6.5 inches / 16.51 cm.

## MAINTENANCE

Proper maintenance will extend the life and performance of your RC Buggy.

- **Cleaning:** Use a soft, dry cloth to wipe down the vehicle after each use. Avoid using water or harsh chemicals, as they can damage the electronics.
- **Storage:** Store the RC Buggy and remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries from both the vehicle and remote control if they will not be used for an extended period to prevent leakage and damage.
- **Wheel Inspection:** Periodically check the wheels for any debris or hair that might impede movement.

## TROUBLESHOOTING

If you encounter issues with your RC Buggy, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vehicle does not respond to remote.	Low or dead batteries in vehicle or remote; vehicle and remote not paired.	Replace batteries in both vehicle and remote. Ensure both are turned on and within range.
Poor performance or slow speed.	Low batteries; operating on unsuitable surfaces (e.g., thick carpet); debris in wheels.	Replace batteries. Operate on smooth, flat surfaces. Check and clear any obstructions from wheels.
One wheel not making full contact with ground.	Minor manufacturing variance or slight chassis warp.	This may not significantly affect performance on smooth surfaces. If performance is severely impacted, contact customer support.
Interference with other RC vehicles.	Not applicable with 2.4GHz technology, which minimizes interference.	Ensure no other strong radio signals are present. Re-pair if necessary.

## SPECIFICATIONS

---

Feature	Detail
Product Dimensions (L x W x H)	17 x 10.5 x 8.5 cm (6.7 x 4.1 x 3.3 inches)
Weight	340 grams (0.75 lbs)
Recommended Age	6 - 10 years
Manufacturer Reference	253223025
Number of Pieces	1
Assembly Required	No
Batteries Required	Yes
Batteries Included	Yes
Main Material	Plastic
Color	Multicolor (Red, Blue)
Model Name	RC Buggy Spiderman
Power Source	Battery Powered
Special Feature	Spider Theme



Image: A direct front view of the Spider-Man RC buggy, showcasing its blue hood and red fenders with yellow headlights.



Image: A direct rear view of the Spider-Man RC buggy, showing the chrome-like engine details and large rear wheels.

## SAFETY WARNINGS

**WARNING! Not suitable for children under 3 years. Minimum age 36 months. Small parts. Choking hazard.**

- Always supervise children during play.
- Do not operate the vehicle near people, pets, or fragile objects.
- Avoid operating in wet conditions or on public roads.
- Do not modify the product in any way.
- Dispose of batteries responsibly.

## WARRANTY AND SUPPORT

This product comes with a 1-year availability for spare parts from the date of purchase.

For technical support, warranty claims, or inquiries regarding spare parts, please contact Jada customer service. Refer to the product packaging or the official Jada website for contact information.

You can visit the official Jada store for more information:[Jada Brand Store](#)

