

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

NERF Elite 2.0 Ultimate Blaster

NERF Elite 2.0 Blaster Pack Instruction Manual

MODEL: ELITE 2.0 ULTIMATE BLASTER

Brand: NERF

Introduction

The NERF Elite 2.0 Ultimate Blaster 3-Pack provides an exciting and customizable experience for foam dart enthusiasts. This pack includes three distinct blasters: the Eaglepoint, Tetrad, and Trio, along with 50 Elite darts. Designed for tactical play, these blasters feature upgrade-ready tactical rails, allowing for personalized configurations to suit various play scenarios. This manual provides essential information for setup, operation, maintenance, and safety to ensure a fun and safe experience.

Safety Information

WARNING: CHOKING HAZARD – Small parts. Not suitable for children under 3 years.

Use only official Nerf darts. Do not aim at eyes or face.

Always wear eye protection when using blasters (not included). Do not modify darts or blaster.

What's in the Box

- 1 x NERF Elite 2.0 Eaglepoint Blaster
- 1 x NERF Elite 2.0 Tetrad Blaster
- 1 x NERF Elite 2.0 Trio Blaster
- 1 x Removable Scope attachment
- 1 x Removable Barrel extension
- 50 x Official NERF Elite Darts

Setup

The NERF Elite 2.0 blasters are designed for easy assembly and customization. Follow these steps to prepare your blasters for play:

Eaglepoint Blaster Assembly:

The Eaglepoint blaster comes with a removable scope and barrel extension for enhanced play. These accessories can be easily attached to the tactical rails on the blaster.

1. **Attaching the Barrel Extension:** Align the barrel extension with the front of the Eaglepoint blaster. Push it firmly into place and twist to secure it. Ensure it clicks into position.

2. **Attaching the Scope:** Locate the tactical rail on top of the Eaglepoint blaster. Slide the scope onto the rail from the back until it locks securely into place. The scope offers a magnified view for aiming.




The Eaglepoint blaster fully assembled with its removable scope and barrel extension, ready for action.

This video demonstrates the assembly of the Nerf Elite 2.0 Eaglepoint blaster, including attaching the barrel and scope, loading darts into the rotating cylinder, and utilizing the on-blaster dart storage. It also shows the bolt-action mechanism for firing.

Dart Loading:

All blasters use official NERF Elite darts. Ensure darts are not damaged or bent for optimal performance.

- **Eaglepoint Blaster:** Load up to 8 darts into the rotating cylinder. The cylinder can be accessed by lifting the top cover.
- **Tetrad Blaster:** Load darts into the front-loading barrels.
- **Trio Blaster:** Load darts into the three front-loading barrels.



A detailed view of the three blasters included in the pack: the large Eaglepoint, the medium Tetrad, and the compact Trio, alongside a pile of Elite darts.

Operating Instructions

Once assembled and loaded, your blasters are ready for action!

Firing the Eaglepoint Blaster:

- Prime the Blaster:** Pull the bolt-action priming handle located on the side of the blaster all the way back until it clicks. This cocks the blaster and rotates the cylinder to load a dart.
- Aim:** Use the attached scope for improved accuracy, or aim down the barrel.
- Fire:** Press the trigger to launch the dart.
- Reload and Repeat:** After firing, prime the blaster again to load the next dart from the cylinder.

Firing the Tetrad and Trio Blasters:

These blasters are simpler to operate with direct priming mechanisms.

- Tetrad Blaster:** Pull the pump-action handle back and then forward to prime. Press the trigger to fire.
- Trio Blaster:** Pull the priming handle at the bottom of the grip to prime. Press the trigger to fire.

Dart Storage:

The Eaglepoint blaster features integrated dart storage on both sides of the stock, allowing you to keep extra darts readily accessible during play. Simply push darts into the designated slots.

Maintenance

To ensure the longevity and optimal performance of your NERF blasters, follow these simple maintenance tips:

- Cleaning:** Wipe down the blasters with a damp cloth as needed. Do not submerge blasters in water.
- Dart Care:** Keep darts clean and free from debris. Avoid bending or crushing darts, as this can affect their flight performance and potentially cause jams. Store darts in a dry place.
- Storage:** Store blasters in a cool, dry place away from direct sunlight when not in use.

Troubleshooting

If you encounter any issues with your NERF blasters, try the following solutions:

- Dart Jams:** If a dart gets stuck, ensure the blaster is not primed. Carefully remove the jammed dart from the barrel or loading area. Do not force the priming mechanism.
- Darts Not Firing:** Ensure the blaster is fully primed. Check if the dart is properly loaded into the barrel or cylinder. If darts are old or damaged, replace them with new official NERF Elite darts.
- Reduced Range:** This can be caused by worn-out darts or debris in the barrel. Try using new darts and ensure the barrel is clear.

Specifications

Feature	Detail
Product Dimensions	16 x 10 x 3 inches
Item Weight	4.4 pounds
Item Model Number	Elite 2.0 Ultimate Blaster
Manufacturer Recommended Age	8 - 8 years
Manufacturer	Hasbro

Dart Capacity (Eaglepoint)	8 darts (rotating cylinder)
Dart Storage (Eaglepoint)	8 darts (on-blaster storage)

Warranty and Support

For warranty information or customer support, please refer to the official NERF website or contact Hasbro customer service. Keep your proof of purchase for any warranty claims.

For additional resources and product information, visit the official NERF store online:[NERF Official Store](#)