

Tork 976000-CON

Tork Elevation A3 Continuous Action Air Freshener Starter Pack

Model: 976000-CON

1. INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your Tork Elevation A3 Continuous Action Air Freshener Starter Pack. This innovative system is designed to deliver a consistent and pleasant fragrance, effectively neutralizing odors in various environments.



Image 1.1: Tork Elevation A3 Air Freshener Dispenser and Refill.

2. SAFETY INFORMATION

Please read all safety instructions before using the product. Failure to follow these instructions may result in injury or product damage.

- Keep the dispenser and refills out of reach of children and pets.
- Do not ingest the fragrance refill liquid. In case of ingestion, seek immediate medical attention.
- Avoid contact of the fragrance liquid with skin and eyes. In case of contact, rinse thoroughly with water.
- Use in well-ventilated areas.
- Do not expose the dispenser or refills to open flames, high temperatures, or direct sunlight.
- Only use Tork A3 refills with this dispenser.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Tork Elevation Air Freshener Dispenser (White)
- 1 x Tork A3 Air Freshener Refill (Brezza fragrance)

- Instruction Manual

Note: Batteries are required for operation and are **not included** in this starter pack. Please purchase 2 x AA batteries separately.

4. SETUP

4.1. Mounting the Dispenser

1. Choose a suitable location for the dispenser, ensuring it is at a desired height for optimal fragrance distribution and accessibility.
2. Open the dispenser cover using the provided key or release button.
3. Mark the desired drilling points on the wall using the dispenser's mounting holes as a template.
4. Drill holes and insert appropriate wall plugs (not included).
5. Secure the dispenser to the wall using screws (not included).

4.2. Inserting Batteries

1. Locate the battery compartment inside the dispenser.
2. Insert 2 x AA batteries, ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.

4.3. Inserting the Refill

1. Remove the cap from the Tork A3 air freshener refill.
2. Insert the refill into the designated slot within the dispenser. Ensure it clicks into place.
3. Close the dispenser cover until it locks securely.

Tork® è il primo marchio di igiene professionale al mondo



Venduto
in oltre

110
Paesi



Image 4.1: Tork Elevation A3 Air Freshener Dispenser with cover open, showing internal components.

5. OPERATING INSTRUCTIONS

The Tork Elevation A3 Air Freshener Dispenser operates automatically once set up. It utilizes a patented continuous action delivery technology to ensure a consistent and long-lasting fragrance experience.

- After installation and refill insertion, the dispenser will begin to release fragrance at programmed intervals.
- The system is designed to eliminate odors rather than just masking them, providing a fresh environment.
- No manual intervention is typically required during normal operation until the refill or batteries need replacement.

6. MAINTENANCE

6.1. Refill Replacement

When the fragrance level is low or depleted, replace the refill:

1. Open the dispenser cover.
2. Remove the empty refill from its slot.
3. Insert a new Tork A3 air freshener refill, ensuring it is securely in place.

4. Close the dispenser cover.

6.2. Battery Replacement

Replace batteries when the dispenser's indicator light (if present) signals low power, or when fragrance release becomes inconsistent:

1. Open the dispenser cover.
2. Open the battery compartment.
3. Remove the old batteries and dispose of them according to local regulations.
4. Insert 2 new AA batteries, observing correct polarity.
5. Close the battery compartment and dispenser cover.

6.3. Cleaning

Clean the dispenser periodically to maintain hygiene and appearance:

- Wipe the exterior of the dispenser with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as these may damage the surface.
- Ensure no liquid enters the internal electronic components.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No fragrance released	Empty refill Dead batteries Dispenser cover not closed properly	Replace refill Replace batteries Ensure cover is securely latched
Weak fragrance	Refill nearing depletion Dispenser placed in a very large area Airflow obstruction	Replace refill Consider additional dispensers for larger spaces Ensure dispenser is not blocked by objects
Dispenser not operating	Batteries incorrectly inserted Faulty batteries	Check battery polarity Try new batteries

8. SPECIFICATIONS

Model Number:

976000-CON

Brand:

Tork

Color:

White

Product Dimensions (LxWxH):

12.6 x 16.4 x 16.1 cm

Item Weight:

650 g

Power Source Type:

Passive diffusion (battery-operated mechanism)

Batteries Required:

Yes (2 x AA, not included)

Fragrance Included:

Brezza (Lemon note)

9. WARRANTY INFORMATION

Tork products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or visit the official Tork website. Keep your proof of purchase for any warranty claims.

10. SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact Tork customer support. Contact details can typically be found on the Tork official website or on the product packaging.