Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

M-VAVE M008_Black_WP_1

M-VAVE Wireless Guitar System User Manual


Model: M008_Black_WP_1

1. Introduction

The M-VAVE Wireless Guitar System provides a stable, cable-free connection for your instrument, enhancing your musical performance with advanced 2.4G wireless technology. Designed for ease of use and high-quality sound, this system offers freedom of movement and professional-grade audio output.

Key Features:

- **Wireless 2.4G Technology:** Ensures stable, interference-proof connection.
- **Rechargeable & Long Battery Life:** Built-in rechargeable system for extended use.
- **High-Quality Sound & Enhanced Audio:** Delivers clear, dynamic, and professional sound.
- **Easy Setup & Wireless Convenience:** Seamless plug-and-play operation.
- **Compact Design & Versatile Compatibility:** Portable and compatible with most guitar types and amplifiers.



The M-VAVE wireless system offers freedom from traditional guitar cables.

2. Package Contents

Please ensure all items are present in your package:

- 1 x M-VAVE Wireless Transmitter (WP-1 TRANSMITTER)
- 1 x M-VAVE Wireless Receiver (WP-1 RECEIVER)
- 1 x USB Charging Cable (One-in-two USB cable)
- 1 x User Manual



Contents of the M-VAVE Wireless Guitar System package.

3. Product Overview

Familiarize yourself with the components of your M-VAVE Wireless Guitar System:



Labeled diagram of the M-VAVE WP-1 Transmitter and Receiver.

Key Components:

- **280° Rotatable Joint:** Allows for flexible positioning on various instruments.
- **USB Charging Port:** For convenient recharging.
- **LED Light:** Indicates power, charging, and pairing status.
- **Pairing Button:** Used to establish connection between transmitter and receiver.
- **Power Supply Button:** Turns the unit on/off.

4. Setup

4.1 Charging the Units

Before first use, fully charge both the transmitter and receiver. Use the provided USB charging cable.

- Connect the one-in-two USB cable to both the transmitter and receiver.
- Plug the USB end into a standard USB power adapter (not included) or a computer USB port.
- The LED indicator will show charging status (refer to LED indicator section in specifications for details).
- A full charge provides approximately 6 hours of continuous use.




Charging the M-VAVE wireless units with the provided USB cable.

4.2 Pairing the Units

The transmitter and receiver are pre-paired from the factory. If re-pairing is needed:

- Turn on both the transmitter and receiver by pressing and holding their respective power buttons.
- Press and hold the 'Pair' button on both the transmitter and receiver simultaneously.
- The LED lights will flash during pairing and turn solid green once successfully paired.



Pairing the M-VAVE wireless transmitter and receiver.

5. Operating Instructions

5.1 Connecting to Your Setup

The M-VAVE Wireless Guitar System is designed for versatile use with various musical equipment:

- Plug the **Transmitter** into your instrument's output jack (e.g., guitar, bass, keyboard).
- Plug the **Receiver** into the input of your amplifier, stereo mixer, multi-effects pedal, or other guitar pedals/loopers.
- Ensure both units are powered on and successfully paired.



The transmitter unit connected to an electric guitar.



Connecting the M-VAVE system to various instruments and audio equipment.

5.2 Multi-Device Operation

The M-VAVE system supports multiple units working simultaneously:

- One transmitter can send signals to multiple receivers at the same time.
- Up to 6 pairs of independent transmitters and receivers can operate in the same environment without interference.



One transmitter can connect to multiple receivers.



The system supports up to 6 sets of devices working simultaneously.

5.3 Product Demonstration Video

Watch this official video from the seller for a visual demonstration of the M-VAVE Wireless Guitar System:

Official demonstration video of the M-VAVE Wireless Guitar System, showcasing its features and performance.

6. Maintenance

To ensure the longevity and optimal performance of your M-VAVE Wireless Guitar System, follow these maintenance guidelines:

- **Cleaning:** Wipe the units with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the units in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For long-term storage, charge the batteries to about 50% every three months to prevent deep discharge. Avoid completely draining the battery frequently.

- **Handling:** Handle the units with care, especially the rotatable jack, to prevent damage.

7. Troubleshooting

If you encounter issues with your M-VAVE Wireless Guitar System, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Sound / Intermittent Sound	Units not powered on, not paired, out of range, low battery, interference.	Ensure both units are ON. Re-pair the units. Check battery levels and recharge if necessary. Move closer to the receiver. Avoid strong Wi-Fi or other 2.4Ghz devices nearby.
Poor Sound Quality / Noise	Interference, faulty cable connection, unit malfunction.	Check for sources of interference. Ensure connections are secure. Test with a different cable if applicable.
Units not pairing	Incorrect pairing procedure, low battery.	Follow the pairing instructions carefully (Section 4.2). Ensure both units are sufficiently charged.
Short Battery Life	Incomplete charging, aging battery.	Ensure units are fully charged before use. Battery life naturally degrades over time.

If the issue persists after trying these solutions, please contact M-VAVE customer support for further assistance.

8. Specifications

Detailed technical specifications for the M-VAVE Wireless Guitar System:



Overview of M-VAVE Wireless Guitar System specifications.

Specification	Value
Item Weight	13.1 ounces
Package Dimensions	5.67 x 4.25 x 1.73 inches

Specification	Value
Item Model Number	M008_Black_WP_1
Batteries	2 Lithium Polymer batteries required (included)
Color Name	Black
Compatible Devices	Guitar
Connector Type	3.5mm Jack
Output Wattage	5 Watts
Battery Type	Lithium Polymer
Power Source	Battery Powered
Date First Available	November 4, 2022
Wireless Technology	2.4G
Sample Range	24bit/48KHz
Latency	<12ms
Range	≥100 feet outdoors
THD+Noise	-98dB
Dynamic Range	>105dB
Operating Band	2.4GHz ISM Worldwide
Frequency Response	20-20KHz +1dB/-3dB
Swivel Joints	280° rotation
Device Support	6 groups of devices work at the same time
Transmitter Battery Capacity	780mAh
Receiver Battery Capacity	550mAh

9. Warranty and Support

M-VAVE products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included in your package or visit the official M-VAVE website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 M-VAVE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMGJVWR5

More documents and user manuals: **https://manuals.plus/**