

iPhanmis M200

Sabbat M200 True Wireless Earphones User Manual

Model: M200 | Brand: iPhanmis

INTRODUCTION

Thank you for choosing the Sabbat M200 True Wireless Earphones. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your earphones to ensure an optimal audio experience. Please read this manual thoroughly before using the product.

WHAT'S IN THE BOX



The image shows the Sabbat M200 True Wireless Earphones in their charging case. The earbuds feature a unique "Blooming" color pattern with white, orange, and blue accents. The charging case is white and compact.

- 1 pair Sabbat M200 Wireless Earbuds
- 1 Charging Case
- 1 Type-C Charging Cable
- 1 User Manual (this document)


SETUP

1. Charging the Earphones and Case

Before first use, fully charge the earphones and the charging case. Connect the provided Type-C charging cable to the charging case and a USB power source. The charging indicator will show the charging status. A full charge for the case takes approximately 1 hour.

The charging case can provide 4-5 full charges to the earbuds, offering an extended listening time.

2. Bluetooth Pairing



This image illustrates the ease of connection: the Sabbat M200 earbuds are shown in their open charging case, with a visual representation of instant connection. The background features soft, blurred purple flowers, suggesting a seamless and pleasant user experience.

1. Ensure the charging case has power and the earbuds are inside.
2. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for new devices.
4. Select "Sabbat M200" from the list of available devices to connect.
5. Once connected, you will hear a confirmation tone. The earphones utilize Bluetooth 5.3 for a fast and stable connection with low power consumption.

The Sabbat M200 supports both single and dual earbud use. You can use either earbud independently after initial pairing.


OPERATING INSTRUCTIONS

1. Basic Controls

The Sabbat M200 earphones feature touch controls for media playback and call management. Specific touch gestures are detailed below:

Action	Function
Single Tap	Play/Pause music, Answer/End call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap	Activate Voice Assistant
Long Press (2 seconds)	Reject Call

2. Dual Mode Switching (Game/Music)




This image displays the "Dual Mode Multiple Experience" feature, showing two distinct scenarios: "Game Mode" with a user playing a mobile game, emphasizing low latency (as low as 40ms), and "Music Mode" with a user listening to music, highlighting enhanced sound quality with a metal diaphragm sound unit.

The Sabbath M200 earphones support dual mode switching between Game Mode and Music Mode. This allows you to optimize your audio experience based on your activity.

- **Game Mode:** Provides ultra-low latency (as low as 40ms) for synchronized audio and video, crucial for gaming.
- **Music Mode:** Enhances sound quality with a metal diaphragm sound unit, delivering richer bass, clear vocals, and detailed audio for an immersive listening experience.

To switch between modes, perform a specific touch gesture (e.g., long press on a specific earbud or a triple tap on both, refer to the quick start guide for exact gesture if not listed here). A voice prompt will confirm the mode change.

3. Call Functions (ENC Call Noise Reduction)



This image features a person wearing the Sabbath M200 earbuds, with text highlighting "ENC Call Noise Reduction To Create Your Exclusive Space." It explains that DSP digital noise reduction and intelligent noise reduction technology with a high-sensitivity microphone work to weaken environmental noise, ensuring clear words and sentences in noisy environments.

The Sabbath M200 earphones are equipped with Environmental Noise Cancellation (ENC) technology for calls. This feature uses DSP digital noise reduction and intelligent noise reduction technology with a high-sensitivity microphone to minimize ambient noise, ensuring clear voice transmission during calls, even in noisy environments.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage.
- **Battery Care:** To prolong battery life, avoid fully discharging the earphones frequently. Charge them regularly, even if not used for extended periods.
- **Water Resistance:** The Sabbath M200 earphones are **Not Water Resistant**. Avoid exposure to water, sweat, or high humidity to prevent damage.

- **Temperature:** Do not expose the earphones to extreme temperatures (hot or cold) as this can affect battery life and performance.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing with device	Ensure earbuds are charged and in the case. Open the case lid to activate pairing mode. Turn off and on Bluetooth on your device. Forget "Sabbat M200" from your device's Bluetooth list and re-pair.
Only one earbud playing sound	Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. Ensure both earbuds are charged. Try re-pairing the earbuds with your device.
Low volume or poor sound quality	Adjust volume on both your device and the earbuds. Clean any debris from the earbud speaker mesh. Ensure a stable Bluetooth connection (within 10M range).
Charging case not charging	Check the Type-C cable and power adapter. Ensure the charging port is clean and free of debris. Try a different charging cable or power source.

SPECIFICATIONS

Feature	Detail
Model Name	Sabbat M200
Brand	iPhanmis
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	Up to 10 meters
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Active Noise Cancellation (for calls)
Sensitivity	110 dB
Impedance	32 Ohm
Talking Time	Approximately 4 hours
Charging Case Battery Life	Provides 4-5 charges to earbuds (approx. 16 hours total)

Feature	Detail
Charging Case Battery Capacity	400 Milliamp Hours
Charging Case Charging Time	Approximately 1 hour
Control Type	Media Control (Touch)
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	36.2 Grams (earbuds) / 1.28 ounces (total package)
Water Resistance Level	Not Water Resistant
Color	Blooming

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official product documentation or contact iPhanmis customer service. A digital version of this user guide is available for download at: [User Guide \(PDF\)](#). The product typically comes with a 30-day return/replacement policy. For specific terms, please check your purchase details.

© 2024 iPhanmis. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CMGJW2RW>

More documents and user manuals: <https://manuals.plus/>