



[Manuals.plus](#) /

› [HOMCOM](#) /

› [HOMCOM Fabric Accent Chair \(Model 839-877V00CG\) Instruction Manual](#)

HOMCOM 839-877V00CG

HOMCOM Fabric Accent Chair Instruction Manual

Model: 839-877V00CG

[Contents](#) [Assembly](#) [Usage](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

[Introduction](#) [Safety Information](#) [Package](#)

1. INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your HOMCOM Fabric Accent Chair, Model 839-877V00CG. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. Keep this manual for future reference.



Figure 1.1: HOMCOM Fabric Accent Chair, Dark Gray.

2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- **Assembly Required:** Ensure all parts are present and correctly assembled according to the instructions.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 330 lbs (150 kg). Overloading may cause damage or injury.
- **Indoor Use Only:** This chair is designed for indoor use. Exposure to outdoor elements may damage the fabric and frame.
- **Stable Surface:** Place the chair on a flat, stable surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- **Regular Inspection:** Periodically check all fasteners to ensure they remain tight.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are

missing or damaged, do not proceed with assembly. Contact customer support for assistance.

Typical package contents include:

- Chair Backrest
- Chair Seat
- Armrests (Left and Right)
- Legs (4 pieces)
- Hardware Pack (screws, washers, Allen wrench)

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to assemble the chair on a soft, clean surface to prevent scratching.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a protected surface. Identify each component against the package contents list.
2. **Attach Legs:** Locate the four legs and the corresponding attachment points on the underside of the chair seat. Secure each leg using the provided screws and washers. Ensure they are tightened firmly but do not overtighten. The chair features adjustable foot pads for stability on uneven floors.



Figure 4.1: Adjustable foot pad for stability.

3. **Attach Backrest:** Align the backrest with the seat and armrests. Secure it using the designated

hardware. Ensure all connections are flush and stable.

4. **Final Tightening:** Once all major components are in place, gently rock the chair to ensure stability. If stable, perform a final tightening of all screws. Avoid excessive force to prevent stripping.



Figure 4.2: Fully assembled accent chair.

5. OPERATING INSTRUCTIONS

The HOMCOM Fabric Accent Chair is designed for comfortable seating in various indoor environments such as living rooms, bedrooms, or home offices.

- **Seating:** Use the chair for sitting and relaxing. The padded seat with S-springs and breathable linen-feel fabric provides comfort.
- **Placement:** Position the chair in a desired location, ensuring it is on a level surface. Adjust the foot pads if necessary to eliminate wobbling.
- **Features:** The chair features a high back, rolled arms, and a modern design with a striped pattern on the backrest.



Figure 5.1: Key design features of the accent chair.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your accent chair.

- **Cleaning:** Wipe clean with a damp cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the fabric with a soft brush or vacuum with an upholstery attachment.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric.
- **Structural Check:** Periodically inspect the frame and legs for any signs of wear or loosening. Tighten any loose screws as needed.

7. TROUBLESHOOTING

If you encounter issues with your HOMCOM Fabric Accent Chair, refer to the following common solutions:

- **Wobbling Chair:** Ensure all legs are securely tightened. Adjust the foot pads on the bottom of each leg to level the chair on uneven surfaces.
- **Squeaking Noises:** Check all assembly points and tighten any loose screws. Apply a small amount

of lubricant to joints if necessary, ensuring it does not stain the fabric.

- **Fabric Stains:** For minor stains, use a mild fabric cleaner according to its instructions. Test on an inconspicuous area first. For stubborn stains, professional upholstery cleaning may be required.

8. SPECIFICATIONS

Feature	Detail
Brand	HOMCOM
Model Number	839-877V00CG
Color	Dark Gray
Overall Dimensions (W x D x H)	31.5" x 28.75" x 37"
Seat Dimensions (W x D x H)	18.5" x 21.25" x 18"
Backrest Height	22"
Arm Height	24.75"
Weight Capacity	330 lbs (150 kg)
Material	Fabric (Linen-feel), Foam, Plywood Frame, Rubber Wood Legs
Item Weight	30.8 lbs
Assembly Required	Yes



Figure 8.1: Dimensional overview of the accent chair.

9. WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please contact HOMCOM customer service. Refer to your purchase documentation for specific contact details or visit the official HOMCOM website. Please have your model number (839-877V00CG) and proof of purchase ready when contacting support.