

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [MAMAZING](#) /

› [MAMAZING Ultra Air Lightweight Baby Travel Stroller \(Model S66\) Instruction Manual](#)

## MAMAZING S66

# MAMAZING Ultra Air Lightweight Baby Travel Stroller (Model S66) Instruction Manual

## IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembling and using the MAMAZING Ultra Air Lightweight Baby Travel Stroller. Failure to follow these instructions could result in serious injury or death.

- **WARNING:** Never leave your child unattended in the stroller.
- **WARNING:** Always use the 5-point harness to secure your child.
- **WARNING:** Ensure the stroller is fully open and locked before placing a child in it.
- **WARNING:** Always engage the brakes when the stroller is stationary.
- **WARNING:** Do not overload the storage basket or attach items to the handle, as this may cause the stroller to become unstable.
- **WARNING:** This stroller is suitable for children aged 6 months and up, weighing up to 50 pounds (maximum height of 39.4 inches).
- **WARNING:** This product is not suitable for running or skating.
- Regularly inspect the stroller for loose parts, damaged components, or worn fabric. Discontinue use if any damage is found.

## PRODUCT OVERVIEW

The MAMAZING Ultra Air Lightweight Baby Travel Stroller (Model S66) is designed for convenience and portability. Featuring a durable carbon fiber frame, it offers a lightweight and compact solution for parents on the go. Key features include a one-handed folding mechanism, an adjustable canopy with UV protection, and a secure 5-point harness system.

## COMPONENTS LIST

The following components are included with your MAMAZING Ultra Air Stroller:

- Stroller Frame with Seat Fabric
- Canopy

- Under-Seat Storage Basket
- Bumper Bar
- Travel Bag

## SETUP AND ASSEMBLY

### Unfolding the Stroller

1. Place the folded stroller on a flat surface with the wheels facing down.
2. Locate the release button on the handlebar. Simultaneously press the button and pull the handlebar upwards.
3. Continue pulling until the stroller frame fully extends and locks into place. You should hear an audible 'click'.
4. Ensure all locking mechanisms are securely engaged before use.

Carbon Fiber Stroller Series

Over **120,000+** Units Sold Globally  
Peak Sales of **1,000** Units Per Day



● Global Market Leader

Figure 1: The MAMAZING Ultra Air Stroller in its fully unfolded and ready-to-use position.

## OPERATING INSTRUCTIONS

## Folding the Stroller (One-Handed)

1. Ensure the canopy is retracted and the seat is in an upright position.
2. Locate the primary release button on the handlebar.
3. Press the release button and simultaneously squeeze the secondary release lever on the handlebar.
4. Push the handlebar downwards, allowing the stroller to fold compactly.
5. Once fully folded, the stroller will automatically lock into its compact position.

Video demonstrating the one-handed folding and unfolding mechanism of the MAMAZING Ultra Air Stroller, along with adjustments for the canopy, recline, and storage features.

Video 1: Demonstration of the stroller's one-handed folding and unfolding, recline, and canopy adjustments.

## Fit for Every Trip

As small as a 21" carry-on suitcase



Figure 2: The one-handed folding process, showing the compact result.

## Seat Recline Adjustment

To adjust the seat recline, locate the strap and buckle mechanism on the back of the seat. Squeeze the buckle to loosen the strap and recline the seat to the desired angle. Pull the strap to bring the seat back to an upright position.

# Folds with Just One Hand



Figure 3: Visual guide to adjusting the seat recline, canopy, and footrest for optimal child comfort.

## Canopy Adjustment

The stroller features an extendable UPF 50+ canopy for sun protection. Pull the canopy forward to extend it. For additional ventilation, unzip the mesh panel located on the canopy. To retract, push the canopy back.

## Footrest Adjustment

The footrest can be adjusted for your child's comfort. Locate the buttons on either side of the footrest. Press these buttons simultaneously and adjust the footrest to the desired upward or downward position.

## 5-Point Harness System


To secure your child, place them in the seat and bring the shoulder straps over their shoulders and the waist straps around their waist. Insert the two buckle prongs into the central buckle until they click securely. To release, press the button on the central buckle.

# Keep Your Baby Comfortable

## Multi-Position Recline



## Extendable Canopy (UPF 50+)



## Adjustable Footrest



Figure 4: A child safely secured in the stroller using the 5-point harness.

## Foot-Operated Brake System

To engage the brakes, press down on the red pedal located near the rear wheels. To release the brakes, lift the green pedal upwards. Always ensure both brakes are fully engaged when the stroller is stationary.

## Safe and Secure



Figure 5: Detail of the foot-operated brake system for secure parking.

### **Storage Basket**

The stroller includes a spacious under-seat storage basket for essentials such as diaper bags, toys, and snacks. Do not exceed the recommended weight limit for the basket to maintain stroller stability.

# Ultra Air Solves Every Stroller Struggle



Too big to travel or store away



Can't sleep comfortably



Too heavy

Figure 6: The convenient under-seat storage basket.

## MAINTENANCE AND CARE

- **Cleaning:** Wipe clean with a damp cloth. For more detailed cleaning, refer to the manufacturer's instructions.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use. Use the provided travel bag for protection during transport or extended storage.
- **Wheel Maintenance:** Periodically check wheels for debris and ensure they rotate freely.
- **Fabric Care:** Avoid using harsh chemicals or abrasive cleaners on the fabric.

## TROUBLESHOOTING

- **Stroller not unfolding/folding smoothly:** Check for any obstructions in the folding mechanism. Ensure all components are aligned correctly.
- **Wheels not moving freely:** Inspect wheels for trapped debris (e.g., hair, dirt) and clean as necessary.
- **Harness not securing:** Ensure all buckle prongs are fully inserted into the central buckle until a click is heard. Adjust straps for a snug fit.

## SPECIFICATIONS

Feature	Specification
Brand	MAMAZING
Model Number	S66
Item Weight	11.6 lbs (5.22 Kilograms)
Frame Material	Carbon Fiber
Fabric Type	Polyester, Faux Leather, Cotton
Age Range (Recommended)	6 months up to 50 lbs
Maximum Height	39.4 Inches
Folded Size	H20.6 x W18.5 x D11 inch
Unfolded Dimensions (L x W x H)	26.77"L x 18.11"W x 40.55"H
Harness Type	5 Point
Brake System	Foot-operated
Safety Standards	Meets or exceeds CPSC and ASTM standards

## WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please visit the official MAMAZING website or contact our customer service team. Keep your purchase receipt for warranty claims.

**MAMAZING Customer Service:** [Visit the MAMAZING Store on Amazon](#)