



[Manuals.plus](#) /

› [BoxWave](#) /

› BoxWave AccuPoint Active Stylus User Manual for Xiaomi Pad 6

BoxWave bw-1434-40852-10305

BoxWave AccuPoint Active Stylus User Manual

Model: bw-1434-40852-10305 - Compatible with Xiaomi Pad 6

1. INTRODUCTION

Thank you for choosing the BoxWave AccuPoint Active Stylus. This electronic stylus is designed to provide a precise and natural writing experience on your Xiaomi Pad 6. It operates without the need for Bluetooth pairing, offering immediate functionality. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your stylus.



Image 1.1: The BoxWave AccuPoint Active Stylus in Metallic Silver.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- BoxWave AccuPoint Active Stylus
- MicroUSB Charging Cable

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your AccuPoint Active Stylus:



Image 3.1: Key components of the AccuPoint Active Stylus, including the built-in charging port, indicator light, 1.9mm extra fine tip, and FiberMesh tip.

- **1.9mm Extra Fine Tip:** For precise writing, drawing, and navigation.
- **FiberMesh Tip:** A secondary tip for general navigation and broader strokes.
- **Power Button / Indicator Light:** Activates the stylus and displays power status.
- **Built-in Charging Port:** MicroUSB port for recharging the internal battery.

4. SETUP

4.1 Charging the Stylus

Before first use, fully charge your stylus. The stylus has an internal battery that provides up to 12 hours of use on a full charge.

1. Locate the MicroUSB charging port on the stylus.
2. Connect the provided MicroUSB cable to the stylus's charging port.
3. Connect the other end of the MicroUSB cable to any standard USB power source (e.g., computer, wall adapter).



Conveniently Charge

Image 4.1: The stylus connected to a MicroUSB charging cable, plugged into a laptop. The indicator light will show the charging status:

- **Red Light:** Charging in progress.
- **Green Light:** Fully charged.



Image 4.2: Visual representation of the indicator light colors for power on, charging, and full charge.

4.2 Powering On/Off

- To turn on the stylus, press the power button located near the charging port. The indicator light will illuminate blue.
- To turn off the stylus, press the power button again. The indicator light will turn off.

5. OPERATING INSTRUCTIONS

5.1 Basic Usage

The AccuPoint Active Stylus does not require Bluetooth pairing. Simply turn it on and begin using it with your Xiaomi Pad 6.

1. Ensure the stylus is powered on (blue indicator light).
2. Gently touch the stylus tip to your device's screen to interact. The stylus emits electronic pulses to simulate a finger touch, allowing for natural writing and navigation.



Tap, Swipe, or Write Naturally With the AccuPoint Active Stylus

No pairing required! The AccuPoint Active Stylus emits quick electronic pulses to interact with your device's screen.


(Please note: the AccuPoint Active Stylus does not support palm rejection)

BoxWave AccuPoint Active Stylus

Image 5.1: A hand demonstrating natural writing and interaction with a tablet using the AccuPoint Active Stylus.

5.2 Tips for Use

- Use the **1.9mm Extra Fine Tip** for detailed tasks such as writing, drawing, and precise selection.
- The **FiberMesh Tip** can be used for general navigation, scrolling, and tapping.
- The stylus is designed for precise touchscreen control across various applications.



Precise touchscreen control in all your apps.

Its sleek design makes it comfortable to hold and a perfect companion.

BoxWave AccuPoint Active Stylus

Image 5.2: The stylus being used for precise touchscreen control on a smartphone, highlighting its comfortable design.

5.3 Important Considerations

- The AccuPoint Active Stylus **does not support Palm Rejection**. Avoid resting your palm on the screen while using the stylus to prevent unintended input.
- The stylus **does not support Pressure Sensitivity**. Line thickness and opacity will not vary with pressure applied.

6. MAINTENANCE

6.1 Cleaning

To maintain optimal performance and appearance:

- Wipe the stylus body with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Keep the stylus tips clean and free from debris.

6.2 Storage

When not in use, store the stylus in a safe place to prevent damage. Avoid extreme temperatures and direct sunlight.

7. TROUBLESHOOTING

If you encounter issues with your AccuPoint Active Stylus, please refer to the following common solutions:

Problem	Solution
Stylus not responding	<ul style="list-style-type: none">• Ensure the stylus is powered on (blue indicator light).• Charge the stylus fully. A low battery can affect performance.• Ensure your device's screen is clean and free of smudges.• Restart your Xiaomi Pad 6.
Indicator light not working	<ul style="list-style-type: none">• Ensure the stylus is powered on or connected to a charging source.• If the stylus is charging but the light is off, try a different MicroUSB cable or power source.
Inaccurate input	<ul style="list-style-type: none">• Ensure the stylus tip is clean.• Make sure you are not resting your palm on the screen (due to lack of palm rejection).• Restart your device.

8. SPECIFICATIONS

Detailed technical specifications for the BoxWave AccuPoint Active Stylus:




Image 8.1: Diagram illustrating key features and specifications of the AccuPoint Active Stylus.

- **Model Number:** bw-1434-40852-10305
- **Color:** Metallic Silver

- **Material:** Aluminum
- **Item Weight:** 1.3 ounces
- **Package Dimensions:** 8 x 2 x 1 inches
- **Compatible Devices:** Tablets (specifically Xiaomi Pad 6)
- **Battery:** 1 Product Specific battery (included)
- **Battery Life:** Up to 12 hours of use
- **Charging Port:** MicroUSB
- **Tip Size:** 1.9mm (Extra Fine Tip)
- **Special Features:** No pairing required, Power Indicator, Removable FiberMesh Tip
- **Limitations:** Does not support Palm Rejection or Pressure Sensitivity

9. WARRANTY AND SUPPORT

For warranty information or technical assistance, please contact BoxWave customer support. Refer to the product packaging or the official BoxWave website for contact details.

Please note that this product includes limited 3rd party tech support for your device (up to 3 inquiries via messaging) - not affiliated with or endorsed by Xiaomi.