watnature Blue 38.7inch

watnature 38.7"H Outdoor Water Fountains and Waterfalls User Manual

Model: Blue 38.7inch
Brand: watnature

Product Overview

The watnature 38.7"H Outdoor Water Fountain is designed to enhance both indoor and outdoor spaces with its modern jar design and integrated LED lights. Constructed from durable resin and fiberglass, it offers long-lasting beauty and stability. The fountain features a circulating water system and an adjustable pump to control water flow and prevent splashing.



Figure 1: The watnature 38.7"H Outdoor Water Fountain, showcasing its modern jar design and integrated LED lighting.

Components

The watnature water fountain comes as a complete kit, including the main fountain unit, an electric water pump, and integrated LED lights. All necessary components for operation are provided.

- Fountain Unit (Blue 38.7inch)
- Electric Water Pump (adjustable speed)
- Integrated LED Lights
- Power Cord

Setup Instructions

1. **Unpack Components:** Carefully remove all items from the packaging and inspect for any damage.
2. **Position the Fountain:** Place the fountain on a stable, level surface in your desired indoor or outdoor location.

Ensure it is near a standard electrical outlet.

3. **Connect Pump and Lights:** Follow the partial installation instructions provided to connect the water pump and LED lights to their designated points within the fountain.
4. **Add Water:** Fill the fountain reservoir with clean water. Ensure the water level is sufficient to fully submerse the pump.
5. **Adjust Water Speed:** Before plugging in, it is recommended to set the pump's adjustable water speed to approximately halfway open to prevent excessive splashing.
6. **Power On:** Plug the power cord into a standard electrical outlet. The pump will begin circulating water, and the LED lights will illuminate.




Figure 2: Product dimensions for placement planning.

Operating Instructions

Once set up, the watnature fountain operates continuously when plugged in. The adjustable water pump allows for customization of the water flow.

- **Adjusting Water Flow:** The water pump features an adjustable control. Turn the dial or lever on the pump to increase or decrease the water flow intensity. Adjust as needed to achieve your preferred sound and to minimize splashing, especially when used indoors.
- **Sound:** The fountain is designed to produce a soothing trickling sound. If the sound is too loud or too quiet, adjust the water flow.
- **Lighting:** The integrated LED lights automatically illuminate when the fountain is powered on, enhancing the visual appeal, particularly in low-light conditions.



Figure 3: The fountain integrated into an outdoor garden environment.

Official Product Video

Your browser does not support the video tag.

Video 1: A demonstration of the Indoor Water Jar Fountain with LED Light and Pump, showcasing its operation and visual appeal.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your watnature fountain.

- **Water Level:** Periodically check the water level and refill as needed to ensure the pump remains fully submerged. This prevents the pump from running dry, which can cause damage.
- **Cleaning:** Clean the fountain and pump regularly to prevent mineral buildup and algae growth. Disconnect from power before cleaning. Use a soft cloth and mild soap for the fountain surface. For the pump, follow the manufacturer's instructions for cleaning its filter and impeller.
- **Winterization (Outdoor Use):** If used outdoors in freezing temperatures, drain all water from the fountain and pump. Store the pump indoors in a dry, frost-free location. Cover the fountain or store it indoors to protect it from harsh weather.

Troubleshooting

If you encounter issues with your fountain, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fountain not running / Pump not working	• Not plugged in or power outage. • Insufficient water level. • Pump clogged or damaged.	• Check power connection and outlet. • Add water to cover the pump. • Disconnect power, clean pump impeller and intake. If still not working, pump may need replacement.
Excessive splashing	• Water flow too high. • Fountain not level.	• Adjust the pump's flow control to a lower setting. • Ensure the fountain is on a completely level surface.
Lights not working	• Loose connection. • LED bulb failure.	• Check all light connections. • Contact customer support for replacement parts if bulbs are not user-replaceable.

Specifications

Feature	Detail
Brand	watnature
Model	Blue 38.7inch
Color	Blue
Material	Fiberglass, Resin
Product Dimensions (L x W x H)	13.5" x 11.4" x 38.7"
Power Source	Corded Electric
Special Features	Fade Resistant, Lighted, Weather Resistant, UV Resistant, Rust Resistant

Warranty and Support

This product is subject to a 30-day return policy. For specific warranty details or support inquiries, please refer to the

purchase documentation or contact the seller directly through the platform where the product was purchased. You may also visit the official watnature store for additional information.

watnature Store: Visit Store

© 2024 watnature. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question