Fafeicy SZ06

Fafeicy SZ06 Digital Multimeter User Manual

Model: SZ06

Introduction Safety Contents Overview Setup Operation Maintenance Troubleshooting Specifications

1. Introduction

This manual provides instructions for the safe and effective use of the Fafeicy SZ06 Digital Multimeter. This device is designed for measuring various electrical parameters including current, voltage, and resistance. It features a high-definition backlit display for clear readings and an automatic shutdown function to conserve battery life.

2. Safety Information

Please read all safety warnings and operating instructions before using this product. Failure to do so may result in electric shock, fire, or injury.

- Always ensure the test leads are properly connected and the function switch is set to the correct range before making any measurements.
- Do not attempt to measure voltages or currents exceeding the maximum specified limits of the device.
- Exercise caution when working with live circuits. High voltages can be dangerous.
- Before opening the battery compartment or replacing fuses, disconnect the test leads from the circuit and turn off the multimeter.
- Do not use the multimeter if it appears damaged or if the test leads are frayed or broken.
- The device includes built-in overload protection. However, always operate within specified ranges to prevent damage.



Image: The Fafeicy SZ06 Digital Multimeter, highlighting its high accuracy and anti-burn protection features, indicating enhanced safety during operation.

3. Package Contents

Verify that all items are present and undamaged upon opening the package:

- 1 x Fafeicy SZ06 Digital Multimeter
- 2 x Test Pens (Red and Black Test Leads)

Note: 1.5V AAA batteries (x2) are required for operation and are not included in the package.



Image: The Fafeicy SZ06 Digital Multimeter shown alongside its red and black test leads, representing the complete package contents.

4. Product Overview

The Fafeicy SZ06 Digital Multimeter is a compact and portable device designed for electrical measurements. Key features include:

- **HD Backlit Display:** Provides clear visibility of readings in various lighting conditions.
- **Rotary Function Switch:** Allows selection of different measurement modes.
- **Input Jacks:** For connecting test leads.
- **90° Support Stand:** Integrated stand for convenient hands-free operation.
- **Automatic Shutdown:** Powers off after 15 minutes of inactivity to save battery.



Image: An angled view of the Fafeicy SZ06 Digital Multimeter with its integrated 90-degree support stand extended, demonstrating its hands-free capability.

5. Setup

5.1 Battery Installation

1. Ensure the multimeter is turned off and disconnect any test leads.
2. Locate the battery compartment cover on the back of the device.
3. Use a screwdriver to remove the screw securing the battery cover.
4. Insert two 1.5V AAA batteries, observing the correct polarity (+/-) as indicated inside the compartment.
5. Replace the battery compartment cover and secure it with the screw.



Image: The rear view of the Fafeicy SZ06 Digital Multimeter, showing the battery compartment cover and a safety warning regarding fuse replacement.

5.2 Connecting Test Leads

- Insert the black test lead into the 'COM' (common) jack.
- For most voltage, resistance, and small current (mA) measurements, insert the red test lead into the 'VΩmA' jack.
- For large current (10A) measurements, insert the red test lead into the '10A' jack.



Image: A close-up view of the input jacks on the Fafeicy SZ06 Digital Multimeter, clearly showing the 'COM', 'VΩmA', and '10A' ports for test lead connection.

6. Operating Instructions

Before taking any measurement, ensure the test leads are correctly connected and the rotary switch is set to the desired function and range.



Image: A detailed close-up of the rotary function switch on the Fafeicy SZ06 Digital Multimeter, showing various measurement settings.

6.1 Measuring DC Voltage (V–)

1. Set the rotary switch to the desired DC Voltage (V–) range. If the voltage is unknown, start with the highest range and decrease as needed.
2. Connect the red test lead to the positive (+) side of the circuit and the black test lead to the negative (-) side.
3. Read the voltage value on the display.

6.2 Measuring AC Voltage (V~)

1. Set the rotary switch to the desired AC Voltage (V~) range.
2. Connect the test leads across the AC voltage source.
3. Read the voltage value on the display.

6.3 Measuring DC Current (A–)

1. **Important:** To measure current, the multimeter must be connected in series with the circuit.
2. Set the rotary switch to the appropriate DC Current (A–) range (e.g., mA or 10A).
3. If measuring 10A, move the red test lead to the '10A' jack. For mA, keep it in 'VΩmA'.
4. Open the circuit where you want to measure current. Connect the multimeter in series, ensuring the current flows through the multimeter.
5. Read the current value on the display.

6.4 Measuring Resistance (Ω)

1. Ensure the circuit is de-energized before measuring resistance.
2. Set the rotary switch to the desired Resistance (Ω) range.
3. Connect the test leads across the component or circuit segment to be measured.
4. Read the resistance value on the display.

6.5 Backlight Function

Press the backlight button (often indicated by a light bulb icon) to illuminate the display for better visibility in low-light conditions. Press it again to turn off the backlight.

6.6 Data Hold Function

Press the 'HOLD' button to freeze the current reading on the display. Press it again to release the hold function and resume live readings.



Image: The Fafeicy SZ06 Digital Multimeter in use, with its test leads connected to a car battery to measure voltage, demonstrating a practical application.

7. Maintenance

7.1 Cleaning

Wipe the multimeter casing with a damp cloth. Do not use abrasive cleaners or solvents. Ensure the device is dry before use.

7.2 Battery Replacement

When the battery indicator appears on the display, replace the batteries as described in the 'Battery Installation' section (5.1).

7.3 Fuse Replacement

If the current measurement function stops working, the fuse may need replacement. Refer to the warning label on the back of the device for the correct fuse rating (e.g., F200mA/250V). Disconnect all test leads and turn off the multimeter before opening the case to replace the fuse.

7.4 Storage

Store the multimeter in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, remove the batteries to prevent leakage.

8. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim	Low batteries or no batteries installed.	Replace batteries (refer to section 5.1).
No reading for current measurement	Blown fuse or incorrect test lead connection.	Check and replace fuse (refer to section 7.3). Ensure red lead is in '10A' or 'VΩmA' jack as appropriate and connected in series.
Incorrect readings	Incorrect function/range selected or poor test lead contact.	Verify function switch setting and range. Ensure test leads make firm contact with the circuit.
Multimeter automatically shuts off	Automatic shutdown feature activated.	This is normal behavior after 15 minutes of inactivity. Turn the rotary switch to 'OFF' and then back to the desired function to restart.

9. Specifications

- **Model:** SZ06
- **Material:** ABS
- **Power:** 2 x 1.5V AAA batteries (not included)
- **Display:** HD Backlit Digital Display
- **Features:** Overload Protection, Automatic Shutdown (15 minutes), Data Hold, Backlight
- **Dimensions:** Approximately 5.91 x 3.94 x 1.57 inches (Package Dimensions)

10. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Fafeicy customer service through the retailer where the product was purchased.

© 2025 Fafeicy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question