

[Manuals.plus](#) /

> [SONGMICS](#) /

> SONGMICS HSR152B01 Double Bar Coat Rack Instruction Manual

SONGMICS HSR152B01

SONGMICS HSR152B01 Double Bar Coat Rack Instruction Manual

Model: HSR152B01 | Brand: SONGMICS

1. INTRODUCTION

Thank you for choosing the SONGMICS HSR152B01 Double Bar Coat Rack. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new garment rack. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. SAFETY INSTRUCTIONS

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Do not exceed the maximum load capacities: 40 kg per hanging bar, 20 kg for the bottom shelf, and a total maximum load of 100 kg for the entire unit. Overloading can cause damage or injury.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- Place the coat rack on a level, stable surface to prevent tipping.
- Regularly check all connections and tighten screws as needed to maintain stability.

3. PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

Part	Description	Quantity
A	Top Hanging Bar	1
B	Lower Hanging Bar	1

Part	Description	Quantity
C	Vertical Support Poles (Long)	2
D	Vertical Support Poles (Short)	2
E	Base Frame Tubes	2
F	Side Support Bars	2
G	Bottom Shelf Board	1
H	Casters with Brakes	2
I	Casters without Brakes	2
J	Screws / Fasteners	Assorted
K	Allen Key	1
L	Spanner	1

4. SETUP AND ASSEMBLY

Follow these steps to assemble your SONGMICS HSR152B01 Coat Rack. It is recommended to have a second person for easier assembly, though it can be done by one person.

Step 4.1: Assemble the Base Frame

1. Attach the two casters with brakes (H) and two casters without brakes (I) to the ends of the base frame tubes (E). Ensure the brakes are unlocked during attachment.
2. Connect the base frame tubes (E) using the appropriate connectors and screws (J).



Image: Detail of the bottom shelf and casters, highlighting the 360° swivel and brake function.

Step 4.2: Install the Bottom Shelf

1. Place the bottom shelf board (G) onto the assembled base frame. Secure it using the designated screws (J).



Image: The bottom shelf, demonstrating its 35 cm depth and ease of cleaning.

Step 4.3: Attach Vertical Supports

1. Insert the long vertical support poles (C) into the designated slots on the base frame.
2. Attach the short vertical support poles (D) to the long poles (C) using the provided connectors and screws (J). Ensure all connections are firm.




Image: Illustration of tube connection method and tube diameter.

Step 4.4: Install Hanging Bars and Side Supports

1. Attach the lower hanging bar (B) to the short vertical support poles (D).
2. Attach the top hanging bar (A) to the long vertical support poles (C).
3. Secure the side support bars (F) between the vertical poles to enhance stability.




Image: The fully assembled SONGMICS HSR152B01 Double Bar Coat Rack.

SONGMICS

by SONGMICS HOME



Image: The coat rack in use, showcasing its storage capacity for clothes and accessories.

5. OPERATING INSTRUCTIONS

5.1: Utilizing the Hanging Bars

The coat rack features two robust hanging bars, providing ample space for various garments. The top bar is ideal for longer items like coats and dresses, while the lower bar is perfect for shirts, jackets, and pants. Ensure weight is distributed evenly and does not exceed 40 kg per bar.



Image: Demonstrating the 35 cm gap between the two hanging bars, allowing for easy access and organization.

5.2: Using the Bottom Shelf

The rustic brown bottom shelf provides additional storage for shoes, storage boxes, or bags. The shelf has a maximum load capacity of 20 kg. Utilize this space to keep your floor clear and organized.

5.3: Mobility and Stability

Equipped with four 360° swivel casters, this coat rack can be easily moved. Two of the casters include brakes. To lock the rack in place, press down on the brake levers on the two braked casters. To move the rack, release the brakes.



Image: Visual representation of the load capacities for the hanging bars and bottom shelf.

6. MAINTENANCE

To ensure the longevity and appearance of your coat rack, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the steel frame and shelf with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten any loose fasteners to maintain stability.

- **Caster Care:** Keep the casters free of dust and debris to ensure smooth movement.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Loose screws or uneven surface.	Ensure all screws are tightened securely. Move the rack to a flat, level surface.
Casters do not roll smoothly.	Brakes are engaged or debris in casters.	Check if the caster brakes are disengaged. Clean any hair or debris from the caster wheels.
Parts do not fit together.	Incorrect orientation or manufacturing defect.	Review the assembly steps and diagrams carefully. If parts still do not fit, contact customer support.
Rack tips over when loaded.	Overloaded or uneven weight distribution.	Do not exceed maximum load capacities. Distribute weight evenly across both bars and the shelf.

8. SPECIFICATIONS



Image: Overall dimensions and total load capacity of the coat rack.

Feature	Detail
Brand	SONGMICS
Model Number	HSR152B01 / 0194343151434
Color	Rustic Brown + Black Ink

Feature	Detail
Material	Alloy Steel Frame, Engineered Wood Shelf
Product Dimensions (L x W x H)	98.5 cm x 39.6 cm x 156.8 cm (38.78"D x 15.59"W x 61.65"H)
Item Weight	7.5 kg (16.5 pounds)
Max. Load Capacity (Each Bar)	40 kg (88 lbs)
Max. Load Capacity (Bottom Shelf)	20 kg (44 lbs)
Total Max. Load Capacity	100 kg (220 lbs)
Installation Type	Free Standing
Assembly Required	Yes
Special Feature	360° Swivel Casters (2 with brakes)

9. WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your SONGMICS HSR152B01 Coat Rack, please contact SONGMICS customer support. Refer to your purchase documentation for specific warranty details and contact information.

You can also visit the official SONGMICS store for more information and support: [SONGMICS Store on Amazon](#)