Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AODK B0CMQDKWR4

AODK L-Shaped Desk User Manual

Model: B0CMQDKWR4

Introduction

Thank you for choosing the AODK L-Shaped Desk. This versatile desk is designed to optimize your workspace, offering ample storage, integrated power solutions, and a durable construction. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk.

Product Features

- **Optimized Storage Space:** Features four spacious fabric drawers and two sturdy iron hooks, maximizing organization for documents, stationery, and personal items. The design keeps your workspace clutter-free, with a large surface area for your printer, scanner, and other peripherals.
- **Integrated Power Outlets and USB Ports:** Equipped with a built-in power strip including 3 AC outlets and 2 USB ports (5V/2A). This simplifies device charging, ensuring convenience and safety for gaming or intense work sessions without extra extension cords.
- **Reversible Design with Host Stand:** The corner desk includes a host stand for convenient PC placement, freeing up under-desk space. Its reversible design allows for flexible configuration to fit your room layout.
- **Durable and Sturdy Construction:** Constructed from waterproof and durable desk boards that resist deformation and cracking. The lightweight iron frame offers high strength and long-lasting durability. Adjustable pads provide comfortable height and stability on uneven floors.



Image: The AODK L-Shaped Desk configured for a multi-monitor setup, showcasing its spacious design and integrated storage.

AODK

Reversible Design

Product Size



Image: Detailed diagram illustrating the dimensions of the AODK L-Shaped Desk and its reversible design capability.



Image: Close-up view of the four large capacity fabric drawers, highlighting their smooth sliding mechanism for easy access.



Image: Detail of the integrated power strip on the desk surface, showing 3 AC outlets and 2 USB charging ports in use.

Setup and Assembly

The AODK L-Shaped Desk is designed for straightforward assembly. All necessary tools and clearly labeled parts are included in the package. Follow the step-by-step instructions provided in the assembly guide that accompanies your product.

Important Tips:

- Before starting, lay out all parts and verify against the parts list in the assembly guide.
- While the provided tools are sufficient, having a personal set of tools, such as a socket wrench (10mm recommended) or an electric ratchet with an Allen head, can significantly expedite the assembly process.
- Pay close attention to the orientation of parts, especially when assembling the reversible sections. The manual provides instructions for both left (L#) and right (R#) configurations. Ensure you are following the correct sequence for your desired desk orientation.
- It is recommended to assemble the desk with assistance from another person for easier handling of larger components.

Operating Instructions

Using the Integrated Power Outlets and USB Ports

The desk features a built-in power strip for convenient charging. Simply plug the desk's power cord into a standard wall

outlet. You can then use the 3 AC outlets for laptops, monitors, or other electronics, and the 2 USB ports for charging mobile phones, tablets, or other USB-powered devices.

- Ensure the power cord is securely plugged into both the desk unit and the wall outlet.
- Avoid overloading the power strip. Refer to the power strip's specifications for maximum wattage.

Utilizing Storage Features

- **Fabric Drawers:** The four fabric drawers are ideal for organizing documents, office supplies, and personal items. They slide smoothly for easy access.
- **Host Stand:** Place your computer tower on the designated host stand to keep it off the floor and free up desk space.
- **Headphone Hooks:** Use the two iron hooks located on the side of the desk to hang your headphones, keeping them easily accessible and preventing clutter.

Maintenance

To ensure the longevity and appearance of your AODK L-Shaped Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish. For spills, clean immediately to prevent staining.
- **Drawer Care:** The fabric drawers can be spot cleaned with a mild detergent and water. Allow them to air dry completely before reinserting.
- **Stability Check:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain desk stability.
- **Adjustable Pads:** Ensure the adjustable foot pads are properly set to keep the desk level and stable on uneven floors.

Troubleshooting

This section addresses common issues you might encounter with your AODK L-Shaped Desk.

Assembly Challenges

- **Difficulty with Wrench:** The provided wrench may not offer sufficient grip for all fasteners. Using a standard 10mm socket wrench or an electric ratchet can greatly ease the tightening of bolts.
- **Confusing Reversible Instructions:** Some users have noted that the "L#" and "R#" labels in the assembly manual for the reversible design might be counter-intuitive (e.g., L# instructions leading to a right-side drawer configuration). If you find the assembly not matching your desired orientation, double-check the diagrams carefully or consider reversing the L#/R# instructions if necessary. Always refer to the visual diagrams to confirm part orientation.
- **Missing or Damaged Parts:** If any parts are missing or damaged upon unboxing, do not proceed with assembly. Contact AODK customer support immediately for assistance.

Stability Issues

- **Wobbling Desk:** Ensure all screws and bolts are fully tightened. Adjust the leveling foot pads at the bottom of the desk legs to compensate for uneven floor surfaces.

Power Outlets Not Working

- **No Power:** Check if the desk's main power cord is securely plugged into both the desk unit and a functioning wall outlet. Test the wall outlet with another device to ensure it has power.
- **Overload:** If too many high-power devices are connected, the power strip's circuit breaker might trip. Unplug some

devices and reset the power strip if it has a reset button.

Specifications

Feature	Detail
Brand	AODK
Model	B0CMQDKWR4
Color	Grey Oak
Product Dimensions (L x W x H)	155 cm x 137.2 cm x 75 cm (approx. 61 x 54 x 29.5 inches)
Material	Engineered Wood (Desk Boards), Metal (Frame)
Item Weight	21 Kilograms (approx. 46.3 lbs)
Number of Drawers	4 (Fabric)
Power Outlets	3 AC Outlets (120V/12A)
USB Charging Ports	2 USB Ports (5V/2A)
Recommended Uses	Gaming, Work, Home Office

Warranty and Support

AODK is committed to providing high-quality products and excellent customer service. For any questions, concerns, or issues regarding your L-Shaped Desk, please refer to the contact information provided with your purchase or visit the official AODK website for support.
Please retain your proof of purchase for warranty claims. The professional after-sales team aims to respond to messages within 24 hours to ensure customer satisfaction.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMQDKWR4

More documents and user manuals: **https://manuals.plus/**