

[Manuals.plus](#) /

› [HCK](#) /

› HCK 115L Wine Cooler Refrigerator User Manual

HCK SC-130B-E-220-AU

HCK 115L Wine Cooler Refrigerator User Manual

Model: SC-130B-E-220-AU

Brand: HCK

1. INTRODUCTION

Thank you for choosing the HCK 115L Wine Cooler Refrigerator. This appliance is designed to provide optimal storage conditions for your wine collection, ensuring your wines are preserved at their ideal temperature and humidity. Please read this manual thoroughly before operating your new wine cooler to ensure safe and efficient use. Keep this manual for future reference.



Image: Front view of the HCK 115L Wine Cooler Refrigerator, showcasing its sleek black design and the interior filled with wine bottles.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your wine cooler, follow these basic precautions:

- Read all instructions before using the appliance.
- Ensure the appliance is connected to a properly grounded electrical outlet.
- Do not operate the appliance if the power cord or plug is damaged.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the wine cooler before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PRODUCT FEATURES

The HCK 115L Wine Cooler Refrigerator is equipped with advanced features to ensure optimal wine preservation:

- **Elegant Design:** Stylish black finish with silver accents and retro door hinges, complementing any room decor.
- **Large Capacity:** 115L capacity, capable of storing up to 48 Bordeaux wine bottles on 5 adjustable shelves.
- **Touchscreen Control:** Simple electronic temperature adjustment from 4°C to 22°C (39°F to 72°F) for precise climate control.
- **Triple-Layer Glass Door:** Features a frost-free, 3-layer glass door with low-E film to prevent condensation, stabilize temperature, and protect wine from harmful UV light.
- **Humidity Control:** Integrated technology maintains humidity levels between 50% and 75% for optimal cork and wine preservation.
- **Low Noise Level:** Operates quietly at approximately 39dB.
- **HIPS Antibacterial Inner Tank:** Ensures a hygienic storage environment.




Image: Overview of the wine cooler's key features, including 115L capacity, 4-22°C temperature range, 50-70% humidity, antibacterial inner tank, smart touch panel, and low noise level.



Image: The wine cooler with its door open, demonstrating its capacity to store up to 48 wine bottles, alongside a single bottle and wine glass for scale.



Image: A diagram illustrating the three layers of the wine cooler's glass door, highlighting the tempered glass and low-E film for light blocking and insulation.

4. SETUP AND INSTALLATION

Proper setup is crucial for the performance and longevity of your wine cooler.

4.1 Unpacking

- Remove all packaging materials, including foam and adhesive tape.
- Inspect the appliance for any damage. Report any damage to your retailer immediately.
- Keep packaging materials out of reach of children.

4.2 Placement

- Place the wine cooler on a flat, stable surface strong enough to support its weight when fully loaded.
- Ensure adequate air circulation around the appliance. Allow at least 10 cm (4 inches) of space at the back and sides, and 30 cm (12 inches) at the top.
- Avoid placing the unit in direct sunlight or near heat sources (e.g., oven, radiator).
- Do not install in areas with extreme cold or heat, or excessive humidity.



Image: The HCK wine cooler with its dimensions indicated: 845mm height, 548mm width, and 540mm depth, providing guidance for placement.

4.3 Electrical Connection

- Before plugging in, allow the appliance to stand upright for at least 2-4 hours. This allows the refrigerant to settle.
- Connect the wine cooler to a dedicated, grounded electrical outlet with the correct voltage (220-240V AC, 50Hz).
- Do not use extension cords or ungrounded adapters.

5. OPERATING INSTRUCTIONS

Operating your HCK wine cooler is straightforward with its intuitive touchscreen control panel.

5.1 Control Panel Overview

The control panel is located on the top front of the appliance and features touch-sensitive buttons for temperature adjustment and light control.



Image: Close-up of the smart temperature control panel, showing the digital display and touch buttons for adjusting temperature and controlling the interior light. Various wine types are shown with recommended serving temperatures.

5.2 Setting the Temperature

- Press the **Temperature Up (+)** or **Temperature Down (-)** buttons to adjust the desired temperature.
- The temperature range is 4°C to 22°C (39°F to 72°F).
- The display will show the set temperature, then revert to the actual internal temperature after a few seconds.

5.3 Interior Light

- Press the **Light** () button to turn the interior LED light on or off.

5.4 Loading Wine Bottles

- Arrange bottles on the adjustable shelves, ensuring proper air circulation.
- Avoid overloading shelves to prevent damage and ensure efficient cooling.

6. MAINTENANCE AND CARE

Regular maintenance helps ensure your wine cooler operates efficiently and extends its lifespan.

6.1 Cleaning the Interior

- Always unplug the appliance before cleaning.
- Clean the interior with a soft cloth dampened with a solution of lukewarm water and mild detergent.
- Do not use abrasive cleaners or solvents.
- Remove and clean the shelves as needed. Ensure they are completely dry before placing them back.



Image: A close-up view of the interior shelves of the wine cooler, showing their wire construction and how they slide out for easy access and cleaning.



Image: A close-up view of the interior LED light strip located at the top of the wine cooler, providing illumination for the stored bottles.

6.2 Cleaning the Exterior

- Wipe the exterior with a soft, damp cloth.
- For stubborn stains, use a mild, non-abrasive cleaner.
- Clean the door gasket regularly to ensure a proper seal.

6.3 Power Outage

- In case of a power outage, keep the door closed to maintain the internal temperature for as long as possible.
- Avoid opening the door unnecessarily.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following troubleshooting guide for common issues:

Problem	Possible Cause & Solution
Appliance does not operate.	• Not plugged in. Ensure the power plug is fully inserted into the outlet. • A circuit breaker has tripped or a fuse has blown. Check the household circuit breaker/fuse box. • Power switch is off. Ensure the power switch (if applicable) is in the ON position.
Temperature is not cold enough.	• Temperature setting is too high. Adjust to a lower temperature. • Door is not closed properly. Ensure the door is fully closed and sealed. • Frequent door openings. Minimize door openings. • Poor ventilation. Ensure adequate space around the unit for air circulation. • Excessive ambient temperature. The unit may struggle in very hot environments.
Vibrations.	• Appliance is not level. Adjust the leveling feet. • Unit is touching a wall or other object. Move the unit slightly away.
Noise.	• Normal operating sounds: The refrigerant circulating, fan motor, and compressor may produce sounds. • Loose parts. Check for any loose components inside or outside the unit.
Moisture builds up on the exterior.	• High humidity environment. This is normal in very humid conditions. Wipe dry. • Door not sealed properly. Check the door gasket for damage or obstructions.

8. SPECIFICATIONS

Specification	Detail
Brand	HCK
Model Name	SC-130B-E-220-AU
Installation Method	Freestanding
Form Factor	Wine Cellar
Capacity	115 Litres (approx. 48 Bordeaux bottles)
Temperature Range	4-22°C (39-72°F)
Humidity Control	50-75%
Item Height	84.5 centimetres
Item Width	54 centimetres
Item Length (Depth)	54 centimetres
Item Weight	32 Kilograms
Colour	Black
Special Feature	Electronic Temperature Control, Triple-Layer Glass Door

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. HCK is committed to providing quality products and customer satisfaction.

For technical support or service inquiries, please visit the official HCK website or contact their customer service department using the contact information provided in your purchase materials.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question