

**CIAO TECH CPBTI01-035**

# CIAO TECH Portable Charger Power Bank User Manual

Model: CPBTI01-035

## INTRODUCTION

Thank you for choosing the CIAO TECH Portable Charger Power Bank. This device is designed to provide reliable and efficient power for your electronic devices on the go. With its high-capacity battery and versatile charging options, you can stay connected wherever you are.





Image: The CIAO TECH Portable Charger Power Bank, a sleek black device with an LED display indicating charge levels (25, 50, 75, 100).

## PRODUCT FEATURES

---

- **High Capacity:** Equipped with a 20000 mAh battery, capable of charging multiple devices.
- **Dual USB Outputs:** Provides two USB-A outputs, each delivering DC5V 2.1A for efficient charging.
- **Flexible Inputs:** Features both Type-C and Micro USB inputs (DC5V 2A) for convenient recharging of the power bank.
- **LED Display:** A user-friendly LED screen displays the remaining battery percentage, allowing for easy monitoring of the charging status.
- **Integrated Flashlight:** Includes a utility flashlight for added convenience.
- **Compact and Portable Design:** Slim and durable, designed for easy portability and travel.

# POCKET-SIZED POWERHOUSE



Image: A diagram illustrating the compact dimensions (2.65 in x 5.4 in x 1.1 in) and port locations (Micro USB, Type-C, Dual USB Outputs DC5V 2.1A) of the power bank.

## SETUP

### Initial Charging of the Power Bank

Before first use, it is recommended to fully charge your CIAO TECH Portable Charger Power Bank. This ensures optimal performance and battery longevity.

1. Connect a compatible USB cable (Type-C or Micro USB) to the corresponding input port on the power bank.
2. Plug the other end of the USB cable into a USB wall adapter (not included) or a computer's USB port.
3. The LED display will illuminate, showing the charging progress. The numbers (25, 50, 75, 100) will light up sequentially as the power bank charges.
4. Once the display shows "100", the power bank is fully charged and ready for use. Disconnect the charging cable.

# FUEL YOUR POWER BANK QUICKLY FOR NON-STOP CONNECTIVITY



Type C Charger Not Included



Image: The power bank connected to a wall adapter via a USB cable, illustrating the recharging process. Note: Type-C charger not included.

## OPERATING INSTRUCTIONS

### Charging Your Devices

The power bank features dual USB-A output ports for charging your electronic devices.

1. Connect your device's USB charging cable to one of the USB-A output ports on the power bank.
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The LED display will show the current charge level of the power bank.
4. You can charge two devices simultaneously using both USB-A output ports.



On the Go  
Design

## JOURNEY-READY JUICE BUILT FOR THE ROAD



Travel  
Friendly



Sleek  
Design

Easy to  
Carry



CIAO TECH

Image: A person charging a smartphone with the power bank, demonstrating its portability and "on-the-go" design.

### Using the Flashlight

The power bank includes a built-in utility flashlight.

- To turn on the flashlight, press and hold the power button located on the side of the power bank for approximately 3 seconds.
- To turn off the flashlight, press and hold the power button again for approximately 3 seconds.

### MAINTENANCE

Proper maintenance will extend the lifespan of your power bank.

- Keep the power bank away from extreme temperatures (hot or cold) and direct sunlight.
- Avoid dropping or subjecting the power bank to strong impacts.
- Do not expose the power bank to water or excessive moisture.
- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- If storing for an extended period, charge the power bank to approximately 50-75% capacity and recharge every 3-6 months to prevent deep discharge.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable not properly connected; faulty cable; wall adapter issue; power bank fully discharged.	Ensure cables are securely connected. Try a different charging cable or wall adapter. Allow the power bank to charge for a few minutes, even if the display doesn't immediately light up.
Device not charging from power bank	Power bank is out of charge; device cable is faulty; device is not compatible; power bank is in flashlight mode.	Recharge the power bank. Try a different charging cable. Ensure your device is compatible with standard USB charging. Turn off the flashlight if it is on.
Flashlight not turning on/off	Incorrect button press; power bank is out of charge.	Press and hold the power button for approximately 3 seconds. Recharge the power bank.
Slow charging speed	Using a non-fast charging cable/adapter; charging multiple devices; device's charging input limit.	Ensure you are using appropriate cables and adapters. Charging two devices simultaneously may reduce individual charging speeds.

## SPECIFICATIONS

Feature	Detail
Model Number	CPBTI01-035
Battery Capacity	20000 mAh
Type-C Input	DC5V 2.0A
Micro USB Input	DC5V 2.0A
USB A Output	DC5V 2.1A (Max)
Type-C Output	DC5V 2.1A (Max)
Product Dimensions	2.65 x 5.4 x 1.1 inches
Item Weight	13.1 ounces
Color	Black
Special Features	LED Indicator Lights, Utility Flashlight



## WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the warranty card included with your purchase or contact the manufacturer directly. Keep your proof of purchase for any warranty claims.

For technical support or further inquiries, please visit the official CIAO TECH website or contact their customer service department. Contact details are typically provided on the product packaging or the manufacturer's website.

© 2023 CIAO TECH. All rights reserved.

## Related Documents - CPBTI01-035

	<p><a href="#">Outdoor Tech Kodiak Plus 2.0 Portable Rugged Power Bank User Manual</a></p> <p>User manual and specifications for the Outdoor Tech Kodiak Plus 2.0 portable rugged power bank, featuring 10,000 mAh capacity, flashlight, waterproof design, and dual USB output ports.</p>
	<p><a href="#">Outdoor Tech Kodiak 2.0 Portable Rugged Power Bank User Manual &amp; Specifications</a></p> <p>User manual and specifications for the Outdoor Tech Kodiak 2.0 Portable Rugged Power Bank. Learn about its features, charging, maintenance, and technical details.</p>
	<p><a href="#">Outdoor Tech Buckshot Pro: All-in-One Wireless Speaker, Powerbank, and Flashlight User Manual</a></p> <p>Comprehensive user manual for the Outdoor Tech Buckshot Pro, an all-in-one wireless speaker, powerbank, and flashlight. Learn about its features, anatomy, attachment, functions, charging, pairing, specifications, and care.</p>
	<p><a href="#">Outdoor Tech Kodiak Mini 2.0 Portable Rugged Power Bank User Manual</a></p> <p>User manual for the Outdoor Tech Kodiak Mini 2.0 portable rugged power bank, detailing its anatomy, charging instructions, features like waterproofing and flashlight, care and maintenance guidelines, and technical specifications.</p>

	<p><a href="#"><u>Touratech ZEGA Pro Luggage System for BMW R1300GS Installation Guide</u></a></p> <p>Detailed installation instructions for the Touratech ZEGA Pro Luggage System (01-035-5700/5710/5720-0) with stainless steel carrier for the BMW R1300GS motorcycle. Includes general safety advice, torque specifications, and step-by-step visual guides.</p>
	<p><a href="#"><u>FUTECH MULTICROSS 3D/4D Línuleysir Notendahandbók</u></a></p> <p>Notendahandbók fyrir FUTECH MULTICROSS 3D og 4D línuleysitæki. Inniheldur upplýsingar um notkun, öryggi, tæknilýsingar og viðhald.</p>