

[Manuals.plus](#) /

› [TOZO](#) /

› TOZO Golden X1 Wireless Earbuds User Manual

TOZO Golden X1

TOZO Golden X1 Wireless Earbuds User Manual

Model: Golden X1

INTRODUCTION

Thank you for choosing the TOZO Golden X1 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. The Golden X1 features a hybrid dynamic driver and balanced armature driver system, LDAC HD audio-decoding, Hi-Res Audio Wireless certification, and advanced noise cancellation technology.



Image: The TOZO Golden X1 Wireless Earbuds in their charging case, showcasing the sleek design and digital display.

PACKAGE CONTENTS

Please check the package for the following items:


- TOZO Golden X1 Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Multiple sizes of Eartips (S, M, L)
- User Manual
- Quick Start Guide

PRODUCT OVERVIEW

Familiarize yourself with the components of your TOZO Golden X1 earbuds and charging case.

Balanced armature drivers and dynamic drivers

Carbon Nanotube
Diaphragm Dynamic Driver



 **knowles**

Balanced Armature Drivers

*The chip/circuit board is an effect drawing, the internal structure is not fully displayed, please refer to the actual product.

Image: An exploded diagram illustrating the internal components of the TOZO Golden X1 earbud, highlighting the Balanced Armature Drivers and Carbon Nanotube Diaphragm Dynamic Driver.

The earbuds feature a hybrid driver system for superior sound quality, combining a 12mm dynamic driver and a balanced armature driver. They are designed for an ergonomic fit and include multiple microphones for environmental noise cancellation during calls.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Connect the USB-C charging cable to the charging port on the case and a power source.
2. The LED digital display on the case will show the battery percentage.

3. Place the earbuds into the charging case. The earbuds will begin charging automatically.
4. The case supports both Type-C wired charging and wireless charging.

Ultra-Long Battery Life

Up to 32 hours of listening time

8 hrs
Single charge

32 hrs
With charging case

500 mAh
Battery capacity



Image: An illustration showing the battery life of the TOZO Golden X1: 8 hours on a single charge and up to 32 hours with the charging case, which has a 500mAh capacity.

2. Bluetooth Pairing

Pair your TOZO Golden X1 earbuds with your device for the first time.

1. Open the charging case, and the earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
3. Search for "TOZO Golden X1" in the list of available devices and select it to connect.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. The earbuds feature Bluetooth 5.3 technology for stable and instant pairing.

3. Wearing the Earbuds

For optimal sound quality and comfort, ensure a proper fit.

1. Choose the eartips that best fit your ear canals. Experiment with different sizes for the best seal.
2. Gently insert the earbuds into your ears and rotate them slightly until they feel secure and comfortable.
3. A good seal is crucial for effective noise cancellation and bass response.

OPERATING INSTRUCTIONS

Touch Controls

The TOZO Golden X1 earbuds feature intuitive touch controls. The specific functions can often be customized via the TOZO APP.

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Volume Up	N/A (usually on right)	Long Press
Volume Down	Long Press	N/A (usually on left)
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press	Long Press
Switch ANC/Transparency/Normal Mode	Hold for 2 seconds	Hold for 2 seconds

Note: Specific touch control assignments may vary or be customizable via the TOZO APP.

Active Noise Cancellation (ANC) and Transparency Mode

The TOZO Golden X1 offers advanced noise cancellation and transparency features.

- **Active Noise Cancellation (ANC):** Reduces ambient noise by up to 42dB, allowing for an immersive listening experience or quiet environment. Ideal for travel or noisy surroundings.
- **Transparency Mode:** Allows you to hear your surroundings without removing the earbuds, useful for conversations or being aware of traffic.
- **Normal Mode:** Standard audio playback without noise cancellation or transparency.

Switch between modes by holding the touch area on either earbud for 2 seconds. You can also adjust noise reduction intensity via the TOZO APP.

TUV Rheinland Certified Noise Canceling Earbuds

TOZO's high-performance noise-canceling earbuds certified by TUV Rheinland. Active Noise Cancellation (ANC) brings you an immersive experience with a noise reduction depth of 42dB.




Image: A visual representation of the TOZO Golden X1 earbud highlighting its TUV Rheinland certification for noise cancellation, demonstrating a 42dB noise reduction capability.

Environmental Call Noise Cancellation




Image: A person wearing the TOZO Golden X1 earbuds, illustrating the effectiveness of the environmental call noise cancellation feature during a conversation.

Using the TOZO APP

Enhance your listening experience and customize settings with the TOZO APP.

- Download the TOZO APP from your device's app store.
- Connect your Golden X1 earbuds to your device via Bluetooth.
- Open the TOZO APP to access features such as:
 - **32 Preset EQ Modes:** Choose from various sound profiles (Rock, Classical, Jazz, Hip-Pop, etc.) or create custom EQ settings.
 - **Noise Reduction Intensity Adjustment:** Fine-tune the level of active noise cancellation.
 - **Customized Touch Controls:** Reassign touch functions to your preference.
 - **Firmware Updates:** Keep your earbuds updated with the latest features and improvements.

Support 32 preset EQ modes and 6 noise reduction modes in the App



6 Types of Active Noise Cancellation Modes



32 Types of EQ Sound Modes



Customized Touch Controls



Firmware Updates




Image: Screenshots of the TOZO App interface, demonstrating the availability of 32 preset EQ modes, 6 types of active noise cancellation modes, customized touch controls, and firmware updates.

MAINTENANCE

Proper care will extend the life of your TOZO Golden X1 earbuds.

• Cleaning:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Use a cotton swab or small brush to gently clean the charging contacts on both the earbuds and the case.
- Avoid using abrasive cleaners, alcohol, or chemical solvents.

• Storage:

- Always store the earbuds in their charging case when not in use to protect them and keep them charged.

- Store in a cool, dry place, away from extreme temperatures and direct sunlight.
- **Water Resistance:** While the earbuds may have some level of water resistance, avoid submerging them in water or exposing them to heavy rain. Refer to product specifications for exact IP rating if available.

TROUBLESHOOTING

If you encounter issues with your TOZO Golden X1 earbuds, try the following solutions:

- **Earbuds not charging:**
 - Ensure the charging cable is securely connected to both the case and the power source.
 - Check if the charging contacts on the earbuds and case are clean and free of debris.
 - Verify the charging case has sufficient battery charge.
- **Earbuds not pairing/connecting:**
 - Make sure Bluetooth is enabled on your device.
 - Place the earbuds back into the case, close the lid, wait a few seconds, then open it again to re-enter pairing mode.
 - Forget "TOZO Golden X1" from your device's Bluetooth list and try pairing again.
 - Ensure the earbuds are sufficiently charged.
- **No sound or low volume:**
 - Check the volume level on both your device and the earbuds.
 - Ensure the earbuds are properly seated in your ears and forming a good seal.
 - Clean any earwax or debris from the earbud nozzles.
 - Try playing audio from a different application or device.
- **Noise cancellation not effective:**
 - Ensure the earbuds are properly fitted and sealed in your ear canals.
 - Verify that ANC mode is activated (not Transparency or Normal mode).
 - Adjust the noise reduction intensity via the TOZO APP.
- **One earbud not working:**
 - Place both earbuds back into the charging case, close the lid, and then take them out again.
 - Try resetting the earbuds (refer to the quick start guide or TOZO APP for specific reset instructions).

SPECIFICATIONS

Key technical specifications for the TOZO Golden X1 Wireless Earbuds:

Feature	Detail
Brand	TOZO
Model	Golden X1
Color	Blue

Feature	Detail
Ear Placement	In Ear
Form Factor	In Ear
Impedance	28 Ohm
Driver Type	Hybrid (Balanced Armature & 12mm Dynamic Driver)
Audio Codec	LDAC, Hi-Res Audio Wireless
Bluetooth Version	5.3
Noise Cancellation	Active Noise Cancellation (up to 42dB), Environmental Noise Reduction (6 mics)
Battery Life (Earbuds)	Up to 8 hours (single charge)
Battery Life (with Case)	Up to 32 hours
Charging Case Battery Capacity	500 mAh
Charging Compatibility	Type-C, Wireless Charging
Frequency Response	12Hz to 44.1kHz

**12mm diameter dynamic speaker
with polymer composite film materials.**




Image: Key features of the TOZO Golden X1, including its 12mm dynamic speaker, Hi-Res Audio Wireless certification, LDAC support, OrigX Pro technology, TUV Rheinland certification, and IDA Design Awards.

12Hz to 44.1KHz Supper Wide Frequency Range

Golden X1 Reproduce the music with clarity, precision and impact




Image: A graph illustrating the wide frequency response range of the TOZO Golden X1, from 12Hz to 44.1kHz, demonstrating its capability to reproduce music with clarity and impact.

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please visit the official TOZO website or contact their customer service. Details can typically be found on the TOZO brand store page or in the product packaging.

Official TOZO Store: [TOZO Store on Amazon](#)

© 2023 TOZO. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CMSXNQNX>

More documents and user manuals: <https://manuals.plus/>