

DUXOT DX-2057

DUXOT Atlantica DX-2057 Automatic Dive Watch User Manual

Model: DX-2057

INTRODUCTION

Welcome to the user manual for your DUXOT Atlantica DX-2057 Automatic Dive Watch. This timepiece combines classic design with modern engineering, featuring a Japanese automatic movement and robust construction suitable for daily wear and aquatic activities. Please read this manual carefully to understand the features and proper operation of your watch.




Image: Front view of the DUXOT Atlantica DX-2057 Automatic Dive Watch with a charcoal grey dial and stainless steel bracelet.

KEY FEATURES

- **Japanese Automatic Movement:** Self-winding mechanism with three-hand display and date function.
- **42mm Stainless Steel Case:** Durable construction with a sapphire lens for scratch resistance.
- **200m (20 ATM) Water Resistance:** Suitable for diving, swimming, and other water sports.
- **Screw-Down Crown:** Enhances water resistance and protects the movement.
- **Unidirectional Rotating Bezel:** For timing dive durations or other events.

- **Stainless Steel Bracelet:** Features a fold-over clasp with safety lock and push button for secure wear.



Image: Diagram illustrating key components and specifications of the DUXOT Atlantica DX-2057 watch.

SETUP AND INITIAL USE

Unboxing and First Impressions



Image: The DUXOT Atlantica DX-2057 watch presented in its packaging.

Upon receiving your DUXOT Atlantica watch, carefully remove it from its packaging. The watch is powered by an automatic movement, meaning it winds itself through the motion of your wrist. If the watch has stopped, it will need to be manually wound to initiate power reserve.

Winding the Watch

1. **Unscrew the Crown:** Gently unscrew the crown counter-clockwise until it is free from the case. This is position 0.
2. **Manual Winding:** In position 0, turn the crown clockwise approximately 20-30 times. This will build up an initial power reserve.

Setting the Time and Date

1. **Set the Date:** Pull the crown out to position 1 (first click). Turn the crown clockwise or counter-clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
2. **Set the Time:** Pull the crown out to position 2 (second click). The second hand will stop. Turn the crown to set the hour and minute hands. To ensure accurate time, set the time past 12 AM to confirm the date changes, then set to

the current time.

3. **Secure the Crown:** Once time and date are set, push the crown back into position 0 and screw it down tightly clockwise against the case. This ensures water resistance.

Your browser does not support the video tag.

Video: An overview of the DUXOT Atlantica DX-2057 watch, demonstrating its appearance and features, including unboxing and handling.

OPERATING YOUR WATCH

Automatic Movement

Your DUXOT Atlantica watch is powered by a Japanese automatic movement. This movement is self-winding, relying on the natural motion of your wrist to keep it powered. For optimal performance, wear your watch regularly. If the watch is not worn for an extended period, it may stop and require manual winding as described in the "Setup" section.



Image: Detailed view of an automatic watch movement, highlighting its intricate mechanical components.

Using the Unidirectional Rotating Bezel

The bezel on your dive watch rotates in one direction (counter-clockwise). This feature is designed to prevent accidental increases in timed duration. To use it:

1. Align the zero marker on the bezel with the minute hand at the start of an event (e.g., a dive).
2. The minute hand will then indicate the elapsed time against the bezel's scale.

Water Resistance (200m / 20 ATM)

Your DUXOT Atlantica watch is water-resistant to 200 meters (20 ATM), making it suitable for professional marine activity and serious surface water sports, but not saturation diving. Always ensure the crown is fully screwed down before exposing the watch to water.

CARE AND MAINTENANCE

Cleaning Your Watch

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. For the stainless steel case and bracelet, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

Water Resistance Precautions

- Always ensure the crown is fully screwed down before any contact with water.
- Do not operate the crown or pushers (if any) while the watch is submerged or wet.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.
- Avoid exposing the watch to extreme temperature changes, such as going from a hot sauna directly into cold water, as this can affect the seals.

Service and Inspection

It is recommended to have your automatic watch serviced by a qualified watchmaker every 3-5 years to ensure its longevity and maintain its water resistance. This includes checking and replacing seals as necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or is running slow.	Insufficient power reserve (not worn enough or not manually wound).	Manually wind the watch by unscrewing the crown and turning it clockwise 20-30 times. Wear the watch regularly.
Date changes at noon instead of midnight.	AM/PM setting is incorrect.	Advance the time by 12 hours.
Condensation under the crystal.	Water ingress due to improper crown sealing or damaged seals.	Immediately take the watch to a qualified watchmaker for inspection and repair to prevent further damage. Ensure crown is always screwed down.
Bezel is difficult to turn.	Dirt or debris lodged under the bezel.	Rinse the watch under running fresh water while rotating the bezel to dislodge debris. If problem persists, seek professional cleaning.

SPECIFICATIONS

Feature	Detail
Model Number	DX-2057
Movement	Japanese Automatic (3 Hands with Date)
Case Material	Stainless Steel
Case Diameter	42 mm
Lens	Sapphire Crystal
Water Resistance	200 meters (20 ATM)
Crown Type	Screw Down
Bezel	Unidirectional Turning Bezel
Band Material	22mm Stainless Steel Bracelet

Feature	Detail
Clasp Type	Fold Over Buckle With Push Button
Product Dimensions	0.87 x 1.65 x 0.51 inches; 7.05 ounces







WARRANTY AND SUPPORT

Your DUXOT Atlantica DX-2057 watch is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and how to make a claim.

For technical support, service, or inquiries regarding your watch, please contact DUXOT customer service through their official website or the contact information provided with your product documentation. Ensure you have your model number (DX-2057) and proof of purchase available when contacting support.



Related Documents - DX-2057

 <p>Atlantica DIVER AUTOMATIC AUTOMATIC WATCH This watch is a diver's watch. It is designed for use in water. It is not a toy. It is not a clock. It is a watch. For more information, please visit www.duxotwatches.com</p>	Duxot Atlantica Diver Automatic Watch Instruction Manual Instruction manual for the Duxot Atlantica Diver Automatic watch, covering operation, time and date setting, bracelet adjustment, and water resistance.
 <p>QUADRATA AUTOMATIC WATCH This watch is a diver's watch. It is designed for use in water. It is not a toy. It is not a clock. It is a watch. For more information, please visit www.duxotwatches.com</p>	Duxot Quadrata Automatic Watch Instruction Manual Comprehensive instruction manual for the Duxot Quadrata Automatic Watch, covering winding, setting time and date, clasp operation, bracelet resizing, and water resistance guidelines.
 <p>VITESSE DUAL TIME CHRONOGRAPH CHRONOGRAPH WATCH This watch is a diver's watch. It is designed for use in water. It is not a toy. It is not a clock. It is a watch. For more information, please visit www.duxotwatches.com</p>	Duxot Vitesse Dual Time Chronograph Instruction Manual Comprehensive instruction manual for the Duxot Vitesse Dual Time Chronograph watch, covering setup, operation, water resistance, and maintenance.
 <p>Ascensus AUTOMATIC WATCH This watch is a diver's watch. It is designed for use in water. It is not a toy. It is not a clock. It is a watch. For more information, please visit www.duxotwatches.com</p>	Duxot Ascensus Automatic Watch Instruction Manual - Operation and Care Comprehensive instruction manual for the Duxot Ascensus Automatic Watch. Learn about its self-winding movement, crown operation, time/date setting, bezel functions, and water resistance guidelines.
 <p>TIBURON MECA-QUARTZ CHRONOGRAPH WATCH This watch is a diver's watch. It is designed for use in water. It is not a toy. It is not a clock. It is a watch. For more information, please visit www.duxotwatches.com</p>	Duxot Tiburon Meca-Quartz Chronograph Watch Instruction Manual Comprehensive instruction manual for the Duxot Tiburon Meca-Quartz Chronograph Watch. Learn how to set time and date, operate the stopwatch, understand water resistance, and care for your timepiece. Includes details on the Meca-Quartz movement and bracelet resizing.
 <p>ACCELERO MECA-QUARTZ CHRONOGRAPH WATCH This watch is a diver's watch. It is designed for use in water. It is not a toy. It is not a clock. It is a watch. For more information, please visit www.duxotwatches.com</p>	Duxot Accelero Meteorite Chronograph Limited Edition Meca-Quartz Watch Instruction Manual Official instruction manual for the Duxot Accelero Meteorite Chronograph Limited Edition Meca-Quartz watch, detailing operation, settings, stopwatch functions, water resistance, and bracelet adjustment.

