Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VONLUCE CFN-1312-GW-HASFBA-1

VONLUCE 52-Inch Ceiling Fan with Lights User Manual

Model: CFN-1312-GW-HASFBA-1

1. Important Safety Information

Please read all instructions carefully before beginning installation. Failure to follow these instructions could result in electric shock, fire, or serious personal injury. Always consult a qualified electrician if you are unsure about any part of the installation process.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes.
- The ceiling fan must be mounted to a structure capable of supporting the fan's weight (minimum 35 lbs).
- Do not connect the fan to a dimmer switch or rheostat unless specifically designed for ceiling fans.
- Keep hands, feet, and other objects away from the fan blades when the fan is operating.

2. Package Contents

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, please contact VONLUCE customer support.



Image: The complete package contents including the ceiling fan assembly, remote control, remote mounting bracket, 5-inch downrod, and 10-inch downrod.

Included Components:

- Ceiling Fan Assembly (Motor, Blades, Light Kit)
- Remote Control
- Remote Mounting Bracket
- 5-inch Downrod
- 10-inch Downrod
- Mounting Hardware Kit

3. Setup and Installation

This ceiling fan is designed for easy installation. For detailed visual guidance, please refer to the installation videos available on the product's Amazon page.

Mounting Options:

- **Downrod Options:** The fan includes both 5-inch and 10-inch downrods to accommodate different ceiling heights. Choose the appropriate length for your space.
- **Ceiling Compatibility:** Suitable for flat ceilings and sloped ceilings up to a 10-degree incline.
- **Safety Cable:** A built-in safety cable is included for added security during installation and operation. Ensure it is properly secured.



Image: Diagram illustrating the fan's dimensions (52-inch span, max 13.8-inch height, min 8.9-inch height), available downrod lengths (5-inch and 10-inch), and compatible mounting options for flat and sloped ceilings (up to 10 degrees).

Installation Steps (General Overview):

1. Turn off power at the circuit breaker.
2. Install the mounting bracket to the ceiling junction box.
3. Assemble the downrod and canopy to the fan motor.
4. Hang the fan assembly onto the mounting bracket.
5. Complete electrical connections (ensure proper grounding).
6. Attach the fan blades and light kit.
7. Secure the canopy to the ceiling.
8. Install batteries in the remote control.
9. Restore power and test the fan.

4. Operating Instructions

Your VONLUCE ceiling fan is controlled by the included remote, offering a range of functions for optimal comfort.



Image: A modern living room with the ceiling fan installed, accompanied by icons highlighting its features: quiet operation (<35dB), 6 fan speeds, 0-100% dimming, 1/4/8 hour timer, remote control, and 5" & 10" downrods.

Remote Control Functions:

- **Power On/Off:** Turns the fan and light on or off.
- **Fan Speed Control:** Adjusts fan speed across 6 levels.
- **Light On/Off:** Controls the light independently from the fan.
- **Stepless Dimming:** Adjusts light brightness from 10% to 100%.

- **Color Temperature Adjustment:** Changes light color temperature from 3000K (warm white) to 6500K (cool white).
- **Timer:** Set the fan to turn off automatically after 2, 4, or 8 hours.
- **Reversible Fan Direction (F/R):** Changes the direction of blade rotation for summer (downward airflow) or winter (upward airflow).
- **Memory Function:** The fan remembers the last light and wind speed settings if it runs for more than 10 seconds before being turned off. It will resume these settings when turned on again.




Image: Visual representation of the 6 adjustable fan speeds: Levels 1-2 for gentle breeze (restful sleep), Levels 3-4 for natural wind (family

gatherings), and Levels 5-6 for high cooling air (hot summer days).




Image: Illustrates the dimmable LED light feature, showing the light output at 3000K (warm), 4500K (neutral), and 6500K (cool), with a slider indicating 10% to 100% brightness adjustment.



Image: Depicts the reversible DC motor function, showing downward airflow for cooling in summer and upward airflow for circulating warm air in winter.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or electrical components.
- **Blade Care:** Periodically check the fan blades for dust accumulation. Clean them gently to maintain balance and airflow efficiency.
- **Tighten Screws:** Over time, some screws may loosen. Check and tighten all screws on the fan body and mounting hardware annually.
- **Light Source:** The LED light source is integrated and designed for long life. Do not attempt to replace the LED module yourself.

6. Troubleshooting

If you experience issues with your ceiling fan, refer to the common problems and solutions below. If the problem persists, contact VONLUCE customer support.

Problem	Possible Cause	Solution
Fan does not start	No power; Loose wiring; Remote control battery dead.	Check circuit breaker; Verify all wire connections are secure; Replace remote control battery.
Light does not work	Loose wiring; Light function off on remote.	Check light kit wiring; Ensure light button on remote is pressed.
Fan wobbles	Loose blades; Unbalanced blades; Loose mounting bracket.	Ensure all blade screws are tight; Use balancing kit (not included) if necessary; Tighten mounting bracket screws.
Noisy operation	Loose screws; Motor hum.	Check and tighten all screws; A slight motor hum is normal for DC motors, but this model is designed for ultra-quiet operation (<35dB).




Image: A graph illustrating the quiet operation of the VONLUCE ceiling fan (35dB) compared to typical conversation (60dB) and other fans (55dB), emphasizing its suitability for quiet environments.

7. Specifications

Detailed technical specifications for your VONLUCE ceiling fan.

Feature	Detail
Brand	VONLUCE
Model Name	VONLUCE Ceiling Fan (CFN-1312-GW-HASFBA-1)
Color	White Gold
Electric Fan Design	Ceiling Fan
Power Source	DC
Style	Stepless
Product Dimensions	26"D x 9"W x 10.6"H (Fan body only, without downrod)
Room Type	Bedroom, Kitchen, Living Room, Farmhouse
Special Features	6 Speed, DC motor, Stepless adjustments brightness, Stepless adjustments color temperature, Timer
Recommended Uses	Ceiling fan with light
Noise Level	35 dB
Wattage	33 watts
Finish Type	Polished
Number of Blades	3
Speed	6 RPM (levels)
Voltage	110 Volts
Switch Type	Remote
Included Components	Remote
Indoor/Outdoor Usage	Indoor, Covered Outdoor (not exposed to rain)
Control Method	Remote
Blade Material	Plastic
Efficiency	High (Energy-efficient DC motor)
Item Weight	13.27 pounds
Batteries Required?	Yes (for remote, not included)

8. Important Notes

Color Variation Notice: Slight color variations may occur due to material batches, manufacturing processes, or display

settings. These are normal and do not impact product quality.
Ideal Room Sizes: This fan is ideal for rooms sized between 12x12 ft. and 18x18 ft.

9. Warranty and Support

For warranty information, technical support, or to purchase protection plans, please contact VONLUCE customer service directly or visit the official VONLUCE store on Amazon. Protection plans are available for 3-year and 4-year durations, as well as a monthly Complete Protect plan.
VONLUCE Store Link: Visit the VONLUCE Store

© 2024 VONLUCE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMTDXCG4

More documents and user manuals: **https://manuals.plus/**