

Luoba PH05

Luoba Kids Smart Phone Instruction Manual (Model PH05)

Model: PH05

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Luoba Kids Smart Phone, Model PH05. This device is designed to offer a blend of entertainment and educational content for children aged 3-12, featuring a 2.8-inch touchscreen, dual cameras, various games, a music player, and interactive learning themes.

2. PRODUCT FEATURES

- **2.8-inch Touchscreen:** Intuitive and easy-to-use interface for young children.
- **Dual Cameras:** Front and rear cameras for taking photos and recording videos, with 23 fun stickers.
- **13 Puzzle Games:** Engaging games designed to develop logical thinking, reaction skills, and hand-eye coordination.
- **Music Player:** Supports MP3 format, includes a built-in high-quality speaker, and a 3.5mm headphone jack. Comes with an 8GB SD card for additional music storage.
- **Educational Themes:** Includes ABC learning (A-Z letters with pronunciation and animal sounds), 24 iconic world buildings, 5 daily learning guides, and 10 fable stories.
- **Habit Tracker:** 12 habit tracker time alarms to help children develop good daily routines and time management skills.
- **Useful Gadgets:** Recorder, calculator, calendar, alarm clock, torch, countdown timer, and stopwatch.
- **Customization:** 31 styles of wallpaper and 10 desktop background wallpapers.
- **Durable Design:** Comes with a cute pattern design silicone phone case for drop protection and a lanyard for easy carrying.

Multi-Function Kids Smart Phone

More fun experiences for kids



NEW

Funny Learning



Image: The Luoba Kids Smart Phone interface showing multiple functions like camera, music, games, and utility apps.

3. WHAT'S IN THE BOX

- Luoba Kids Smart Phone (Model PH05)
- Silicone Phone Case
- 8GB SD Card (pre-installed or included separately)
- USB Type-C Charging Cable
- Lanyard
- User Manual (this document)



Image: An illustration showing the Luoba Kids Smart Phone, its silicone case, an 8GB SD card, a USB charging cable, and

4. SETUP

4.1 Initial Power On

1. Locate the **RESET Switch** on the side of the device. Ensure it is in the ON position.
2. Press and hold the **Power Button** (located on the side) for a few seconds until the screen illuminates.

4.2 Charging the Device

Before first use, fully charge the device. Connect the provided USB Type-C charging cable to the charging port on the phone and plug the other end into a compatible USB power adapter (not included). The battery indicator on the screen will show charging status.

4.3 Inserting/Removing SD Card

The device comes with an 8GB SD card for expanded storage. To insert or remove the card, carefully open the SD card slot cover (usually located on the side or bottom) and gently push the card in until it clicks, or pull it out. Ensure the device is powered off before performing this action.

5. OPERATING INSTRUCTIONS

5.1 Navigation

- **Touchscreen:** Swipe left or right to navigate between different application screens. Tap an icon to open an application.
- **Home Button:** Press the circular button at the bottom of the screen to return to the main menu from any application.

5.2 Camera and Video Recording

The Luoba Kids Smart Phone features dual cameras (front and rear) for capturing photos and videos.

1. Tap the 'Camera' icon to open the camera application.
2. Tap the camera icon on the screen to switch between front and rear cameras.
3. Tap the circular button to take a photo.
4. To record a video, tap the 'Video' icon from the main menu. Tap the record button to start/stop recording.
5. Access saved photos and videos by tapping the 'Photos' or 'Player' icons from the main menu.
6. Utilize the 23 built-in cute stickers to enhance photos.



Image: The dual camera function of the smart phone, demonstrating how children can take photos and videos with fun stickers.

5.3 Music Player

Enjoy pre-loaded music or add your own MP3 files.

1. Tap the 'Music' icon to open the music player.
2. Use the on-screen controls (play, pause, skip, volume) to manage playback.
3. Connect 3.5mm headphones (not included) for private listening.
4. To add more music, connect the device to a computer using the USB cable and transfer MP3 files to the 8GB SD card.

Music Player Phone for Kids

Includes 8G SD card to download more child's favorite music



Image: The music player feature, showing children listening to music with headphones, and icons indicating 3.5mm jack support, built-in speaker, and 8GB card for more music.

5.4 Games

The device includes 13 fun puzzle games.

1. Tap the 'Games' icon to access the game library.
2. Select a game by tapping its icon.
3. Follow the on-screen instructions to play.
4. A 'School mode' can be set to control playtime, if desired.

Fun Toys Phones for Kids



Image: The games section of the smart phone, illustrating various puzzle games available for children.

5.5 Learning Features

Engage with various educational content.

- **ABC Learning:** Tap the 'ABC' icon to learn letters with pronunciation and associated animal sounds.
- **Country Buildings:** Explore 24 iconic buildings from different countries to expand general knowledge.
- **Daily Guide:** Access 5 daily learning activities.
- **Stories:** Listen to 10 fun fable stories.
- **Habit Tracker:** Use the 12 habit tracker alarms to establish and maintain good daily habits.



Image: The learning themes section, showcasing ABC learning, daily guides, and world landmarks, designed to make learning enjoyable.

5.6 Utility Tools

The device includes several practical tools:

- **Recorder:** For voice recording.
- **Calculator:** Basic arithmetic functions.
- **Calendar:** View dates and manage schedules.
- **Alarm Clock:** Set alarms for various activities.
- **Torch:** A simple flashlight function.
- **Countdown Timer:** Set a timer for specific durations.
- **Stopwatch:** Measure elapsed time.



Image: A visual representation of the various useful functions available on the smart phone, including an alarm clock, calculator, timer, stopwatch, calendar, and flashlight.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and body of the device. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly.
- **Protective Case:** Always use the provided silicone protective case to guard against drops and impacts.

7. TROUBLESHOOTING

Problem	Possible Solution
Device will not turn on.	Check if the RESET Switch is in the ON position. Ensure the battery is charged. Long press the Power Button.
Screen is unresponsive.	Restart the device by turning the RESET Switch OFF and then ON, then long press the Power Button.
Cannot take photos/videos.	Check if the SD card is properly inserted and has sufficient storage space.
Music is not playing.	Ensure music files are in MP3 format. Check volume settings. Verify SD card is inserted correctly.

8. SPECIFICATIONS

- **Model Number:** PH05
- **Screen Size:** 2.8 inches (Touchscreen)

- **Product Dimensions:** 0.51 x 4.33 x 2.36 inches
- **Item Weight:** 3.2 ounces
- **Recommended Age:** 36 months - 12 years
- **Battery:** 1 Lithium Ion battery (included)
- **Storage:** 8GB SD Card (included)
- **Manufacturer:** Luoba




Image: A diagram illustrating the dimensions of the smart phone, showing its height as 5.04 inches and width as 2.56 inches.

9. WARRANTY & SUPPORT

To activate a **5-year extended warranty** and apply for a phone case or headphone, please register your product.

- **Email Support:** support@ucidtoys.com
- **Phone Support:** +1(978)252-4700 (Monday-Friday, 9:00 AM - 5:00 PM EST)

For further assistance or inquiries, please contact our support team during business hours.

10. PRODUCT OVERVIEW VIDEO

Video: An overview of the Luoba Kids Smart Phone, demonstrating its various features and functions.