

Volkano VK-9025-BK

Volkano Roma Series 20W 20000mAh PD Powerbank User Manual

Model: VK-9025-BK

INTRODUCTION

Thank you for choosing the Volkano Roma Series 20W 20000mAh PD Powerbank. This portable charger is designed to provide reliable power for your devices on the go. Its compact and lightweight design ensures easy portability, while the durable construction offers protection during daily use. This manual provides essential information for the safe and efficient operation of your power bank.

PACKAGE CONTENTS

- 1 x Volkano Roma Series 20W 20000mAh PD Powerbank
- 1 x Charging Cable (Micro USB, typically included for charging the power bank itself)
- 1 x User Manual




Image: Volkano Roma Series Powerbank shown within its retail packaging, indicating the product as it appears when purchased.

PRODUCT OVERVIEW

Familiarize yourself with the components and features of your Volkano Roma Series Powerbank.



Image: A clear front view of the Volcano Roma Series Powerbank, showcasing its sleek design and the digital display indicating 100% charge.



Image: Top-down view of the Volcano Roma Series Powerbank, highlighting the USB-A, USB-C, and Micro USB ports. A rear view displays the product specifications label.



Image: A detailed view of the power bank's input and output ports, including two Type-C ports (input/output) and one USB-A output port, with an indication of 22.5W Power Delivery charging capability.

- **USB-C Ports (x2):** These ports support both input (for charging the power bank) and output (for charging devices) with Power Delivery (PD) fast charging.
- **USB-A Output Port:** Standard USB port for charging various devices.
- **Digital Display:** Shows the current battery percentage of the power bank.

SETUP: CHARGING THE POWER BANK

Before first use, fully charge your Volcano Roma Series Powerbank. It is recommended to use a compatible wall adapter (not included) for optimal charging speed.

1. Connect the provided Micro USB cable (or a USB-C cable) to the input port on the power bank.
2. Connect the other end of the cable to a USB wall charger or a computer's USB port.
3. The digital display will show the charging progress. When the display shows "100%", the power bank is fully charged.

Note: Charging the power bank itself may take several hours due to its high capacity (20000mAh).

OPERATING: CHARGING YOUR DEVICES

The Volcano Roma Series Powerbank can charge most USB-powered devices, including smartphones, tablets, and other gadgets.

1. Connect your device's charging cable to one of the output ports on the power bank (USB-A or USB-C).
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The digital display will show the remaining battery percentage.
4. Once your device is fully charged, disconnect it from the power bank.




Image: The Volcano Roma Series Powerbank connected and simultaneously charging a smartphone, a tablet, and another mobile device, demonstrating its multi-device charging capability.

Power Delivery (PD) Fast Charging: The USB-C port supports PD fast charging up to 20W, allowing compatible devices to charge significantly faster than with standard chargers. Ensure your device and cable support PD for optimal performance.

LED INDICATOR GUIDE

The digital display on your power bank provides real-time information about its battery status.




Image: A close-up of the Volcano Roma Series Powerbank's LED display, clearly showing "100%" and a charging icon, indicating a full battery level.

- **Digital Percentage:** Indicates the exact remaining battery capacity of the power bank (e.g., 100%,

75%, 25%).

- **Charging Icon:** A small icon (often a lightning bolt or similar) will appear next to the percentage when the power bank is being charged.

MAINTENANCE AND SAFETY INSTRUCTIONS

To ensure the longevity and safe operation of your power bank, please observe the following:

- Do not expose the power bank to extreme temperatures (hot or cold), direct sunlight, or high humidity.
- Avoid dropping, puncturing, or disassembling the device.
- Keep away from water and other liquids.
- Use only original or certified compatible charging cables.
- Store the power bank in a cool, dry place when not in use.
- Do not attempt to replace the internal battery.
- Dispose of the power bank responsibly according to local regulations.
- Keep out of reach of children.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable not connected properly; faulty cable/adaptor; power bank fully discharged.	Ensure cable is securely connected. Try a different cable or wall adapter. Allow a few minutes for the power bank to respond if deeply discharged.
Device not charging from power bank	Power bank battery low; faulty cable; device incompatibility; incorrect port used.	Check power bank battery level. Try a different charging cable. Ensure your device is compatible with USB charging. Use an output port.
Slow charging	Non-fast charging cable/adaptor; device does not support fast charging; multiple devices charging simultaneously.	Use a PD-compatible cable and adaptor for fast charging. Ensure your device supports PD. Charging multiple devices may reduce individual charging speeds.
Digital display not working	Power bank is off; internal malfunction.	Ensure the power bank is active (some models require a button press). If the issue persists, contact customer support.

SPECIFICATIONS

Model Name	Roma Series
Model Number	VK-9025-BK
Battery Capacity	20000 mAh
Battery Cell Composition	Lithium Polymer

Input (USB-C)	PD 20W (5V=3A, 9V=2.22A, 12V=1.5A)
Output (USB-C)	PD 20W (5V=3A, 9V=2.22A, 12V=1.5A)
Output (USB-A)	5V=3A, 9V=2A, 12V=1.5A
Total Output	22.5W Max
Item Weight	440 g
Dimensions	18.2 x 10.4 x 4 cm (approximate package dimensions)
Color	Black
Special Features	Digital Display, Lightweight

WARRANTY AND SUPPORT

Your Volcano Roma Series Powerbank is covered by a **1-Year Limited Warranty** from the date of purchase.




You can extend your coverage by an additional 12 months, for a total of **24 Months coverage**, by registering your product. Please visit the official Volcano website for product registration details.




For technical support, warranty claims, or any questions regarding your product, please contact Volcano customer support via their official website or the contact information provided with your purchase. Please have your model number (VK-9025-BK) and proof of purchase ready.

Volcano Official Page: [Visit Volcano Store on Amazon](#)

© 2023 Volcano. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - VK-9025-BK

	<p>Volcano Electronics Catalog: Power Banks & Batteries Portable Charging Solutions</p> <p>Discover the comprehensive Volcano Electronics Catalog featuring a wide range of power banks (Relief, Nano, Nano+, Fuel, Spawn, Booster, Omega series) and Extra Series button cell batteries (CR2016, CR2025). Find reliable portable charging solutions and essential power for your devices.</p>
	<p>Volcano Rush 2.0 Series Bluetooth Earphones with Mic - Instruction Manual</p> <p>Comprehensive instruction manual for the Volcano Rush 2.0 Series Bluetooth Earphones with Mic, covering highlights, specifications, setup, controls, safety, cleaning, troubleshooting, and warranty information.</p>
	<p>Volcano VK-5065-BK Core Series Fitness Watch Instruction Manual</p> <p>Comprehensive instruction manual for the Volcano VK-5065-BK Core Series Splash Resistant Fitness Watch with Heart Rate Monitor. Learn about features, specifications, setup, usage, and care.</p>

 <p>The image shows the cover of the instruction manual for the Volkano Gemini Series 2x True Wireless Bluetooth Speakers. It features the product name, a small image of the speakers, and the text 'INSTRUCTION MANUAL'. At the bottom, there are various certification logos and a small disclaimer.</p>	<p>Volkano Gemini Series 2x True Wireless Bluetooth Speakers Instruction Manual VK-3133-BK</p> <p>Get detailed instructions for the Volkano Gemini Series 2x True Wireless Bluetooth Speakers (VK-3133-BK). This manual covers setup, charging, pairing, controls for music playback and calls, FM radio, USB/SD card modes, troubleshooting, safety precautions, and warranty information.</p>
 <p>The image shows the cover of the instruction manual for the Volkano X Vision Series 4K Action Camera. It features the product name, a small image of the camera, and the text 'INSTRUCTION MANUAL'. At the bottom, there are various certification logos and a small disclaimer.</p>	<p>Volkano X Vision Series 4K Action Camera Instruction Manual</p> <p>Instruction manual for the Volkano X Vision Series 4K Action Camera, detailing package contents, specifications, features, parts description, charging, storage, operation modes, Wi-Fi connectivity, USB connection, and safety precautions.</p>
 <p>The image shows the cover of the instruction manual for the Volkano Trailblazer Series Smartwatch. It features the product name, a small image of the smartwatch, and the text 'INSTRUCTION MANUAL'. At the bottom, there are various certification logos and a small disclaimer.</p>	<p>Volkano Trailblazer Smartwatch: Waterproof Fitness Tracker with GPS & Heart Rate Monitor - Instruction Manual</p> <p>Explore the features and specifications of the Volkano Trailblazer Series Smartwatch (VK-5069-BK). This instruction manual covers its waterproof design, GPS tracking, heart rate monitoring, multi-sport modes, and app connectivity.</p>