

Manuals.plus /

› DURAGS /

› PeriPage A40 Portable Thermal Printer User Manual

## DURAGS A40

# PeriPage A40 Portable Thermal Printer User Manual

Model: A40 | Brand: DURAGS

## INTRODUCTION

Welcome to the user manual for your new PeriPage A40 Portable Thermal Printer. This compact and versatile printer is designed for convenient printing of documents, photos, and various materials on thermal paper. It supports multiple paper sizes and offers seamless connectivity via Bluetooth and USB. Please read this manual thoroughly to ensure proper setup, operation, and maintenance of your device.



Image: The PeriPage A40 printer actively printing a document, showcasing its compact design and paper output.

## PRODUCT OVERVIEW

The PeriPage A40 is an all-in-one portable thermal printer. It is ideal for various printing needs, including PDF files, test papers, web pages, contracts, and photos. Its compact size and long standby time make it an excellent tool for both study and office work, allowing you to print on the go.

# Mini A4 printer

Print wherever you go , carry it easily More efficient for business



Image: A person demonstrating the portability of the PeriPage A40 printer by easily placing it into a bag.

The printer supports multiple thermal paper widths: 210mm (A4), 107mm (4-inch), 77mm (3-inch), and 56mm (2-inch). It accommodates both paper rolls and folded paper, providing flexibility for different printing tasks.

# 2 Paper Types More Efficient



## Folding Paper

Automatic paging  
Multiple Paper Printing



## Inner Roll Paper

Portable, Free Space  
Customized Paper Length

Image: A visual representation of the two supported paper types: folding paper and inner roll paper, highlighting the printer's versatility.

## SPECIFICATIONS

---

Feature	Detail
Model	A40
Color	Sky Gray
Battery	Built-in rechargeable 2600 mAh x 2, 7.4V
Continuous Operation Time	3 hours
Standby Time	Up to 90 days
Input	5V 2A
Connectivity	Bluetooth, USB Type-C
Printing Technology	Thermal Printing
Product Size	265 × 80 × 45 mm (10.4 × 3.1 × 1.8 inches)
Product Weight	658 grams (23.2 ounces)
Print Head Life	Over 50 km (approx. 168,000 A4 sheets)




Image: A diagram illustrating the physical dimensions of the PeriPage A40 printer.

# Long Standby Time

## 5200mAh



USB port power supply connection, print as you go



**90** Days  
Long Standby Time



**5200** mAh  
Powerful Battery



**3** H  
Continuous Print 3 Hours  
Full Charge



**360** Papers  
360 Papers Print  
Full Charge



Image: Visual details on the long standby time and powerful battery capacity of the PeriPage A40 printer.

## SETUP

---

### 1. Unboxing and Initial Charge

Upon unboxing, ensure all components listed in the "Package Contents" section are present. Before first use, fully charge the printer using the provided USB Type-C cable.

## 2. Loading Thermal Paper

The PeriPage A40 uses thermal paper only. To open the paper compartment, press the two buttons located on the sides of the printer simultaneously. Insert the thermal paper roll or folded thermal paper, ensuring it is aligned correctly. Close the cover firmly until it clicks into place.

Press the buttons at the same time to open the cover



Image: A visual guide showing how to open the printer cover by pressing side buttons, and identifying the power button and Type-C interface.

## 3. App Installation (for Mobile Devices)

For mobile printing (iOS and Android), download the official "PeriPage" application from your device's app store.

# Functional Free APP Not Just a Printer




Image: A smartphone displaying the PeriPage app, illustrating its functional interface for different printing tasks.

## 4. Driver Installation (for Computers)

For printing from a computer, you will need to download and install the appropriate driver. The driver can be found at: <https://www.ileadtek.com/en/download.html>. **Note: Mac OS is not currently supported by the driver.**

## OPERATING INSTRUCTIONS

---

### 1. Powering On/Off

To power on the printer, press and hold the power button for two seconds. To power off, press and hold the power button again until the device shuts down.

### 2. Connecting via Bluetooth (Mobile)

1. Ensure the printer is powered on.
2. Open the PeriPage app on your iOS or Android device.
3. Within the app, navigate to the device connection settings.

4. Select your PeriPage A40 printer from the list of available Bluetooth devices to establish a connection.

### **3. Connecting via USB (Computer)**

After installing the driver, connect the printer to your computer using the provided USB Type-C cable. The printer should be recognized by your system, allowing you to print directly from your applications.

### **4. Printing Documents**

Once connected, you can initiate printing from your chosen application (e.g., PeriPage app, word processor, PDF viewer). Select the PeriPage A40 as your printer and adjust print settings as needed.

## **MAINTENANCE**

---

### **1. Cleaning the Print Head**

To maintain print quality, periodically clean the print head. Use a soft, lint-free cloth lightly dampened with isopropyl alcohol. Gently wipe the print head surface. Ensure the printer is off and cool before cleaning.

## HD Printer Head Print life over 50km

**50** km  
≈ **168000 A4 paper**

**50** km  
≈ **7000rolls paper**  
(1 roll ≈ 7m)

Image: A detailed view of the printer's high-quality print head, emphasizing its durability and performance.

### 2. Paper Handling

Always use high-quality thermal paper for optimal results. Store thermal paper in a cool, dry place away from direct sunlight to prevent degradation.

### 3. Battery Care

To prolong battery life, avoid completely discharging the battery frequently. Charge the printer regularly, even if not in constant use.

## TROUBLESHOOTING

- **Printer not turning on:** Ensure the battery is charged. Connect the printer to a power source using the USB Type-C cable and try again.

- **Poor print quality or blank prints:**

- Ensure you are using thermal paper. This printer is not compatible with ordinary paper.
- Check if the thermal paper is loaded correctly, with the printable side facing the print head.
- Clean the print head as described in the Maintenance section.

- **Cannot connect via Bluetooth:**

- Ensure Bluetooth is enabled on your mobile device.
- Make sure the printer is powered on and within range.
- Restart both the printer and your mobile device.
- Ensure you are connecting through the PeriPage app, not directly through your phone's Bluetooth settings.

- **Printing from computer not working:**

- Verify that the correct driver is installed from <https://www.ileadtek.com/en/download.html>.
- Check the USB cable connection.
- Remember that Mac OS is not currently supported.

- **General printing errors:** If printing is incorrect, please check the paper roll installation or contact customer support.

## PACKAGE CONTENTS

---

The following items are included in your PeriPage A40 printer package:

- 1 × PeriPage A40 Thermal Printer
- 1 × USB Type-C Cable
- 1 × A4 Thermal Paper Roll
- 1 × User Manual (this document)

## WARRANTY AND SUPPORT

---

For any issues not covered in this manual or for further assistance, please contact DURAGS customer support. Refer to your purchase documentation for specific warranty details.

For driver downloads and additional resources, visit: <https://www.ileadtek.com/en/download.html>

