

[Manuals.plus](#) /

› [ASPECTEK](#) /

› ASPECTEK Electric Fly Swatter and UV Mosquito Lamp User Manual

ASPECTEK HR

ASPECTEK Electric Fly Swatter and UV Mosquito Lamp

USER MANUAL

Introduction

Thank you for choosing the ASPECTEK Electric Fly Swatter and UV Mosquito Lamp. This device is designed to provide effective and convenient insect control for both indoor and outdoor environments. Please read this manual carefully before use to ensure proper operation, safety, and longevity of your product.

This manual covers the setup, operation, maintenance, and troubleshooting of your new electric fly swatter.

Important Safety Instructions

- **High Voltage:** The internal grid operates at 3000V. Do not touch the internal grid when the device is active or charging.
- **Protective Grids:** The electric mosquito swatter is equipped with two protective mesh grids on the outside to prevent accidental contact with the powerful 3000V internal grid. However, exercise caution.
- **Charging Safety:** Use only the provided USB charging cable. Do not leave the device unattended while charging, especially overnight. Overcharging or using incompatible chargers may pose a fire hazard. Ensure the charging port is dry before connecting the cable.
- **Water Exposure:** Do not expose the device to water or rain. This product is not waterproof.
- **Children and Pets:** Keep out of reach of children and pets. This is not a toy.
- **Flammable Materials:** Do not use near flammable liquids, gases, or materials.
- **Intended Use:** Use only for its intended purpose of eliminating flying insects.
- **Damage:** Do not use if the device or charging cable is damaged. Contact customer support for assistance.

Product Overview

The ASPECTEK Electric Fly Swatter combines a traditional handheld swatter with a UV mosquito lamp function, offering versatile insect control.




Image: Two ASPECTEK Electric Fly Swatters in white, accompanied by their USB charging cables. The swatters feature a round head with a visible internal grid and a handle.

Key Features:

- **3000V High-Voltage Grid:** Quickly and effectively eliminates flying insects upon contact.
- **UV Mosquito Lamp:** Integrated 365nm wavelength UV light attracts mosquitoes for automatic elimination in lamp mode.
- **Rechargeable Battery:** Equipped with a 1200 mAh Li-Ion battery, providing up to 10,000 zaps on a full charge.
- **USB Charging:** Conveniently recharges via USB (cable included) in approximately 2-3 hours.
- **Dual Mode Operation:** Can be used manually as a fly swatter or placed in a desired location for automatic mosquito elimination.
- **Three Working Modes:** Handheld, Wall-Mounted, and Baiting Mode (automatic lamp mode).
- **Portable Design:** Suitable for indoor use (kitchen, bedroom, living room) and outdoor activities (camping, BBQ, hiking).
- **Safety Protection:** Features a 3-layer safety grid to prevent accidental contact.

Setup and Charging

Initial Charge:

Before first use, fully charge the device. Connect the provided USB charging cable to the charging port on the handle and plug the other end into a standard USB power adapter (not included) or a computer USB port.

- During charging, the indicator light will glow **red**.
- Once fully charged (approximately 2-3 hours), the indicator light will turn **green**.



Image: The ASPECTEK Electric Fly Swatter is shown charging via a USB-C cable connected to a wall adapter, illustrating its energy-saving and rechargeable features.

Placement:

The device can be used handheld, placed on a flat surface, or hung on a wall using the integrated hook. Choose a location where insects are prevalent, ensuring it's away from water sources and out of reach of children and pets.

3-LAYER

Safety Protection




Image: This image illustrates the three versatile modes of the fly swatter: foldable for tabletop use, hangable for wall mounting, and handheld for active use.

Operating Instructions

The ASPECTEK Electric Fly Swatter features a multi-position switch and an electric button for different operating modes.

Switch Positions:

- **OFF:** The device is completely off.
- **ON 1 Position (Manual Swatting Mode):**

Slide the switch to the "ON 1" position. The UV light will activate. To zap insects, press and hold the **Electric Button** on the handle. The internal grid will become active, and the indicator light will glow red. Release the button to deactivate the grid.
- **ON 2 Position (Automatic Lamp Mode):**

Slide the switch to the "ON 2" position. The UV light will activate, and the internal grid will remain continuously active. This mode is ideal for placing the device on a surface or hanging it to attract and eliminate mosquitoes automatically, especially effective at night.


3 MODES



FOLDABLE



HANGING



HANDHELD

Image: The ASPECTEK Electric Fly Swatter is shown in a dimly lit room, highlighting its 360-degree UV light feature which releases 365nm wavelength light to attract mosquitoes quietly.

Video Demonstration:

Your browser does not support the video tag.

Video: This video demonstrates the various features and operating modes of the ASPECTEK Electric Fly Swatter, including its handheld use, wall-mounted option, baiting mode, and charging process. It highlights the UV light attraction and the protective external grill.

Maintenance

- **Cleaning:** Ensure the device is OFF and unplugged before cleaning. Use a soft, dry brush or cloth to gently remove any insect debris from the grids. Do not use water or cleaning solutions directly on the grids or electrical components.
- **Storage:** Store the device in a cool, dry place when not in use, away from direct sunlight and moisture.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Recharge the device regularly, even if not in constant use.

Troubleshooting

Problem	Possible Cause	Solution
Device not zapping/UV light not turning on.	Battery is low or depleted. Switch is in OFF position. Electric button not pressed (in ON 1 mode).	Charge the device fully. Slide the switch to ON 1 or ON 2. Press and hold the Electric Button (in ON 1 mode).
Device not charging.	Charging cable or adapter faulty. Charging port is dirty or damaged.	Try a different USB cable and adapter. Ensure the charging port is clean and dry. If issues persist, contact customer support.
UV light not attracting insects effectively.	Too much ambient light. Device placed incorrectly.	Use in darker environments for best results. Place the device away from competing light sources.
Device overheats or smells burnt during charging.	Faulty battery or charging circuit. Overcharging.	Immediately unplug the device. Do not use or charge again. This indicates a serious safety risk. Contact customer support for replacement or disposal instructions.

Specifications

Feature	Detail
Brand	ASPECTEK
Model Number	HR
ASIN	B0CMWHLB4W
UPC	805939203900
Voltage	3000V (Grid)
Battery Capacity	1200 mAh Li-Ion
Charging Time	Approx. 2-3 hours
Product Dimensions	38 x 8 x 27 cm; 890 Grams (Also 12.6L x 24.8W x 27H cm)
Target Species	Flies, Mosquitoes, Gnats, Wasps, Moths
Color	White

Warranty and Support

ASPECTEK products are designed for your satisfaction. This product typically comes with **2-year warranty** from the date of purchase, covering manufacturing defects.

For warranty claims, technical support, or any questions regarding your product, please refer to the contact information provided with your purchase or visit the official ASPECTEK website.

Please retain your proof of purchase for warranty purposes.

© 2023 ASPECTEK. All rights reserved.
Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CMWHLB4W>

More documents and user manuals: <https://manuals.plus/>