



[Manuals.plus](#) /

› [LILUOKE](#) /

› LILUOKE DT-LK9011G-01 Men's Quartz Watch Instruction Manual

LILUOKE DT-LK9011G-01

LILUOKE DT-LK9011G-01 Men's Quartz Watch Instruction Manual

1. INTRODUCTION

Thank you for choosing the LILUOKE DT-LK9011G-01 Men's Quartz Watch. This manual provides detailed instructions for the proper setup, operation, and maintenance of your timepiece. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.



Figure 1: The LILUOKE DT-LK9011G-01 watch as worn on a wrist, showcasing its design and fit.

2. PRODUCT OVERVIEW

The LILUOKE DT-LK9011G-01 is a robust quartz watch featuring a luminous design, a large face, and a stainless steel construction. It includes multiple sub-dials for enhanced functionality.

Key Features:

- **Premium Stainless Steel Construction:** Both the case and strap are crafted from high-quality stainless steel for durability and resistance to fading.
- **Multifunction Sub-Dial Design:** Features three functional sub-dials (minute, second, and 24-hour) for tracking multiple time functions.
- **Imported Quartz Movement:** Ensures stable performance and accurate timekeeping with minimal deviation.
- **Daily Water Resistance:** Designed to withstand accidental splashes or water exposure during hand washing. *Not suitable for swimming, showering, or diving.*

Watch Components:



Figure 2: Front view of the LILUOKE DT-LK9011G-01 watch, showing the main dial, three sub-dials, crown, and pushers.



Figure 3: Angled view of the LILUOKE DT-LK9011G-01 watch, highlighting the side profile and pushers.

1. **Crown:** Used for setting time and date.
2. **Pusher A:** Start/Stop button for the chronograph.
3. **Pusher B:** Reset button for the chronograph.
4. **Hour Hand:** Indicates the hour.
5. **Minute Hand:** Indicates the minute.
6. **Second Hand:** Main second hand for timekeeping.
7. **Chronograph Minute Sub-dial:** Measures elapsed minutes for the chronograph.
8. **Chronograph Second Sub-dial:** Measures elapsed seconds for the chronograph.
9. **24-Hour Sub-dial:** Displays time in a 24-hour format.
10. **Date Window:** Displays the current date.

3. INITIAL SETUP

3.1 Setting the Time

1. Pull the crown out to position 2 (the outermost position). The second hand will stop.
2. Rotate the crown to move the hour and minute hands to the desired time. Ensure the 24-hour sub-dial also reflects the correct AM/PM (or 24-hour cycle).
3. Once the time is set, push the crown back into position 0 (normal position). The second hand will resume movement.

3.2 Setting the Date

1. Pull the crown out to position 1 (the first click).
2. Rotate the crown clockwise or counter-clockwise (depending on the movement) until the correct date appears in the date window.
3. Once the date is set, push the crown back into position 0.
4. *Note: Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism. If the date needs to be adjusted during this period, first set the time outside this range, adjust the date, then reset the time.*

4. OPERATING THE CHRONOGRAPH

Your LILUOKE watch is equipped with a chronograph function for measuring elapsed time.

1. **Starting the Chronograph:** Press Pusher A to start the chronograph. The chronograph second hand will begin to move.
2. **Stopping the Chronograph:** Press Pusher A again to stop the chronograph. The elapsed time (seconds on the chronograph second sub-dial, minutes on the chronograph minute sub-dial) will be displayed.
3. **Resetting the Chronograph:** After stopping the chronograph, press Pusher B to reset all chronograph hands to their zero positions.
4. **Split Time:** If your watch supports this, press Pusher B while the chronograph is running to temporarily freeze the display, then press Pusher B again to catch up to the running time. Press Pusher A to stop, then Pusher B to reset.

The 24-hour sub-dial operates continuously with the main time display, indicating the current hour in a 24-hour format (e.g., 1 PM is 13:00).

5. CARE AND MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain the appearance and hygiene of your watch. Use a soft, dry cloth to wipe the case and strap. For stainless steel, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive materials.

5.2 Water Resistance



Figure 4: The LILUOKE DT-LK9011G-01 watch demonstrating its daily water resistance against splashes.

Your watch is designed with "Daily Water Resistance" (30ATM). This means it is protected against accidental splashes, rain, and hand washing. **It is crucial to avoid wearing the watch during swimming, showering, bathing, or diving, as this can compromise the water seals and cause damage.** Always ensure the crown is fully pushed in before any contact with water.

5.3 Battery Replacement

The watch is powered by a Lithium Ion battery. When the watch stops or the second hand begins to skip (indicating low battery), it is time for a battery replacement. We recommend having the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

5.4 Storage

Store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. When not in use for extended periods, consider storing it in its original packaging or a watch box.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or is running intermittently.	Low or depleted battery.	Replace the battery by a professional watch technician.
Time is inaccurate.	Incorrect time setting; exposure to strong magnetic fields; battery low.	Reset the time correctly. Keep the watch away from magnets. Check battery.
Water or condensation inside the watch.	Water resistance compromised (e.g., crown not fully pushed in, exposure to excessive water pressure).	Immediately take the watch to a professional for inspection and repair to prevent further damage.
Chronograph hands do not reset to zero.	Chronograph reset mechanism issue.	Consult a professional watch technician for adjustment.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact LILUOKE customer support or a certified watch repair center.

7. SPECIFICATIONS

Brand	LILUOKE
Model Number	DT-LK9011G-01
Movement Type	Quartz
Case Material	Stainless Steel
Strap Material	Stainless Steel
Water Resistance	30ATM (Daily Water Resistance - not for swimming/diving)
Battery Type	1 Lithium Ion (included)
Package Dimensions	17.7 x 12.09 x 3.99 cm
Weight	600 g

8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your purchase or visit the official LILUOKE website. The warranty typically covers manufacturing defects under normal use.

For technical support, service, or inquiries, please contact LILUOKE customer service through their official channels. Keep your purchase receipt and model number (DT-LK9011G-01) handy when contacting support.

LILUOKE Official Website: [LILUOKE Brand Page on Amazon](#)

