



Manuals.plus /

- › TRIUMPHKEY /
- › TRIUMPHKEY 140x60cm Z-Shaped Gaming Desk Instruction Manual

TRIUMPHKEY 140 x 60 cm

TRIUMPHKEY 140x60cm Z-Shaped Gaming Desk

Instruction Manual

1. INTRODUCTION

Thank you for choosing the TRIUMPHKEY 140x60cm Z-Shaped Gaming Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your product. Please read this manual thoroughly before assembly and retain it for future reference.



Image 1.1: The TRIUMPHKEY 140x60cm Z-Shaped Gaming Desk in a typical gaming environment.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Do not exceed a load of 100 kg (220 lbs) on the desk surface.
- Ensure the desk is assembled correctly for optimal stability.
- Always place the desk on a flat and even surface.
- Keep small parts away from children during assembly to prevent choking hazards.
- Periodically check all screws and connections to ensure they remain tight.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Surface (Carbon Fiber)
- Z-Shaped Leg Frames (2 units)

- Support Beams/Crossbars
- Adjustable Feet (4 units)
- Headphone Hook
- Cup Holder
- Cable Management Grommets (2 units)
- Assembly Hardware (screws, bolts, washers, Allen wrench)
- Instruction Manual



Image 3.1: All components included in the package for assembly.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your TRIUMPHKEY Gaming Desk. It is recommended to have a second person assist with assembly for easier handling of larger components.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Refer to the package contents list to ensure all parts are present.
2. **Attach Support Beams to Legs:** Connect the support beams to the Z-shaped leg frames using the

- provided screws and Allen wrench. Do not fully tighten screws until all components are aligned.
3. **Secure Leg Frames to Desktop:** Carefully place the desktop upside down on a soft surface. Align the assembled leg frames with the pre-drilled holes on the underside of the desktop. Attach using the appropriate screws.
 4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the Z-shaped leg frames.
 5. **Install Accessories:** Attach the headphone hook and cup holder to the designated locations on the desktop or frame. Insert the cable management grommets into the desktop holes.
 6. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws. Do not overtighten.
 7. **Position the Desk:** Carefully flip the desk upright and place it in your desired location. Adjust the feet to ensure the desk is level and stable on uneven floors.



Image 4.1: General assembly steps for the gaming desk structure.

5. OPERATING INSTRUCTIONS

Your TRIUMPHKEY Gaming Desk is designed for versatile use in gaming, office, or study environments. Utilize its features to enhance your experience:

- **Surface Usage:** The spacious 140x60cm carbon fiber surface accommodates multiple monitors, keyboards, mice, and other gaming peripherals or work essentials.
- **Cable Management:** Use the integrated cable grommets to route and organize power cords and peripheral cables, keeping your workspace tidy and clutter-free.
- **Headphone Hook:** Hang your gaming headset or headphones on the dedicated hook for easy access and to keep them off the desk surface.
- **Cup Holder:** Place your beverage in the cup holder to prevent spills and keep it within reach during intense gaming sessions or work.
- **Adjustable Feet:** Fine-tune the desk's stability by adjusting the individual feet to compensate for uneven flooring.

6. FEATURES OVERVIEW

The TRIUMPHKEY Gaming Desk incorporates several design elements for durability, stability, and user convenience:

6.1. Carbon Fiber Surface

The desktop is covered with a high-quality carbon fiber texture, known for its durability, scratch resistance, and ease of cleaning. This surface provides a smooth and robust platform for all your activities.



DISEÑO ESTRUCTURAL ROBUSTO EN FORMA DE Z

Capaz de soportar equipos más pesados y un uso prolongado, no es fácil de sacudir o dañar, lo que garantiza la estabilidad de la mesa durante el juego!

Image 6.1: Detailed view of the carbon fiber surface, highlighting its texture and properties.

6.2. Robust Z-Shaped Design

The desk features Z-shaped legs constructed from cold-rolled steel, providing a mechanically reinforced triangular structure. This design ensures exceptional stability and durability, preventing wobbling during intensive use.



PORTAVASOS

El portavasos evita que las bebidas se derramen y se caigan en el calor del juego!

Image 6.2: Visual representation of the Z-shaped leg design and adjustable feet.

6.3. Integrated Accessories

For enhanced convenience, the desk includes a dedicated headphone hook and a cup holder, keeping your essentials organized and easily accessible.

SOPORTE PARA AURICULARES

Mantiene los auriculares en una posición fácilmente accesible en todo momento!



Image 6.3: Overview of the integrated headphone hook, cup holder, and cable management features.

7. MAINTENANCE

To maintain the appearance and functionality of your gaming desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the carbon fiber surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the surface.
- **Hardware Check:** Periodically inspect all screws and bolts to ensure they are tight. Retighten if necessary to maintain structural integrity.
- **Avoid Excessive Heat:** Do not place extremely hot items directly on the desk surface without protection.

8. TROUBLESHOOTING

If you encounter any issues with your TRIUMPHKEY Gaming Desk, refer to the following common problems and solutions:

- **Desk is Wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the leveling feet at the bottom of the legs to compensate for uneven floor surfaces.
- **Missing Parts:**
 - Double-check the packaging and all packing materials.
 - If parts are genuinely missing, contact TRIUMPHKEY customer support with your purchase details.
- **Surface Scratches:**
 - While the carbon fiber surface is scratch-resistant, extreme force or sharp objects can still cause damage. Use mouse pads and coasters to protect the surface.

For issues not covered here, please contact TRIUMPHKEY customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	TRIUMPHKEY
Model	140 x 60 cm Gaming Desk
Color	Black
Product Dimensions (L x W x H)	140 x 60 x 75 cm (55.1 x 23.6 x 29.5 inches)
Weight	15 kg (33 lbs)
Material	Carbon Fiber (Desktop), Cold-rolled Steel (Frame)
Special Features	Scratch Resistant, Z-Shaped Design, Cup Holder, Headphone Hook, Cable Management, Adjustable Feet
Max Load Capacity	100 kg (220 lbs)



Image 9.1: Key dimensions of the gaming desk.

10. WARRANTY AND SUPPORT

TRIUMPHKEY products are manufactured with quality and durability in mind. For warranty information, product support, or to report any issues, please contact the seller directly through your purchase platform. Please have your order number and product model readily available when contacting support. We are committed to providing excellent customer service and will assist you with any difficulties you may encounter during installation or use.