

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [POMUIC](#) /

› [POMUIC Wireless Earbuds Bluetooth Headphones User Manual](#)

POMUIC Q53-Z-1

POMUIC Wireless Earbuds User Manual

Model: Q53-Z-1

INTRODUCTION

Thank you for choosing the POMUIC Wireless Earbuds. These earbuds are designed to provide a high-fidelity audio experience with advanced features such as Bluetooth 5.3 connectivity, extended battery life, and IP7 waterproof rating. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: The POMUIC Wireless Earbuds, purple in color, resting inside their open charging case, showcasing the earhook design and the digital display on the case.

WHAT'S IN THE BOX

- POMUIC Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your POMUIC Wireless Earbuds.



Image: An exploded diagram illustrating the internal components of the earbud, highlighting the 13.4mm dynamic driver for high-fidelity audio.

The earbuds feature 13.4mm dynamic drivers designed to deliver powerful stereo sound and an immersive musical experience. The ergonomic earhook design ensures a secure and comfortable fit, ideal for sports and active use.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are properly seated.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).

3. The LED display on the charging case will indicate the charging status. A full charge provides up to 8 hours of playtime for the earbuds and up to 120 hours with the charging case.



Image: The charging case displaying battery levels for both earbuds and the case, alongside icons indicating 8 hours of earbud playtime, 120 hours with the case, 1.5 hours fast charging, and USB-C charging.

The charging case also functions as a 2200mAh emergency power bank for mobile phones or other devices. Simply connect your device to the USB-A output port on the charging case using your device's charging cable.

2200MAH EMERGENCY POWER BANK FOR MOBILE PHONE



Image: The earbud charging case connected via USB-C to a smartphone, demonstrating its function as a 2200mAh emergency power bank.

2. Pairing with Your Device

The earbuds utilize Bluetooth 5.3 technology for stable and fast connections.

1. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Q53" from the list of found devices to connect.
4. Once paired, the earbuds will automatically connect to your device when you open the charging case lid in the future.

BLUETOOTH 5.3 POWERFUL CHIPS

Compatible with most devices, providing a stable and fast connection.



Image: A visual representation of the earbuds pairing with a smartphone, showing the "Q53" device name in the Bluetooth settings, compatible with Android, iOS, and Windows devices.




Image: A detailed diagram of the Bluetooth 5.3 chip, emphasizing its role in providing stable and fast wireless communication.

OPERATING INSTRUCTIONS

Wearing the Earbuds

The soft silicone ear hooks are designed to fit all ear shapes perfectly, ensuring your earphones stay comfortable and secure during sports and outdoor activities.



Image: A diagram showing how to wear the earbuds with flexible earhooks, illustrating that either the left or right earbud can be used independently.

Smart Touch Controls

The earbuds feature sensitive touch controls for easy management of audio playback and calls.

Action	Left Earbud	Right Earbud
Play/Pause	Double tap (X2)	Double tap (X2)
Switch Song (Next)	N/A	Long press for 2 seconds (2S)
Switch Song (Previous)	Long press for 2 seconds (2S)	N/A
Answer Call	Double tap (X2)	Double tap (X2)
Reject Call	Long press for 2 seconds (2S)	Long press for 2 seconds (2S)
Activate Voice Assistant (SIRI)	Double tap (X2)	Double tap (X2)
Adjust Volume (Up)	N/A	Single tap (X1)
Adjust Volume (Down)	Single tap (X1)	N/A




Image: A detailed diagram illustrating the touch control functions for both the left and right earbuds, including actions for music playback, call management, voice assistant activation, and volume adjustment.

MAINTENANCE

Cleaning

Regular cleaning helps maintain optimal performance and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts on both earbuds and case are clean and dry.

Water Resistance (IP7)

The earbuds are IP7 waterproof, meaning they are protected against the effects of temporary immersion in water (up to 1 meter for 30 minutes). This makes them suitable for use during workouts and in rainy conditions.

- Do not intentionally submerge the earbuds for extended periods or in depths greater than 1 meter.
- Ensure the earbuds are completely dry before placing them back into the charging case to prevent damage.
- The charging case is not waterproof.



Image: The earbuds shown with water droplets, illustrating their IPX7 waterproof rating, designed to prevent damage from sweat and rain.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing/connecting.	<ul style="list-style-type: none">◦ Ensure earbuds are charged.◦ Turn off and on Bluetooth on your device.◦ Forget "Q53" from your device's Bluetooth list and re-pair.◦ Place earbuds back in the case, close the lid, wait a few seconds, then open again.
No sound or low volume.	<ul style="list-style-type: none">◦ Adjust volume on both earbuds and your connected device.◦ Ensure earbuds are properly seated in your ears.◦ Check if earbuds are connected to the correct device.
One earbud not working.	<ul style="list-style-type: none">◦ Ensure both earbuds are charged.◦ Place both earbuds back in the charging case, close the lid, then open again to reset.◦ Try re-pairing the earbuds with your device.
Charging case not charging.	<ul style="list-style-type: none">◦ Check the USB-C cable and power adapter.◦ Ensure the charging port is clean and free of debris.◦ Try a different charging cable or power source.

SPECIFICATIONS

Feature	Detail
Model Name	Q53-Z-1
Connectivity Technology	Wireless (Bluetooth 5.3)
Earbud Battery Life	Up to 8 hours
Total Playtime (with Charging Case)	Up to 120 hours
Charging Case Battery Capacity	2200mAh (Emergency Power Bank)
Water Resistance Level	IP7 Waterproof
Audio Driver Size	13.4 mm Dynamic Driver
Microphone	CVC8.0 HD Microphones
Control Type	Touch Control

Feature	Detail
Ear Placement	In Ear with Earhook
Compatible Devices	Bluetooth enabled devices (iOS, Android, Windows)
Material	Thermoplastic Elastomer (TPE)
Item Weight	5.3 ounces

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official POMUIC website. Keep your proof of purchase for any warranty claims.