

T4TREAM VSC18ST-LRO

T4TREAM Farmhouse Nightstand with Charging Station

Model: VSC18ST-LRO

Brand: T4TREAM

1. SAFETY INFORMATION

- Always assemble the nightstand on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload drawers or shelves. Refer to specifications for weight limits.
- Keep small parts and packaging materials away from children during assembly.
- Place the nightstand on a level surface to prevent tipping.
- Do not attempt to modify the charging station. Use only as intended with compatible devices.

2. PACKAGE CONTENTS

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact T4TREAM customer support.

- Nightstand Panels (Top, Bottom, Sides, Back)
- Drawer Components (Fronts, Sides, Backs, Bottoms)
- Hardware Pack (Screws, Dowels, Cam Locks, Drawer Slides, Handles)
- Charging Station Unit (with 2 AC Outlets and 2 USB Ports)
- Assembly Guide
- Installation Tool (Hex Key)

Product Dimensions



Figure 2.1: Product Dimensions and Weight Capacities. This image illustrates the overall size and structural load limits of the nightstand.

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your T4TREAM Farmhouse Nightstand. It is recommended to have a second person assist with assembly.

1. **Step 1: Unpack and Identify Parts.** Lay out all components on a clean, soft surface. Refer to the included parts list and diagrams in the assembly guide to identify each piece.
2. **Step 2: Assemble the Main Frame.** Attach the side panels to the bottom panel using the provided screws and dowels. Ensure the orientation is correct for the charging station cutout and drawer slides.
3. **Step 3: Install Drawer Slides.** Secure the drawer slides to the inner side panels of the nightstand frame using the designated screws. Ensure they are level and aligned.
4. **Step 4: Assemble Drawers.** Construct the two drawers by attaching the side, back, and bottom panels to the drawer fronts. Insert the drawer handles.
5. **Step 5: Insert Drawers.** Carefully slide the assembled drawers onto the installed drawer slides within the nightstand frame. Ensure smooth operation.

6. **Step 6: Attach the Top Panel.** Secure the top panel to the assembled frame using the appropriate fasteners. Ensure the cutout for the charging station is correctly positioned.
7. **Step 7: Install the Charging Station.** Place the charging station unit into the designated cutout on the top panel and secure it according to the assembly guide.



Figure 3.1: Drawer Construction Details. This image provides a closer look at the drawer design and interior.

Your browser does not support the video tag.

Video 3.1: T4TREAM Farmhouse Nightstand Overview. This video demonstrates the features and design of the nightstand, including its dimensions and aesthetic details, which can aid in understanding the assembly process.

4. OPERATING INSTRUCTIONS

Using the Integrated Charging Station

The T4TREAM Farmhouse Nightstand features a convenient charging station integrated into its top surface. This allows for easy access to power for your electronic devices.

1. **Power Connection:** Ensure the nightstand's power cord (4.9-foot length) is securely plugged into a functional wall outlet.

2. **AC Outlets:** The charging station includes two 125V/12A AC outlets. Plug in any standard electronic device that requires an AC power source.
3. **USB Ports:** Two 5V/2.1A USB ports are available for charging compatible USB-powered devices such as smartphones, tablets, or smartwatches. Connect your device's USB cable to the port.
4. **Safety Note:** Do not exceed the maximum power rating of the charging station. Avoid spilling liquids on the charging unit.



Figure 4.1: Convenient Charging Station. This image demonstrates the functionality of the integrated power outlets and USB ports.

5. MAINTENANCE

- **Cleaning:** Wipe the nightstand surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Hardware Check:** Periodically inspect all screws, bolts, and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Drawer Care:** If drawers become stiff, apply a small amount of silicone lubricant to the drawer slides. Avoid forcing drawers open or closed.
- **Charging Station:** Keep the charging station free of dust and debris. Do not insert foreign objects

into the outlets or USB ports.

6. TROUBLESHOOTING

- **Issue: Nightstand is wobbly.**

Solution: Check all assembly screws and ensure they are fully tightened. Verify the nightstand is on a level surface.

- **Issue: Drawers do not slide smoothly.**

Solution: Ensure drawer slides are correctly installed and aligned. Check for any obstructions in the slides. Apply silicone lubricant if needed.

- **Issue: Charging station is not working.**

Solution: Verify the nightstand's main power cord is securely plugged into a live wall outlet. Check if the device being charged is compatible and its cable is functioning.

- **Issue: Minor scratches or blemishes on the surface.**

Solution: For minor imperfections, a furniture repair marker or touch-up paint matching the Light Rustic Oak finish may be used.

7. SPECIFICATIONS

Excellent Workmanship



Imitation Wood Grain

- The sturdy, imitation wood grain table top with good aesthetic feeling effect

Solid Foundation

- Roman column style exterior decor, showing a simple, elegant, and atmospheric



Figure 7.1: Excellent Workmanship Details. This image showcases key structural and aesthetic features of the nightstand.

Feature	Detail
Model Number	VSC18ST-LRO
Product Dimensions (D x W x H)	18"D x 18.02"W x 24"H
Item Weight	40 Pounds
Frame Material	Wood
Top Material Type	FSC-Certified Engineered Wood
Color	Light Rustic Oak
Number of Drawers	2
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2.1A)
Power Cord Length	4.9-foot
Tabletop Thickness	1.18 Inches
Recommended Uses	Storage, Displaying, Charging Station
Indoor/Outdoor Usage	Indoor

8. WARRANTY AND SUPPORT

T4TREAM is committed to providing quality products and customer satisfaction. If you encounter any issues during assembly, operation, or have questions regarding your nightstand, please refer to the following:

- **Assembly Assistance:** The product includes clear assembly instructions and labeled parts to facilitate the setup process.
- **Customer Service:** For professional assistance with any concerns or to report missing/damaged parts, please contact T4TREAM customer support. Contact information can typically be found on the product packaging or the official T4TREAM website.
- **Warranty Information:** Specific warranty details are provided with the product packaging. Please retain your proof of purchase for any warranty claims.