

uscce UE188-VB

uscce 3-Level Adjustable Bed Shaker Instruction Manual

Model: **UE188-VB** | Brand: **uscce**

INTRODUCTION

Thank you for purchasing the uscce 3-Level Adjustable Bed Shaker. This device is designed to provide a strong, silent vibration to wake heavy sleepers or individuals with hearing impairment. It is an essential accessory for the uscce UE188 Loud Alarm Clock, providing an alternative or supplementary alarm method.

IMPORTANT NOTE: This bed shaker is **ONLY** compatible with the uscce Model UE188 Loud Alarm Clock. It will not function with other alarm clock models.

PACKAGE CONTENTS

Please ensure all items are present in your package:

- 1 x uscce 3-Level Adjustable Bed Shaker (Model UE188-VB)



Image: The uscce 3-Level Adjustable Bed Shaker, a black, disc-shaped device. It features a side switch labeled 'HI', 'MED', and 'LO' for adjusting vibration intensity. The power cord with a barrel connector is visible, ready for connection. The top surface displays the 'uscce' logo and product information including "Super Shaker", "Bed Vibrator", "Model BV188 5V/1A", "Contact for Warranty: support@uscce-shop.com", and "Made in China".

SETUP INSTRUCTIONS

Follow these steps to connect your bed shaker to the uscce UE188 Loud Alarm Clock:

1. **Locate the Shaker Port:** On the back of your uscce UE188 Loud Alarm Clock, identify the dedicated port for the bed shaker. This port is typically labeled or distinctively shaped to fit the shaker's connector.
2. **Connect the Shaker:** Insert the barrel connector of the bed shaker's cord firmly into the shaker port on the alarm clock. Ensure a secure connection.
3. **Position the Shaker:** Place the bed shaker under your pillow or mattress. For optimal effectiveness, position it where it will be in direct contact with your body.
4. **Power On:** Ensure your uscce UE188 Loud Alarm Clock is plugged into a power outlet and functioning correctly. The bed shaker draws power directly from the alarm clock.

OPERATING INSTRUCTIONS

The uscce 3-Level Adjustable Bed Shaker offers customizable vibration intensity to suit your preference. The vibration function is activated when the alarm on your connected UE188 alarm clock sounds.

Adjusting Vibration Strength:

On the side of the bed shaker, you will find a physical switch with three settings:

- **HI (High):** Provides the strongest vibration, ideal for heavy sleepers or those requiring maximum sensory input.
- **MED (Medium):** Offers a balanced vibration strength, suitable for most users.
- **LO (Low):** Delivers a gentle vibration, perfect for light sleepers or as a subtle reminder.

Simply slide the switch to your desired vibration level. The selected level will be active the next time the alarm triggers the shaker.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your uscce Bed Shaker, please follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface of the bed shaker with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the device.
- **Storage:** When not in use for extended periods, store the bed shaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the device or subjecting it to strong impacts, which could damage internal components.
- **Moisture:** Keep the bed shaker away from water and high humidity. It is not waterproof.

TROUBLESHOOTING

If you encounter any issues with your uscce Bed Shaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed shaker does not vibrate.	Not properly connected to alarm clock. Alarm clock not powered on or alarm not set. Shaker is not compatible with the alarm clock. Internal malfunction.	Ensure the shaker's connector is fully inserted into the UE188 alarm clock's shaker port. Verify the UE188 alarm clock is plugged in and the alarm is active. Confirm you are using the uscce UE188 Loud Alarm Clock. This shaker is ONLY compatible with that model. If issues persist, contact customer support.
Vibration is too weak or too strong.	Vibration intensity switch is set incorrectly.	Adjust the HI/MED/LO switch on the side of the bed shaker to your preferred intensity.
Shaker makes unusual noises.	Possible internal damage or foreign object.	Discontinue use and contact customer support. Do not attempt to open the device.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	uscce
Model Number	UE188-VB (Also referred to as BV188 5V/1A)
Product Dimensions	3.6"W x 1.4"H (Approximate)
Item Weight	6.4 ounces

Feature	Detail
Material	Plastic
Color	Black
Power Source	Corded Electric (Powered by compatible alarm clock)
Compatibility	ONLY uscce Model UE188 Loud Alarm Clock
Country of Origin	China

WARRANTY AND CUSTOMER SUPPORT

For warranty information, technical assistance, or any questions regarding your uscce 3-Level Adjustable Bed Shaker, please contact our customer support team.

Email: support@uscce.shop

Please have your product model number (UE188-VB) and purchase details ready when contacting support.

