

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Fabater](#) /

› [Fabater Replacement Brush Rollers Cover Instruction Manual](#)

## Fabater Fabaterqzpsog325

# Fabater Replacement Brush Rollers Cover Instruction Manual

Model: Fabaterqzpsog325

## 1. PRODUCT OVERVIEW

---

This document provides comprehensive instructions for the installation, maintenance, and general information regarding the Fabater Replacement Brush Rollers Cover. This accessory is designed to replace the main brush cover on compatible wet dry vacuum cleaners, ensuring continued efficient operation and protection of internal components.

### Key Features:

- **Durable Construction:** Manufactured from premium ABS material for long-lasting use and resistance to wear and damage.
- **Essential Protection:** Effectively prevents dust and debris from entering the brush roller area, maintaining the vacuum cleaner's optimal cleaning performance.
- **High Compatibility:** Designed to be suitable for various Tineco wet dry vacuum cleaner models, ensuring a proper fit.
- **Simple Replacement:** Engineered for easy installation, allowing users to replace the cover without the need for additional tools.

### Product Identification:





Figure 1.1: Front view of the Fabater Replacement Brush Rollers Cover. This image displays the transparent grey cover with its integrated black latch mechanism.

## 2. INSTALLATION GUIDE

---

Replacing the brush roller cover is a straightforward process. Follow these steps carefully to ensure proper installation and functionality.

### Compatibility:

This brush roller cover is compatible with various Tineco wet dry vacuum cleaner models. Please verify your vacuum cleaner's model number against the following list for confirmed compatibility:

- **For FW1.0:** FW20E 01, FW26M 01, FW25N 01, FW25N 02, FW25M 01, FW25M 02, FW25M 03, FWO4100CN, FW100500CN
- **For FW Pro 2.0LED LCD:** FWOQEECN, FW100100CN, FW100400CN, FW100700CN

- **For FW 2.0SLIM:** FW150100CN, FW160100CN, FW150500CN, FW18010ECN, FW18020ECN, FW18030ECN, FW160500CN



Figure 2.1: The replacement brush cover shown alongside a compatible wet dry vacuum cleaner, illustrating its intended use and fit.

### Step-by-Step Installation:

1. **Preparation:** Ensure your vacuum cleaner is turned off and unplugged from any power source before beginning the replacement process.
2. **Remove Old Cover:** Locate the existing brush roller cover on your vacuum cleaner. Typically, there is a latch or release mechanism. Gently press the release button or slide the latch to unlock and remove the old cover.



Figure 2.2: Close-up view of the latch mechanism on the brush cover, indicating where to press for removal or installation.

3. **Clean Area (Optional):** While the cover is removed, it is an opportune time to clean any accumulated dust or debris from

the brush roller compartment of your vacuum cleaner.

4. **Install New Cover:** Align the new Fabater Replacement Brush Rollers Cover with the corresponding slots on your vacuum cleaner. Gently press it into place until you hear a click, indicating that the latch has securely engaged. Ensure it is flush and stable.

## Installation Video:

Your browser does not support the video tag.

*Video 2.1: This video demonstrates the process of replacing the brush roller cover on a compatible Tineco wet dry vacuum cleaner. It shows the removal of the old cover and the secure installation of the new replacement part.*

## 3. FUNCTIONALITY AND PURPOSE

---

Once correctly installed, the Fabater Replacement Brush Rollers Cover serves a critical role in the efficient operation of your wet dry vacuum cleaner. Its primary functions include:

- **Protection:** It acts as a protective barrier, shielding the internal brush roller and motor from direct exposure to dust, dirt, and liquid during cleaning operations.
- **Optimized Airflow:** The design of the cover ensures proper airflow around the brush roller, which is essential for effective suction and drying performance.
- **Structural Integrity:** It contributes to the overall structural integrity of the vacuum cleaner's floor head, keeping all components securely in place during use.



Figure 3.1: The brush cover integrated into the vacuum cleaner's floor head, demonstrating its role in protecting the brush roller.

## 4. MAINTENANCE

---

Regular maintenance of the brush roller cover helps prolong its lifespan and ensures the continued optimal performance of your vacuum cleaner. While the cover itself requires minimal maintenance, periodic cleaning is recommended.

### Cleaning Instructions:

1. **Removal:** Follow the steps in Section 2.2 to remove the brush roller cover from the vacuum cleaner.
2. **Wipe Down:** Use a soft, damp cloth to wipe away any dust, dirt, or residue from the surface of the cover. For stubborn grime, a mild soap solution can be used, followed by a clean damp cloth.
3. **Dry Thoroughly:** Ensure the cover is completely dry before reattaching it to the vacuum cleaner. Air drying is recommended.
4. **Inspect:** While cleaning, inspect the cover for any signs of wear, cracks, or damage. If significant damage is observed, consider replacing the cover to maintain vacuum performance and prevent further issues.



Figure 4.1: Top view of the brush cover, illustrating the areas that may require periodic cleaning to remove accumulated debris.

## 5. TROUBLESHOOTING

This section addresses common issues that may arise with the brush roller cover and provides solutions.

Problem	Possible Cause	Solution
Cover does not fit or latch securely.	Incorrect model compatibility; improper alignment during installation; debris obstructing the latch.	Verify your vacuum cleaner model against the compatibility list in Section 2.1. Re-align the cover carefully and ensure the latch clicks into place. Check for and remove any debris around the latch mechanism.
Vacuum cleaner performance is reduced after cover replacement.	Cover not fully seated; brush roller or other vacuum components are dirty or damaged.	Ensure the cover is securely latched. Inspect the brush roller and other vacuum parts for blockages or damage and clean/replace as necessary.
Visible wear or damage on the cover.	Normal wear and tear; impact damage.	The cover is designed for durability, but over time or due to accidents, it may show wear. Replace the cover if damage affects its protective function or fit.

## 6. SPECIFICATIONS

Detailed specifications for the Fabater Replacement Brush Rollers Cover.

**Brand:** Fabater

**Model Number:** Fabaterqzpsog325

**Material:** Premium ABS

**Item Weight:** 7.4 ounces (approximately 209.79 grams)

**Package Dimensions:** 12.17 x 5.79 x 1.85 inches (approximately 30.91 x 14.71 x 4.70 cm)

**Compatibility:** Designed for various Tineco wet dry vacuum cleaner models (refer to Section 2.1 for specific models).

## 7. WARRANTY AND SUPPORT

---

For information regarding product warranty, returns, or technical support, please refer to the following resources:

- **Purchase Platform:** Consult the specific return and warranty policies provided by the retailer where the product was purchased (e.g., Amazon.com).
- **Manufacturer Support:** For direct inquiries, visit the official [Fabater Store on Amazon](#) or contact Fabater customer service through the contact information provided on their official channels.

Always retain your proof of purchase for warranty claims.



© 2023 Fabater. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.