



[Manuals.plus](#) /

› [Living District](#) /

› Living District Rohan 54" 6-Light Transitional Metal Chandelier in Matte Black User Manual

Living District LD5056D54MB

Rohan 54" 6-Light Transitional Metal Chandelier

Model: LD5056D54MB | Brand: Living District

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Living District Rohan 54" 6-Light Transitional Metal Chandelier. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: The Rohan 54-inch 6-Light Transitional Metal Chandelier in Matte Black, showcasing its full design.

IMPORTANT SAFETY INFORMATION

- **WARNING:** To avoid electric shock, disconnect power at the circuit breaker before installation.
- All electrical connections must be in accordance with local and National Electrical Code (NEC) standards. If you are unfamiliar with proper electrical wiring connections, consult a qualified electrician.
- This fixture is intended for indoor, dry location use only. Do not expose to moisture.
- Use only E12 base bulbs, with a maximum wattage of 40W per bulb, not exceeding a total of 240W for all six lights.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.
- Always handle the fixture with care. Avoid bending the arms or applying excessive force.

PACKAGE CONTENTS

Carefully unpack the box and ensure all components are present and undamaged. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer support immediately.

- Living District Rohan 54" 6-Light Transitional Metal Chandelier (1 unit)

- 60-inch matching finish chain (1 unit)
- Mounting hardware kit (includes canopy, mounting plate, screws, wire nuts)
- Black electrical wire
- Instruction manual

Note: Light bulbs are not included.



Image: The main body of the Rohan Chandelier with its six arms and central stem, ready for installation.

SETUP AND INSTALLATION

Before installation, ensure the power is turned off at the circuit breaker. It is recommended to have two people for installation due to the size of the fixture.

1. **Prepare the Mounting Location:** Ensure your ceiling junction box is securely mounted and capable of supporting the fixture's weight (approximately 7 lbs).
2. **Attach Mounting Plate:** Secure the mounting plate to the junction box using the provided screws.
3. **Adjust Hanging Height:** The chandelier offers an adjustable hanging height from 36 inches to a maximum of 90 inches. Determine your desired height and adjust the 60-inch chain accordingly. You may need to remove links from the chain.
4. **Wire Connections:**

- Connect the black wire from the fixture to the black (hot) wire from the ceiling using a wire nut.
- Connect the white wire from the fixture to the white (neutral) wire from the ceiling using a wire nut.
- Connect the ground wire from the fixture to the ground wire from the ceiling (usually bare copper or green) using a wire nut.
- Ensure all connections are secure and tucked neatly into the junction box.

5. **Secure the Canopy:** Slide the canopy up to the ceiling and secure it with the provided hardware, covering the junction box and wiring.

6. **Install Bulbs:** Screw six E12 base bulbs (not included) into the sockets. Do not exceed 40W per bulb.

This chandelier can be installed on sloped ceilings. Ensure the mounting hardware is compatible with your ceiling type.



Image: A close-up view of one of the E12 bulb sockets, showing where the bulb is inserted.

Once installed and wired correctly, restore power at the circuit breaker.

- **Power On/Off:** Operate the chandelier using a standard wall switch (push button control).
- **Dimming Function:** This chandelier is dimmable. To utilize the dimming feature, ensure you are using dimmable E12 bulbs and a compatible dimmer switch (sold separately).
- **Light Direction:** The light is directed upwards, providing ambient illumination.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

- **Cleaning:** Turn off the power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the matte black finish.
- **Bulb Replacement:** Ensure the power is off and the bulbs have cooled before replacing. Unscrew old bulbs and screw in new E12 base bulbs.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Power is off at the circuit breaker. Loose wire connection. Faulty bulb.	Check circuit breaker and restore power. Turn off power, check all wire connections. Replace bulb with a new one.
Light flickers.	Loose bulb. Incompatible dimmer switch or non-dimmable bulbs.	Tighten bulbs. Ensure dimmable bulbs are used with a compatible dimmer switch.

If you experience issues not listed here or if the problem persists, please contact Living District customer support.

SPECIFICATIONS

Model Number	LD5056D54MB
Brand	Living District
Material	Metal (Iron)
Finish	Matte Black
Dimensions (L x W x H)	54" x 54" x 28"
Canopy Dimensions (H x W x D)	1.5" x 5.2" x 5.2"
Adjustable Hanging Height	36" to 90"
Chain Length	60"

Wire Length	79"
Item Weight	7 lbs
Number of Lights	6
Bulb Base	E12
Max Wattage per Bulb	40W
Total Max Wattage	240W
Voltage	110V - 125V
Dimmable	Yes (with compatible bulbs and dimmer switch)
Indoor/Outdoor Use	Indoor Only (Dry Location)
Light Direction	Up

WARRANTY AND SUPPORT

This Living District Rohan Chandelier comes with a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by improper installation, misuse, abuse, accidents, or unauthorized modifications. Light bulbs are not covered under warranty.

For warranty claims, technical support, or missing parts, please contact Living District customer service. Have your model number (LD5056D54MB) and proof of purchase ready.

Manufacturer: Living District