

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Renimer](#) /

> [Renimer BK11 Bluetooth 5.3 Wireless Earbuds User Manual](#)

## Renimer BK11

# Renimer BK11 Bluetooth 5.3 Wireless Earbuds User Manual

Model: BK11

## INTRODUCTION

---

### Welcome

Thank you for choosing the Renimer BK11 Bluetooth 5.3 Wireless Earbuds. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new earbuds. Please read this guide thoroughly before use to ensure optimal performance and longevity of your device.

### Package Contents

- Renimer BK11 Wireless Earbuds
- Charging Case
- USB-C Charging Cable
- User Manual
- S/M/L Eartips

## PRODUCT OVERVIEW

---

### Earbud and Charging Case Diagram

Familiarize yourself with the components of your Renimer BK11 earbuds and charging case.



This image displays the Renimer BK11 wireless earbuds placed inside their charging case. The case features an LED display showing "100" and battery indicators, suggesting a full charge. The earbuds themselves have a sleek, dark design with a blue indicator light and a fingerprint-like icon on the touch control area. Model number BK11 and FCC ID are visible on the inside of the case.

### Touch Controls

The earbuds feature touch-sensitive controls for various functions. The exact touch areas are indicated by the fingerprint icon on each earbud.

- **Single tap:** Play/Pause music, Answer/End a phone call.
- **Double tap (Right earbud):** Next track.
- **Double tap (Left earbud):** Previous track.
- **Triple tap (Right earbud):** Volume up.

- **Triple tap (Left earbud):** Volume down.
- **Long press (approx. 2 seconds):** Activate voice assistant, Reject an incoming call.

## SETUP

### Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case to ensure maximum battery life.




This image illustrates the Renimer BK11 charging case being charged via a USB-C cable. The case's LED display shows the battery level, indicating the charging status.

- Connect the provided USB-C cable to the charging port on the case and to a standard USB power adapter (not included).
- The LED display on the case will indicate the charging status and current battery percentage.
- A full charge for the charging case takes approximately 1.5 hours.
- The earbuds provide 6-8 hours of playtime on a single charge.
- The 350 mAh charging case provides multiple recharges, extending total playtime up to 40 hours.

### Bluetooth Pairing

Follow these steps to pair your Renimer BK11 earbuds with your device.



This image illustrates the Bluetooth pairing process, showing a smartphone's Bluetooth settings with "BK11" listed as an available device to connect to. The Renimer BK11 charging case and earbuds are also visible.

### Initial Pairing

1. Ensure both earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, computer, etc.), enable Bluetooth.
4. Search for "BK11" in the list of available Bluetooth devices and select it to connect.
5. Once connected, a voice prompt will confirm successful pairing.

### Reconnecting

Once paired, the earbuds will automatically reconnect to the last paired device when taken out of the charging case, provided Bluetooth is enabled on the device and it is within range.

### Resetting Earbuds

If you experience pairing issues or only one earbud is connecting, you can reset the earbuds:

- Place both earbuds back into the charging case.

- Close the case lid and wait for approximately 5 seconds.
- Open the case lid again. The earbuds should re-synchronize and enter pairing mode.
- If issues persist, try forgetting "BK11" from your device's Bluetooth list and repeat the initial pairing process.

## OPERATING INSTRUCTIONS

### Wearing the Earbuds

For optimal sound quality, comfort, and secure fit, choose the correct eartip size.



# ERGONOMIC DESIGN & IP7 WATERPROOF

Earbud only 3.9g ,  
3 sizes of soft silicone ear design,  
comfort and secure fit

  
Ergonomic Design

  
IP7 Waterproof

  
S/M/L Eartips

This image highlights the ergonomic design of the Renimer BK11 earbuds, showing how they fit securely in the ear. It also displays three sizes of soft silicone eartips (S/M/L) to ensure a comfortable and secure fit for different users.

- Select the eartips (S/M/L) that provide the best seal and comfort for your ears.
- Gently insert the earbuds into your ear canal and twist slightly to secure them in place.

### Call Functions

The earbuds feature CVC8.0 noise reduction and 4 microphones (ENC Mic, Talk Mic) for clear phone calls, minimizing background noise.


# ENC ENC Noise Cancelling- Clear Phone Calls

With 4 microphones and the ENC Noise cancellation technology keep your call clearer.



ENC Mic

Talk Mic



Noise Voice

Before After

This image details the noise-cancelling capabilities, showing the placement of ENC (Environmental Noise Cancellation) and Talk microphones on the earbuds. A graph demonstrates the reduction of noise frequencies "Before" and "After" processing, indicating clearer phone calls.

- **Answer/End Call:** Single tap either earbud.
- **Reject Call:** Long press either earbud for approximately 2 seconds.

## Music Playback

Control your music directly from the earbuds.


- **Play/Pause:** Single tap either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Volume Up:** Triple tap the right earbud.
- **Volume Down:** Triple tap the left earbud.

## Sound Quality

The Renimer BK11 earbuds feature 14.2mm drivers for excellent HiFi sound reproduction.

# EXCELLENT HIFI SOUND

10% larger diameter  
than previous generation



This image provides an internal view of the earbud's driver, highlighting its 14.2mm size and various components, indicating a focus on high-fidelity sound reproduction.

## MAINTENANCE

### Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, abrasive materials, or liquids directly on the earbuds or case.
- Gently remove any earwax or debris from the eartips and speaker mesh using a small, soft brush or cotton swab.

### Storage

- When not in use, always store the earbuds in their charging case to protect them from damage and keep them charged.
- Store the device in a cool, dry place, away from extreme temperatures, direct sunlight, and humidity.

## TROUBLESHOOTING

## Common Issues and Solutions

### 1. Earbuds not pairing:

- Ensure both earbuds are sufficiently charged.
- Place them back in the case, close the lid, then reopen to re-initiate pairing mode.
- Turn off and then turn on your device's Bluetooth.
- Forget "BK11" from your device's Bluetooth list and attempt to re-pair.

### 2. Only one earbud working:

- Ensure both earbuds are charged.
- Place both earbuds back in the charging case, close the lid, wait a few seconds, then open the lid again. This often resynchronizes them.
- If the issue persists, try resetting the earbuds as described in the "Resetting Earbuds" section.

### 3. Poor sound quality:

- Ensure the eartips are properly sealed in your ear canal. Try different eartip sizes.
- Clean any debris from the speaker mesh.
- Ensure the earbuds are within Bluetooth range (typically 10 meters) of your device and there are no significant obstructions.
- Check your device's audio settings and volume levels.

### 4. Charging issues:

- Ensure the USB-C cable is securely connected to both the charging case and the power source.
- Try a different USB-C cable or power adapter to rule out cable/adaptor issues.
- Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.

If problems persist after attempting these solutions, please contact customer support for further assistance.

## SPECIFICATIONS

### Technical Specifications

Feature	Specification
Model	BK11
Bluetooth Version	5.3
Driver Size	14.2 mm
Noise Reduction	CVC8.0, ENC
Microphones	4 (ENC Mic, Talk Mic)
Water Resistance Rating	IP7
Earbud Playtime	6-8 Hours (single charge)
Charging Case Capacity	350 mAh
Total Playtime (with case)	Up to 40 Hours

Charging Time (Case)	Approx. 1.5 Hours
Charging Port	USB-C
Earbud Weight	Approx. 3.9g (each)
Frequency Range	20 Hz - 20,000 Hz
Battery Composition	Lithium-polymer
Compatible Devices	Mobile phones, Computers, Smart speakers

## WARRANTY AND SUPPORT

### Warranty Information


Renimer products are designed for reliability and performance. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Renimer website for the most up-to-date policy.


### Customer Support

If you have any questions, require technical assistance, or encounter any issues with your Renimer BK11 earbuds, please do not hesitate to contact our dedicated customer support team. Contact information can typically be found on the product packaging, the warranty card, or our official website.

© 2024 Renimer. All rights reserved.

## Related Documents - BK11

 <p>User Guide for BK11 True Wireless Stereo Earphones</p>	<p><a href="#">BK11 True Wireless Stereo Earphones User Guide</a></p> <p>A comprehensive user guide for the BK11 True Wireless Stereo Earphones, covering product specifications, pairing instructions, functions, charging, storage, maintenance, and troubleshooting.</p>
 <p>User Guide for i50 True Wireless Stereo Earphones</p>	<p><a href="#">User Guide for i50 True Wireless Stereo Earphones</a></p> <p>This user guide provides instructions and specifications for the i50 True Wireless Stereo Earphones, covering pairing, functions, charging, storage, maintenance, and troubleshooting.</p>
 <p>User Guide for BK11 True Wireless Stereo Earphones</p>	<p><a href="#">BK11 True Wireless Stereo Earphones User Guide</a></p> <p>A comprehensive user guide for the BK11 True Wireless Stereo Earphones, covering product specifications, pairing instructions, functions, charging, storage, maintenance, and troubleshooting.</p>




### [BK11-A Smart Screen Projection Phone Holder User Manual](#)

User manual for the BK11-A Smart Screen Projection Phone Holder by Shenzhen Zhiding Manufacturing Co., Ltd. Details installation, product parameters, functions like wireless charging and screen projection, program usage, and important safety precautions.



### [Hirose BK11 Series: Ultra-Compact FPC-to-Board Connector for Portable Electronics](#)

Explore the Hirose BK11 Series, an ultra-compact FPC-to-board connector engineered for high-performance portable electronics. With a 0.35mm pitch and up to 8A current capacity, it provides a robust, space-saving connectivity solution for devices like smartphones, wearables, and wireless audio equipment.



### [AVAWOOD SS-HNG11](#)

AVAWOOD SS-HNG11