Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

vivicreate HT-C-0012

Vivicreate Cast Iron Propane Gas Stove

MODEL: HT-C-0012

Instruction Manual

Introduction

Thank you for choosing the Vivicreate HT-C-0012 Cast Iron Propane Gas Stove. This heavy-duty, portable double burner stove is designed for outdoor cooking, offering reliable performance for camping, tailgating, backyard use, and emergency preparedness. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal use of your stove.

Important Safety Information

WARNING: For outdoor use only. Never operate this appliance in an enclosed space such as a camper, tent, car, or home. Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

- Always operate the stove on a level, stable, non-combustible surface.
- Keep combustible materials at least 3 feet (0.9 meters) away from the top, sides, and back of the stove.
- Ensure adequate ventilation.
- Do not leave the operating stove unattended.
- Perform a leak test every time the propane cylinder is connected or if you suspect a leak.
- Keep children and pets away from the stove during operation.
- Do not use the stove if it has a damaged hose or regulator.
- Always turn off the propane supply at the cylinder when not in use.

Package Contents

Verify that all components are present and undamaged before assembly:

- Vivicreate Cast Iron Double Burner Stove (HT-C-0012)
- 4 Detachable Legs

- Propane Gas Hose
- CSA Listed Pressure Regulator

Setup Instructions

1. **Assemble the Legs:** Attach the four detachable legs to the base of the stove. Ensure they are securely fastened to provide a stable cooking platform.
2. **Connect the Regulator and Hose:**



Image: The Vivicreate HT-C-0012 stove with the propane hose and CSA-listed regulator connected, ready for use.

Connect the propane gas hose to the stove's gas inlet. Then, connect the CSA-listed pressure regulator to a standard propane tank (not included). Hand-tighten all connections. Do not overtighten.

3. **Perform a Leak Test:**
   Before first use and after every propane tank connection, perform a leak test. Mix a solution of soapy water (50% soap, 50% water). Open the propane tank valve slowly. Apply the soapy solution to all gas connections. If bubbles appear, there is a leak. Immediately close the propane tank valve and tighten the connection. Repeat the test. If leaks persist, do not use the stove and contact customer support.
4. **Position the Stove:** Place the stove on a firm, level surface outdoors, away from any combustible materials.

Your browser does not support the video tag.

Video: A demonstration of connecting the propane tank and lighting the burners on a Vivicreate double burner stove.

Operating Instructions

1. **Open Propane Supply:** Slowly open the valve on your propane tank.
2. **Light the Burner:** Turn the control knob for the desired burner counter-clockwise to the 'HIGH' position. Immediately apply a long-stem lighter or match to the burner ports. The burner should ignite within a few seconds.



Image: The Vivicreate HT-C-0012 stove with both burners actively producing blue flames, indicating proper operation.

3. **Adjust Flame:** Rotate the control knob to adjust the flame intensity from 'HIGH' to 'LOW' as needed for cooking.
4. **Cooking:** Place your cookware on the sturdy cast iron grates. The dual burners allow for simultaneous cooking of different items.



Image: The Vivicreate HT-C-0012 stove being used outdoors, with two pans cooking food over the lit burners.

5. **Turn Off:** When finished cooking, turn the control knobs clockwise to the 'OFF' position. Then, close the valve on the propane tank completely.

Your browser does not support the video tag.

Video: A brief demonstration of the Vivicreate outdoor propane stove in operation, showing flame adjustment and cooking.

Maintenance

- **Cleaning:** Allow the stove to cool completely before cleaning. Wipe down the cast iron surfaces with a damp cloth. For stubborn food residue, use a mild soap solution and a non-abrasive brush. Rinse thoroughly and dry completely to prevent rust.
- **Storage:** Disconnect the propane tank and store it in a well-ventilated area away from direct sunlight and heat sources. Disassemble the stove legs for compact storage and transport. Store the stove in a dry place to prevent corrosion.
- **Inspection:** Regularly inspect the propane hose and regulator for any signs of wear, cracks, or damage. Replace immediately if any damage is found. Ensure burner ports are clear of debris.

Troubleshooting

Problem	Possible Cause	Solution
Burner does not light	No propane flow; Clogged burner ports; Faulty regulator/hose	Check propane tank valve; Clear burner ports; Perform leak test; Replace regulator/hose if damaged
Low flame or inconsistent flame	Low propane level; Clogged burner ports; Regulator issue	Check propane tank level; Clean burner ports; Ensure regulator is properly connected and not faulty
Gas odor detected	Gas leak	Immediately turn off propane tank. Perform a leak test. Do not operate if leak persists.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact customer support.

Specifications

Feature	Detail
Model Number	HT-C-0012
Brand	Vivicreate
Fuel Type	Propane
Material	Cast Iron
Product Dimensions (L x W x H)	13" x 9.5" x 5" (33cm x 24.1cm x 12.7cm)
Item Weight	5.5 Pounds (2.5 kg)
Maximum Energy Output	Up to 11800 BTU per burner
Included Components	CSA listed regulator, Gas hose

Note: Product dimensions and weight are approximate.



Image: The Vivicreate HT-C-0012 stove with key dimensions (length, width, height) indicated.

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact the manufacturer directly through their official website or customer service channels. Please have your model number (HT-C-0012) and proof of purchase available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMYWPXJM

More documents and user manuals: **https://manuals.plus/**